

AK3-A214

Generic LED Lamp Soccer Club Barcelona User Manual

Model: AK3-A214 | Brand: Generic

INTRODUCTION

Thank you for purchasing the Generic LED Lamp Soccer Club Barcelona. This lamp features a vibrant 7-color display, USB power, and a convenient touch switch for easy operation. This manual provides essential information for safe and proper use, setup, and maintenance of your new LED lamp.

IMPORTANT SAFETY INFORMATION

- Read all instructions before use and retain for future reference.
- Do not expose the lamp to water or excessive moisture. This product is for indoor use only.
- Use only the provided USB cable for power.
- Avoid touching the acrylic panel with fingers to prevent smudges. Handle by the edges.
- Keep out of reach of small children.
- Do not attempt to disassemble or modify the lamp. This will void the warranty.
- Ensure the lamp is placed on a stable, flat surface.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1 x LED Lamp Base
- 1 x Acrylic Design Panel (Soccer Club Barcelona)
- 1 x USB Power Cable
- 1 x Remote Control (requires 3 AA batteries, not included)

SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove all components from the packaging.
2. **Insert Acrylic Panel:** Gently insert the acrylic design panel into the slot on the LED lamp base. Ensure it is fully seated

and stable.



Image: The acrylic panel, featuring the Soccer Club Barcelona crest, is shown being inserted into the black circular lamp base.

3. **Connect Power:** Connect the small end of the USB power cable to the port on the lamp base. Connect the other end to a USB power adapter (not included) or a powered USB port.
4. **Remote Control Batteries:** If using the remote control, open the battery compartment and insert 3 AA batteries, observing correct polarity.
5. **Placement:** Place the assembled lamp on a flat, stable surface in your desired location.

OPERATING INSTRUCTIONS

Using the Touch Switch:

1. **Power On:** Touch the power button on the lamp base once to turn on the lamp. It will illuminate in the first color.
2. **Change Color:** Each subsequent touch of the power button will cycle through the 7 available colors (e.g., Red, Green, Blue, Yellow, Cyan, Purple, White).
3. **Automatic Color Cycle:** After cycling through all individual colors, the next touch will activate an automatic color-changing mode, where the lamp smoothly transitions between colors.
4. **Power Off:** Touch and hold the power button for approximately 2-3 seconds to turn off the lamp.

Your browser does not support the video tag.

Video: This video demonstrates the touch switch functionality, showing how to cycle through the different colors of the Barcelona LED lamp.

Using the Remote Control:

If your model includes a remote control, point it directly at the lamp base. The remote typically allows for direct color selection, brightness adjustment, and various lighting modes. Refer to the remote's specific buttons for their functions.

MAINTENANCE

- **Cleaning:** To clean the acrylic panel, gently wipe it with a soft, lint-free cloth. For smudges, use a slightly damp cloth and then dry thoroughly. Avoid abrasive cleaners or solvents.
- **Base Cleaning:** Wipe the lamp base with a dry, soft cloth.
- **Storage:** When not in use, store the lamp in a dry, cool place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	No power or loose connection.	Ensure the USB cable is securely connected to both the lamp base and a powered USB port/adaptor. Try a different USB port or adapter.
Colors are not changing.	Touch switch not responding or remote control issue.	Ensure you are touching the correct area of the touch switch. If using a remote, check battery and line of sight. Replace remote batteries if necessary.
Acrylic panel does not fit into the base.	Incorrect orientation or manufacturing variance.	Ensure the panel is inserted in the correct orientation. Gently try to insert it without forcing. If it still does not fit, contact customer support.
Lamp flickers or turns off unexpectedly.	Unstable power supply.	Use a stable power source. Avoid connecting to USB ports that may have fluctuating power output.

SPECIFICATIONS

Feature	Detail
Brand	Generic
Model Number	AK3-A214
Lamp Type	LED
Light Source Type	LED
Number of Light Sources	7 (colors)
Control Method	Touch, Remote
Power Source	Corded Electric (USB Cable)
Material	Plastic
Product Dimensions	2"D x 3"W x 6"H
Item Weight	0.035 ounces (approx. 1 gram)
Voltage	127 Volts (Input for adapter, lamp likely 5V USB)
Wattage	Max 2.5 Watts
Indoor/Outdoor Usage	Indoor
Assembly Required	No (minimal insertion)
Batteries Required	Yes (3 AA for remote)



Image: The Generic LED Lamp Soccer Club Barcelona, featuring the FC Barcelona crest, illuminated in a bright blue color.




WARRANTY AND SUPPORT




For information regarding warranty coverage or technical support, please refer to the product packaging or contact the retailer where the product was purchased. Keep your proof of purchase for any warranty claims.

For further assistance, you may also visit the manufacturer's website or contact their customer service department if contact details are provided on the packaging.

© 2023 Generic. All rights reserved.
This manual is subject to change without notice.

Related Documents - AK3-A214

	<p>NiPoGi Mini PC User Manual - AK1, AK2, AK3, GK3 Series</p> <p>Comprehensive user guide for NiPoGi Mini PCs (AK1, AK2, AK3, GK3). Features interface explanations, 2.5-inch disk installation, usage instructions, troubleshooting Q&A, and safety precautions.</p>
	<p>NiPoGi Mini PC User Manual for AK1, AK2, AK3, GK3 Series</p> <p>Comprehensive user manual for NiPoGi Mini PCs, covering interface introductions, installation of 2.5" disks, usage instructions, troubleshooting, and precautions for AK1, AK2, AK3, and GK3 models.</p>
	<p>Nova Comet II DR Midi Lathe User Manual</p> <p>Comprehensive user manual for the Nova Comet II DR Midi Lathe, covering safety, setup, operation, maintenance, and troubleshooting.</p>

 The image shows the cover of the Uwell Caliburn AK3 Pod System User Manual. It features a dark background with the Uwell logo in white at the top. Below the logo, the text "User Manual" is written in a small white box, followed by "CALIBURN AK3 Pod System" in a smaller white font.	<p>Uwell Caliburn AK3 Pod System User Manual</p> <p>User manual for the Uwell Caliburn AK3 Pod System, detailing device illustration, quick start guide, specifications, instructions for filling, vaping, charging, and protection features.</p>
 The image shows the cover of the Danfoss ECL Comfort 296 Electronic Controller Data Sheet. It features a light gray background with a small image of the controller unit in the center. The text "Electronic controllers" is written in a small black font, followed by "ECL Comfort 296" in a larger black font. At the bottom, it says "Remote Control Units ECL 301, 311 and Application Kits" in a very small black font.	<p>Danfoss ECL Comfort 296 Electronic Controller Data Sheet</p> <p>Comprehensive data sheet for the Danfoss ECL Comfort 296 electronic weather compensated temperature controller. Details features, applications, ordering information, technical specifications, and installation guides for HVAC and district heating systems.</p>
 The image shows the cover of the Avalon A14/A14BLK Water Cooler Use and Care Guide. It features a light blue background with the text "A few simple steps to ensure perfect water, every time." in a small black font. The Avalon logo is at the bottom right.	<p>Avalon A14/A14BLK Water Cooler Use and Care Guide: Ensuring Perfect Water</p> <p>Comprehensive guide for Avalon A14 and A14BLK water coolers. Learn about features, installation, operation, maintenance, troubleshooting, safety, and warranty for your Avalon water dispenser.</p>