Bellemave Bed Frame

Bellemave Twin Size Loft Bed with Desk and Shelves Instruction Manual

Model: Bed Frame

Introduction

This manual provides essential information for the safe assembly, operation, and maintenance of your Bellemave Twin Size Loft Bed with Desk and Shelves. Please read all instructions carefully before assembly and use to ensure proper function and safety.

Safety Information

- **Weight Capacity:** The loft bed has a maximum weight capacity of 300 LBS. Do not exceed this limit.
- **Guard Rails:** Always ensure guard rails are properly installed and secured on the upper bunk to prevent falls.
- **Staircase Safety:** Use the provided staircase for access to the upper bunk. Ensure all steps are securely fastened.
- **Mattress Thickness:** Use a mattress with a recommended thickness of 6 inches to maintain adequate guard rail height.
- **Assembly:** Assembly must be performed by adults. Follow all instructions carefully. Periodically check and tighten all connectors.
- **Ventilation:** Ensure adequate ventilation around the bed.
- **No Jumping:** Do not jump on the bed.
- **Small Parts:** Keep small parts away from children during assembly.

Package Contents

Your Bellemave Twin Size Loft Bed package includes all necessary components for assembly. Please verify all parts are present before beginning assembly. Refer to the parts list provided in your physical assembly guide.
Note: Mattress is not included.

Setup and Assembly

Assembly of the Bellemave Twin Size Loft Bed is required. It is recommended that two adults perform the assembly. Please follow the step-by-step instructions provided in the physical assembly manual included with your product.

1. **Unpack:** Carefully unpack all components and hardware. Place them on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Refer to the parts list in your manual to identify each component.
3. **Follow Steps:** Assemble the bed frame, desk, shelves, drawers, and staircase according to the numbered steps in your manual.
4. **Secure Connections:** Ensure all bolts, screws, and connectors are tightened securely. Do not overtighten.
5. **Final Check:** Before use, verify that the entire structure is stable and all safety features, such as guard rails, are correctly installed.



Image: Fully assembled Bellemave Twin Size Loft Bed with integrated desk, shelving unit, and storage staircase. The bed is white and includes a mattress on the upper bunk, with a chair and decor items on the desk.




Image: Technical drawing illustrating the detailed dimensions of the loft bed, including the overall length (95.1"), width (41.8"), height (65"), bed area (76"x39.3"), desk, shelves, and staircase storage compartments.

Operating and Usage

The Bellemave Twin Size Loft Bed is designed for versatile use, combining a sleeping area with a functional workspace and storage.

- **Sleeping Area:** The upper bunk accommodates a twin-size mattress (not included). Ensure the mattress fits snugly within the frame.
- **Integrated Desk:** Utilize the spacious desk area beneath the loft bed for studying, working, or creative activities.
- **Storage Shelves:** The integrated shelves provide convenient storage for books, decor, or personal items.
- **Storage Staircase:** The staircase offers safe access to the upper bunk and features built-in drawers or compartments for additional storage.
- **Drawers:** Two large drawers are integrated into the design, offering concealed storage for various belongings.



Image: A view of the Bellemave Twin Size Loft Bed from the front, highlighting the desk area with a chair and the open shelves on the left side, filled with books and decorative items.



Image: An angled view of the loft bed, focusing on the two open drawers beneath the desk and the storage steps of the staircase, which also feature pull-out drawers.

Maintenance

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Hardware Check:** Periodically inspect all bolts, screws, and connections. Tighten any that have become loose to maintain structural integrity.
- **Avoid Moisture:** Protect the wood from excessive moisture and direct sunlight to prevent warping or discoloration.
- **Weight Distribution:** Distribute weight evenly on shelves and in drawers to prevent strain on the structure.

Troubleshooting

- **Squeaking Noises:** If the bed squeaks, check all connections and tighten any loose bolts. Ensure the bed is on a level surface.
- **Wobbly Structure:** A wobbly bed usually indicates loose hardware. Re-tighten all bolts and ensure the bed is assembled correctly according to the manual.
- **Drawers Sticking:** Check for any obstructions in the drawer glides. Ensure the drawers are properly aligned and the glides are clean.
- **Missing Parts:** If any parts are missing upon delivery, refer to your purchase documentation or contact customer

support immediately.

Specifications

Feature	Detail
Product Type	Loft Bed
Size	Twin
Color	White
Product Material	Pine Wood + MDF
Overall Product Dimension	95.1"L x 41.8"W x 65"H
Bed Dimension	76" x 39.3"
Weight Capacity	300 LBS
Recommended Mattress Thickness	6"
Assembly Required	Yes
Country of Origin	Vietnam

Warranty and Support

Bellemave provides hassle-free after-sales service. If you encounter any non-human damage to the loft bed or have any questions regarding its assembly or use, please contact our customer support. Refer to your purchase documentation for specific contact details or visit the official Bellemave store online.
For more information, visit the Bellemave Store.

© 2023 Bellemave. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question