

Silvercrest SMAS 500 C3

SILVERCREST Kitchen Tools SMAS 500 C3 Milk Frother User Manual

Model: SMAS 500 C3

1. INTRODUCTION

The SILVERCREST Kitchen Tools SMAS 500 C3 Milk Frother is designed to quickly and efficiently prepare perfect milk foam for your coffee and other beverages. It features four selectable programs for various milk preparations, an intuitive LED indicator, and a non-stick interior for easy cleaning. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new appliance.

2. SAFETY INFORMATION

Please read all safety instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the appliance is placed on a stable, level, heat-resistant surface.
- Do not immerse the base unit in water or any other liquid.
- Keep the appliance out of reach of children.
- Do not operate the appliance if the power cord or plug is damaged.
- Unplug the appliance from the power outlet when not in use and before cleaning.
- This appliance is for household use only.
- Avoid contact with moving parts.
- Do not fill above the maximum fill line to prevent overflow.
- The appliance is equipped with overheating protection and boil-dry protection.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your milk frother:



Figure 3.1: Front view of the SILVERCREST SMAS 500 C3 Milk Frother, showing the main unit with handle and control panel.



Figure 3.2: Close-up of the control panel with the central power button and four program icons around it, indicating different frothing options.



Figure 3.3: View inside the milk frother, showing the non-stick interior and the whisk attachment for frothing and heating milk.

- **Main Unit:** The primary body of the frother with a handle.
- **Control Panel:** Features a central power button and four program icons.
- **LED Ring:** Illuminates around the power button to indicate the selected program (red for warm, blue for cold).
- **Non-stick Inner Container:** The interior of the frother with fill level markings.
- **Whisk:** One whisk attachment for both frothing and heating functions.
- **Removable Lid:** With a sealing ring for secure closure.
- **Base Unit:** Wireless, 360° rotatable base with anti-slip feet and cable storage.

4. SETUP

1. **Unpacking:** Carefully remove all packaging materials. Keep packaging for future storage or disposal.
2. **Initial Cleaning:** Before first use, clean the inner container, whisk, and lid with warm soapy water. Rinse thoroughly and dry all parts completely. Do not immerse the base unit in water.
3. **Placement:** Place the frother base on a dry, stable, and heat-resistant surface, away from water sources and direct heat. Ensure the power cord is not tangled and is safely routed.
4. **Attach Whisk:** Ensure the whisk is correctly placed at the bottom of the inner container.
5. **Connect Power:** Plug the power cord into a suitable electrical outlet (220-240V, 50Hz).

5. OPERATING INSTRUCTIONS

The SMAS 500 C3 offers four distinct programs for various milk preparations. The LED ring around the power button indicates the selected program (red for warm, blue for cold).

1. **Fill Milk:** Pour the desired amount of milk into the inner container. Observe the fill level markings:
 - Minimum milk quantity: 75 ml
 - Maximum for heating milk (without frothing): 300 ml
 - Maximum for frothing milk: 150 ml (to prevent overflow)
2. **Close Lid:** Place the lid securely on the frother.
3. **Select Program:** Press the central power button repeatedly to cycle through the four programs. The LED ring will illuminate to indicate the selected program:

- **Red LED, Program 1:** Warm and firm foam.
- **Red LED, Program 2:** Warm and creamy foam.
- **Red LED, Program 3:** Heat milk with little foam.
- **Blue LED, Program 4:** Cold foam.

4. **Start Operation:** Once the desired program is selected, the frother will automatically start.
5. **Completion:** The appliance will automatically shut off once the program is complete. The LED light will turn off.
6. **Serve:** Carefully remove the lid and pour the frothed or heated milk. The container is wireless and rotates 360° on its base for easy pouring.

Note: For best results, use cold milk directly from the refrigerator.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your milk frother. Always unplug the appliance before cleaning.

1. **Unplug:** Disconnect the frother from the power outlet and allow it to cool down completely.
2. **Remove Whisk and Lid:** Carefully remove the whisk from the bottom of the container and detach the lid.
3. **Clean Inner Container:** The non-stick inner container should be cleaned immediately after each use to prevent milk residue from drying. Wash with warm water and a mild dish soap using a soft sponge or cloth. Do not use abrasive cleaners or scourers, as this can damage the premium ILAG non-stick coating. Rinse thoroughly.
4. **Clean Whisk and Lid:** Wash the whisk and lid under running water with mild soap. Ensure all milk residue is removed.
5. **Clean Base Unit:** Wipe the exterior of the main unit and the base with a damp cloth. Never immerse the main unit or base in water.
6. **Dry Thoroughly:** Ensure all parts are completely dry before reassembling or storing the appliance.
7. **Storage:** Store the frother in a clean, dry place. The base unit has cable storage for neat organization.

7. TROUBLESHOOTING

If you encounter issues with your milk frother, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Frother does not turn on.	Not plugged in; power outage; appliance not correctly placed on base.	Check power connection; ensure frother is properly seated on the base.
Milk is not frothing or heating properly.	Incorrect milk quantity; whisk not installed; milk type unsuitable; appliance too hot.	Ensure milk is between min/max lines; check whisk placement; use cold, fresh milk (dairy or suitable plant-based); allow appliance to cool down.
Milk overflows.	Too much milk added.	Do not exceed the maximum fill line for frothing (150 ml).
Burning smell.	Milk residue on heating element; appliance overheating.	Clean the inner container thoroughly; allow appliance to cool. If problem persists, discontinue use and contact support.

If the problem persists after trying these solutions, please contact customer support.

8. SPECIFICATIONS

Model Name	SMAS 500 C3
Brand	Silvercrest
Power	500 W
Voltage	220-240 V, 50 Hz
Capacity (Milk Heating)	Max. 300 ml
Capacity (Milk Frothing)	Max. 150 ml
Total Capacity	620 ml
Material	Stainless Steel, Plastic, Silicone (with ILAG non-stick coating)
Dimensions (approx.)	15.5 x 10.8 x 19.5 cm
Weight (Base approx.)	142 g
Weight (Jug approx.)	580 g
Cable Length	85 cm

9. WARRANTY AND SUPPORT

This product is manufactured by Mlap GmbH. For warranty information, technical support, or service inquiries, please refer to the warranty card included with your purchase or contact the retailer where the product was purchased. Please have your model number (SMAS 500 C3) and proof of purchase ready when contacting support.



© 2023 Silvercrest. All rights reserved.

Related Documents

	SILVERCREST MJÖLKSUMMARE SMSP 500 A1 Bruksanvisning Denna bruksanvisning ger omfattande vägledning för SILVERCREST MJÖLKSUMMARE SMSP 500 A1, inklusive säker användning, drift, rengöring och felsökning för att uppnå perfekt mjölkskum och varm mjölk.
	SilverCrest SMSP 500 A1 Tejhabosító Kezelési útmutató Kezelési útmutató a SilverCrest SMSP 500 A1 Tejhabosítóhoz. Tudja meg, hogyan működtetheti, tisztíthatja és karbantarthatja tejhabosítóját a tökéletes tejhab és meleg tej elkészítéséhez.
	SILVERCREST SMSP 500 A1 Milk Frother User Manual Comprehensive user manual for the SILVERCREST SMSP 500 A1 Milk Frother, detailing its features, operation, safety precautions, cleaning, troubleshooting, and warranty information. Learn how to safely and effectively use your milk frother for perfect frothed milk.

	SilverCrest SMAS 500 D1 Mælkeskummer Brugsanvisning Komplet brugsanvisning til SilverCrest SMAS 500 D1 mælkeskummer. Lær om sikker brug, funktioner, vedligeholdelse og fejlfinding for din mælkeskummer.
---	---

Documents - Silvercrest – SMAS 500 C3

[\[pdf\]](#) User Manual Instructions Specifications

MILK FROTHER MLAP GmbH SMAS 500 C3 The user manual is an integral part of this product It contains important safety information and instructions for use disposal Before using the please familiarise yourself with all operating Only as described specified applications Keep in a safe place 9be41743 b516 4830 b879 8674f9af4617 stesbintegrationprod blob core windows net public articlemanual RK 2 RS 6dpEC0E5 OMdEOdmsFhwgxxz Lg |||

MILK FROTHER **SMAS 500 C3** GB IE NI MILK FROTHER Operating instructions GR CY DE AT CH MILCHAUFSCHUMER Bedienungsanleitung IAN 384725_2107 IE NI GB CY GB IE NI Before reading, unfold the page containing the illustrations and familiarise yourself with all functions of the device. GR CY ...

lang:en **score:33** filesize: 620.03 K page_count: 34 document date: 2022-02-02

