Osprey Daylite Commuter Backpack

Osprey Daylite Commuter Backpack Instruction Manual

Model: Daylite Commuter Backpack

Brand: Osprey

Introduction Setup Operating Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

The Osprey Daylite Commuter Backpack is a lightweight and versatile bag designed for everyday use, travel, and light outdoor activities. It features a laptop sleeve, bottle pockets, and a comfortable design for extended wear.

Key Features:

- Compatible as an attachment to several Osprey travel and backpacking bags for additional storage and carry options.
- Large panel-loading main compartment for easy access to contents.
- Multifunctional interior sleeve suitable for a hydration reservoir or most tablets/laptops up to 14 inches.
- Dual side compression straps to stabilize loads.
- Dual water bottle side mesh pockets for convenient hydration access.

2. Setup

2.1 Adjusting Shoulder Straps

To ensure a comfortable fit, adjust the shoulder straps to distribute the weight evenly across your shoulders. Loosen or tighten the straps using the buckles located at the bottom of each strap.

2.2 Utilizing the Laptop/Tablet Sleeve

The interior sleeve is designed to securely hold most tablets or laptops up to 14 inches. Carefully slide your device into the padded sleeve located within the main compartment.



Image: A hand sliding a silver laptop into the dedicated padded sleeve inside the backpack's main compartment.

2.3 Hydration Reservoir Setup

If using a hydration reservoir (not included), place it in the multifunctional interior sleeve. Route the drinking tube through the designated port at the top of the pack and secure it to a shoulder strap using the integrated loops.

3. Operating the Backpack

3.1 Main Compartment Access

The main compartment features a large panel-loading design, allowing for wide access to your belongings. Use the smooth-gliding zippers to open and close the compartment.

3.2 External Pockets

- **Dual Water Bottle Side Mesh Pockets:** These stretchy mesh pockets are ideal for holding water bottles or other

quick-access items.

- **Front Panel Pocket:** A zippered front panel pocket provides secure storage for smaller items like keys, wallet, or phone.



Image: A hand placing a water bottle into one of the stretchy mesh side pockets of the backpack.

3.3 Luggage Pass-Through

For convenient travel, the backpack includes a luggage pass-through sleeve on the back panel. This allows you to slide the backpack over the handle of your rolling luggage, securing it for easier transport through airports or train stations.




OSPREY
DAYLITE

Image: The backpack is shown attached to the extended handle of a rolling suitcase, demonstrating the luggage pass-through feature.

3.4 Dual Side Compression Straps

Use the dual side compression straps to stabilize your load and reduce bulk when the pack is not full. Tighten these straps to keep contents secure and close to your back.

3.5 Back Panel Ventilation

The AirScape back panel is designed to provide ventilation and comfort, preventing excessive sweating during active use. The mesh-covered foam ridges allow air to flow freely.





Image: A detailed view of the backpack's back panel, highlighting the AirScape design with its mesh covering and foam ridges for enhanced airflow.

3.6 Video Overview

Watch this official video from Osprey Packs for a detailed overview and comparison of the Daylite and Daylite Plus models, showcasing various features and usage scenarios.

Video: An official overview of the Osprey Daylite and Daylite Plus backpacks, detailing their features, compartments, and how they can be used for various activities.

4. Maintenance

4.1 Cleaning Instructions

The backpack is made of durable polyester. For general cleaning, wipe the fabric with a damp cloth and mild soap. Avoid harsh detergents or bleach. Air dry thoroughly away from direct sunlight.

4.2 Zipper Care

Keep zippers clean and free of debris. If zippers become stiff, apply a small amount of zipper lubricant or wax to ensure smooth operation.

5. Troubleshooting

5.1 Loose Straps

If straps loosen during use, ensure they are properly threaded through their buckles. Re-adjust as needed for a snug fit.

5.2 Wet Contents

While the backpack material is water-resistant, it is not fully waterproof. For heavy rain, consider using a rain cover (sold separately) or waterproof dry bags for sensitive items.

6. Specifications

Feature	Detail
Brand	Osprey

Model Name	Daylite
Item Dimensions (D x W x H)	7.9"D x 10.2"W x 16.9"H
Item Weight	1.09 Pounds
Material Type	Polyester
Storage Volume	13 Liters
Number Of Pockets	6
Water Resistance Level	Water Resistant
Compatible Device Size Maximum	14 Inches (Laptop/Tablet)

7. Warranty & Support

7.1 Osprey All Mighty Guarantee

Osprey is committed to ensuring their products withstand the test of time. If your product experiences damage such as a torn piece of fabric, worn-out buckle, or broken zipper, Osprey will repair or replace it at no cost. For more details, visit osprey.com/guarantee.

7.2 Customer Support

For any questions, concerns, or support needs not covered in this manual, please contact Osprey customer service through their official website or the retailer where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question