T4TREAM FPSC6DRSC-NO

T4TREAM Fluted 6 Drawers Dresser Instruction Manual

Brand: T4TREAM

Model: FPSC6DRSC-NO

Introduction

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your T4TREAM Fluted 6 Drawers Dresser. Designed with timeless elegance and modern chic, this dresser features a distinctive wave-like fluted panel, a faux marble top, and ample storage. Please read this manual thoroughly before beginning assembly or use to ensure proper setup and longevity of your furniture.

Product Features

- **Timeless Elegance Meets Modern Chic:** Features a distinctive wave-like fluted panel, off-white faux marble top with earth-toned veins, and smooth curved edges. Wide metal handles and splayed legs add a contemporary vibe.
- **Versatile, Stylish Dresser:** Measuring 54"W × 15.75"D × 32"H, it offers a spacious tabletop for display and 6 smooth-glide drawers for efficient storage of clothing, bedding, cosmetics, and jewelry. Suitable for bedroom, living room, hallway, or entryway.
- **Stable, Durable and Textured:** Constructed from FSC-Certified wood, optimal MDF, and P2 engineered wood. The fluted panel uses blister molding technology, and the faux marble top is a melamine veneer, ensuring durability, water resistance, and easy maintenance. Stability is reinforced by a steel support at the base.
- **Effortless Assembly:** Comes with clear, user-friendly instructions and meticulously labeled components. A pack of spare parts is included. Typically, two adults can easily assemble it.
- **Secure Packaging:** Your package is protected with Styrofoam sheets and protective boards to prevent damage during shipping.

Setup and Assembly

The T4TREAM dresser is designed for straightforward assembly. All necessary parts are labeled, and detailed instructions are provided in the included manual. It is recommended that two adults perform the assembly.

Assembly Overview

Begin by unpacking all components and verifying against the parts list. Follow the step-by-step instructions carefully. Ensure all screws and fasteners are securely tightened for stability.




Figure 1: Product dimensions and internal drawer measurements. Note the included feet metal plates for tipping prevention.

Assembly Tips

- Organize all parts before starting. Each component is meticulously labeled.
- Use the provided spare parts if any hardware is lost during assembly.
- Ensure the steel support at the base is correctly installed for enhanced stability.
- Consider using an electric drill for pre-drilled holes, as some may be shallow.
- Install the anti-tipping hardware (wall fastening and front feel metal plates) as directed to prevent accidental tipping, especially in households with children or pets.

Operating Instructions

Your T4TREAM dresser is designed for ease of use and efficient organization.

Drawer Usage

The dresser features 6 smooth-glide drawers. To open, gently pull the metal handle. To close, push the drawer back until it is fully seated. Avoid forcing drawers if they feel stiff; ensure they are properly aligned on their tracks.



Figure 2: The spacious drawers can store 20-25 T-shirts or 15-20 pairs of jeans. The faux marble top provides a durable and stylish surface.

Top Surface Use

The faux marble top is ideal for displaying decorative items, framed photos, or serving as a TV stand. Its melamine veneer surface

is water-resistant and easy to clean.



Figure 3: The dresser seamlessly integrates into various room settings, offering both aesthetic appeal and practical storage.

Maintenance

To maintain the appearance and longevity of your T4TREAM dresser, follow these simple care instructions:

- **Cleaning:** Wipe with a dry cloth. For spills on the faux marble top, wipe immediately with a damp cloth and then dry thoroughly. Avoid abrasive cleaners or harsh chemicals.
- **Protection:** Avoid placing extremely hot or cold items directly on the faux marble top without protective coasters.
- **Inspection:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary.

Troubleshooting

If you encounter any issues with your T4TREAM dresser, please refer to the following common solutions:

- **Drawers not sliding smoothly:** Ensure the drawer slides are properly aligned and free of obstructions. Check that all screws on the slides are tightened.
- **Wobbly dresser:** Verify that all assembly screws are securely tightened. Ensure the steel support at the base is correctly installed and making firm contact with the floor. If applicable, ensure anti-tipping hardware is properly anchored.
- **Missing or damaged parts:** Refer to the "Buy with Confidence" section in the features. Contact T4TREAM customer support immediately for assistance.

Specifications

Attribute	Value
Brand	T4TREAM
Product Dimensions	16"D x 54"W x 32"H
Color	Natural Oak
Mounting Type	Floor Mount
Room Type	Bedroom, Living Room, Hallway, Entryway, Home Office
Special Feature	Fluted Panel Design, Faux Marble Top, Curved Profile, Blister Molding Surface, 6-Drawers Storage, Wood Splayed Legs, 54" Wide
Furniture Finish	Oak
Product Care Instructions	Wipe with Dry Cloth
Assembly Required	Yes
Model Name	FPSC6DRSC-NO
Item Weight	140 Pounds
Number of Pieces	1
Manufacturer	T4TREAM
ASIN	B0CN2LPS56
Date First Available	November 10, 2023

Warranty and Support

T4TREAM is committed to providing high-quality products and customer satisfaction.

- **Return Policy:** This product is eligible for a refund/replacement within 30 days of purchase. Please refer to your purchase platform's return policy for detailed instructions.
- **Customer Support:** For any queries, concerns, or assistance with your product, please feel free to reach out to T4TREAM customer support. Contact information can typically be found on your purchase receipt or the seller's page on the platform where you bought the product.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question