

[Manuals.plus](#) /

› [FOHERE](#) /

› FOHERE Electric Burr Coffee Grinder Instruction Manual

FOHERE Electric Burr Coffee Grinder

FOHERE Electric Burr Coffee Grinder Instruction Manual

Model: Electric Burr Coffee Grinder

INTRODUCTION

Thank you for choosing the FOHERE Electric Burr Coffee Grinder. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new coffee grinder. Please read all instructions carefully before use and retain this manual for future reference.

PRODUCT OVERVIEW

The FOHERE Electric Burr Coffee Grinder is designed to provide consistent and precise grinding for various coffee brewing methods. It features an anti-static conical burr system and 35 precise grind settings.

Key Components



Image: Exploded view of the FOHERE Electric Burr Coffee Grinder, showing the bean hopper lid, stainless steel conical burrs, ON/OFF button, cup selection dial, grinding chamber lid, grinding chamber, motor housing, cleaning brush, and portafilter cradle.

- **Bean Hopper:** Holds whole coffee beans.
- **Conical Burrs:** Precision grinding mechanism for consistent particle size.
- **Grind Setting Dial:** Adjusts the fineness of the grind (1-35).
- **Cup Selection Dial:** Sets the desired quantity of ground coffee (2-12 cups).
- **Grinding Chamber:** Collects ground coffee.
- **Portafilter Cradle:** Allows direct grinding into a 54mm portafilter.

- **Cleaning Brush:** For maintaining the burrs and powder outlet.

Features

Consistent Grind

Conical burr create uniform grinds for better flavor



Image: Close-up view of the conical burrs and coffee beans, highlighting the consistent grind produced by the grinder.

- **Consistent Grind:** Conical burrs ensure uniform grinds, preserving coffee flavor.
- **35 Precise Grind Settings:** Offers a wide range from fine (espresso) to coarse (French press, cold brew).
- **Anti-static Design:** Minimizes static cling of coffee grounds for a cleaner experience.
- **Adjustable Quantity:** Grind from 2 to 12 cups of coffee.

- **Portafilter Compatibility:** Equipped with a 54mm portafilter cradle for direct grinding.

SETUP

Before first use, ensure all packaging materials are removed and the unit is clean. Place the grinder on a stable, dry, and level surface.

1. **Assemble the Bean Hopper:** Place the bean hopper onto the top of the grinder. Align the arrows on the hopper and the grinder base, then press down and rotate clockwise until it locks into place.
2. **Insert Grinding Chamber or Portafilter Cradle:**
 - For collecting ground coffee in the chamber: Slide the grinding chamber into the designated slot at the front of the grinder.
 - For direct grinding into a portafilter: Insert the portafilter cradle into the slot.
3. **Fill the Bean Hopper:** Add whole coffee beans to the bean hopper. Do not overfill beyond the MAX line.

Video: Demonstrates how to install the coffee grinder components, including the bean hopper and grinding chamber/portafilter cradle.

OPERATING INSTRUCTIONS

Follow these steps to grind your coffee beans:

1. **Select Grind Setting:** Rotate the grind setting dial to choose your desired fineness. Settings 1-15 are suitable for Espresso, 16-25 for Drip/Pour Over, and 26-35 for French Press.
2. **Select Quantity:** Rotate the cup selection dial to choose the number of cups you wish to grind (2-12 cups).
3. **Start Grinding:** Press the ON/OFF button to start the grinding process. The grinder will automatically stop once the selected quantity is reached.
4. **For Portafilter Use:** If using the portafilter cradle, place your 54mm portafilter securely in the cradle. Press the ON/OFF button to start grinding. You may need to manually stop the grinder once the desired amount is achieved in the portafilter. After grinding, tamp the coffee powder as needed.

Video: Shows the general operation of the coffee grinder, including selecting grind settings and quantity.

Video: Demonstrates the operation of the coffee grinder specifically for filling an espresso machine portafilter.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your grinder.

1. **Unplug the Grinder:** Always unplug the appliance from the power outlet before cleaning.
2. **Remove Bean Hopper:** Rotate the bean hopper counter-clockwise and lift it off. Pour out any remaining whole beans.
3. **Remove Upper Burr:** Use the provided cleaning brush to carefully remove the upper burr by twisting and lifting.
4. **Clean Burrs and Grinding Chamber:** Use the cleaning brush to remove any residual coffee grounds from both the upper and lower burrs, as well as the grinding chamber and powder outlet.

5. **Clean Grinding Chamber/Portafilter Cradle:** Remove the grinding chamber or portafilter cradle and wash with warm, soapy water. Rinse thoroughly and dry completely before reassembling.
6. **Wipe Exterior:** Wipe the exterior of the grinder with a damp cloth. Do not immerse the main unit in water.
7. **Reassemble:** Once all parts are dry, reassemble the grinder in reverse order of disassembly.



Image: A hand using the provided cleaning brush to clean the removable upper burr of the coffee grinder.

Video: Illustrates the process of cleaning the coffee grinder, including removing the bean hopper and burrs, and using the cleaning brush.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Grinder does not start.	Not plugged in; bean hopper not correctly installed; power outage.	Ensure power cord is securely plugged in. Check if bean hopper is locked in place. Verify power supply.
Coffee grounds are inconsistent.	Burrs are dirty or worn; incorrect grind setting.	Clean the burrs thoroughly. Adjust to a finer or coarser grind setting as needed.
Grinder clogs frequently.	Excessive fine grounds buildup; grinding oily beans; powder outlet blocked.	Clean the burrs and powder outlet regularly with the provided brush. Use a slightly coarser grind setting if using very oily beans.
Static cling of coffee grounds.	Environmental factors; very dry beans.	The grinder has anti-static features, but some static may occur. Lightly misting beans with water before grinding can help reduce static.

SPECIFICATIONS

- **Brand:** FOHERE
- **Model:** Electric Burr Coffee Grinder
- **Color:** Black
- **Material:** Plastic, Stainless Steel
- **Item Weight:** 3.3 Pounds
- **Item Dimensions (L x W x H):** 7.87"L x 5.9"W x 3.93"H
- **Capacity:** Up to 12 Cups
- **Grind Settings:** 35 Precise Settings
- **Included Components:** Electric coffee grinder, cleaning brushes, portafilter cradle.

WARRANTY AND SUPPORT

FOHERE products are manufactured with quality and performance in mind. For any questions, concerns, or support needs regarding your Electric Burr Coffee Grinder, please refer to the contact information provided with your purchase or visit the official FOHERE website. Please retain your proof of purchase for warranty claims.