Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SoBuy BZR122-W

SoBuy Bathroom Cabinet with Laundry Basket - Model BZR122-W Instruction Manual

Comprehensive guide for assembly, operation, and maintenance.

Introduction

Thank you for choosing the SoBuy Bathroom Cabinet with Laundry Basket, Model BZR122-W. This compact and stylish cabinet is designed to maximize space in smaller bathrooms, offering both storage and a convenient laundry solution. Please read this manual carefully before assembly and use to ensure proper installation and longevity of your product.



Image 1: The SoBuy BZR122-W Bathroom Cabinet with Laundry Basket in a typical bathroom environment, showcasing its compact design and functionality.

Safety Information

Important: To ensure the stability of the cabinet and prevent it from tipping over, especially in areas with children or pets, it is highly recommended to use the provided anti-tip device. Always follow the installation instructions for the anti-tip mechanism.

Components Included

- Laundry basket
- Accessory bag (containing hardware)
- User manual (this document)
- Cabinet panels and shelves

- Anti-tip device

Specifications

Feature	Detail
Brand	SoBuy
Model Number	BZR122-W
Color	White
Material	Engineered Wood (MDF)
Product Dimensions (D x W x H)	30 x 30 x 90 cm (11.8 x 11.8 x 35.4 inches)
Item Weight	9.2 kg (20.3 lbs)
Maximum Weight Capacity	15 kg (33 lbs)
Number of Shelves	2
Assembly Required	Yes



Image 2: Technical diagram showing the precise dimensions of the cabinet in centimeters.

Setup and Assembly

The SoBuy BZR122-W cabinet requires assembly. A detailed assembly instruction manual is included in the packaging. Please follow the step-by-step diagrams and instructions carefully. Ensure all components are present before beginning assembly.

Anti-Tip Device Installation

For safety, install the anti-tip device as instructed. This device secures the cabinet to the wall, preventing accidental tipping. Locate the designated attachment points on the cabinet and wall, and use the provided hardware to secure it firmly.




Image 3: Diagram showing how to install the anti-tip device to secure the cabinet to the wall.

Operation

Laundry Basket Usage

The cabinet features a tilting front panel that reveals a removable fabric laundry basket. To use, gently pull the top of the front panel outwards. The basket can be easily lifted out using its handles for convenient transport of laundry to your washing machine.

Your browser does not support the video tag.

Video 1: Demonstration of the tilting laundry basket feature and how to remove the fabric basket for easy laundry transport.



Image 4: The tilting front panel of the cabinet opened, revealing the fabric laundry basket inside.

Storage Shelves

The top section of the cabinet includes an open compartment, ideal for storing frequently used items, decorative pieces, or additional bathroom essentials. The interior shelves provide further storage for towels, toiletries, or cleaning supplies.



Image 5: The open top shelf of the cabinet, displaying various bathroom accessories.

Care and Maintenance

To maintain the appearance and longevity of your SoBuy cabinet, clean it regularly with a dry, soft cloth. Avoid using abrasive cleaners or harsh chemicals, as these may damage the finish. For spills, wipe immediately with a damp cloth and then dry thoroughly.

Troubleshooting

No specific troubleshooting steps are provided for this product. If you encounter any issues during assembly or use that are not covered in this manual, please refer to the contact information in the "Warranty and Support" section.

Warranty and Support

SoBuy products are designed for quality and durability. If you are not satisfied with your product or encounter any problems, please do not hesitate to contact us. We are committed to addressing your needs and questions. You may be eligible for a return label if the product does not meet your expectations or has issues.
For assistance, please contact SoBuy customer service. Contact details can typically be found on the packaging or on the official SoBuy website.

© 2024 SoBuy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CN31QHT6

More documents and user manuals: **https://manuals.plus/**