

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [YESHOMY](#) /

› [YESHOMY Farmhouse Modern Nightstand Assembly and User Manual \(Model YH-NSD0141-KL\)](#)

YESHOMY YH-NSD0141-KL

YESHOMY Farmhouse Modern Nightstand Assembly and User Manual

Model: YH-NSD0141-KL

INTRODUCTION

Thank you for choosing the YESHOMY Farmhouse Modern Nightstand. This manual provides detailed instructions for the assembly, operation, and maintenance of your new furniture. Please read this guide thoroughly before beginning assembly and retain it for future reference.



Image: The YESHOMY Farmhouse Modern Nightstand, showcasing its design and potential use.

SAFETY INFORMATION

Please observe the following safety precautions during assembly and use:

- **Pinch Points:** Exercise caution during assembly to avoid potential pinch points, especially when handling moving parts or aligning panels.
- **Weight Limits:** Do not exceed the maximum weight recommendation of 80 pounds for the nightstand. Overloading can compromise stability and cause damage or injury.
- **Stable Setup:** Ensure the nightstand is placed on a flat, stable surface to prevent tipping. If necessary, use wall anchor kits (not included) for added stability, especially in households with children or pets.
- **Assembly:** While assembly can be performed by one person, two people are recommended for easier and safer handling of components.
- **Small Parts:** Keep all small parts and hardware out of reach of children during assembly to prevent choking hazards.

PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Nightstand components (wood panels, metal hardware)
- Assembly Guide
- Installation Tool (e.g., Allen wrench)

Note: A screwdriver is recommended for assembly but not included.

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is designed to be straightforward. Follow the steps outlined in the included Assembly Guide. Two people are recommended for optimal ease and safety during the process.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Refer to the parts list in your Assembly Guide to identify each component. Ensure all numbered stickers are noted for correct orientation, and remove them carefully after assembly if they are in visible areas.
3. **Assemble Frame:** Begin by connecting the main frame components using the provided hardware and installation tool. Pay close attention to the orientation of panels as indicated in the guide.
4. **Install Shelves:** Secure the internal shelf according to the instructions.
5. **Attach Barn Door:** The barn door can be installed to open from either the left or the right side, depending on your preference. Refer to the diagram below for visual guidance.

2 Setup Options

Install the cabinet door on the left or right

Option 1

Door on the left



Option 2

Door on the right



Image: Two setup options for the barn door, allowing for left or right side opening.

- Final Tightening:** Once all components are in place, gently tighten all screws and connectors to ensure the nightstand is sturdy and stable. Avoid over-tightening.

OPERATING INSTRUCTIONS (USAGE)

The YESHOMY Farmhouse Modern Nightstand is designed for versatile use in bedrooms, living rooms, or home offices.

- **Top Surface:** Use the top surface for lamps, alarm clocks, beverages, or decorative items. Ensure items are placed centrally to maintain balance.
- **Open Shelf:** The open shelf provides easy access storage for books, magazines, or small electronic devices.

- **Barn Door Cabinet:** The enclosed cabinet with a barn door offers discreet storage for personal items, keeping your space tidy.
- **Cable Management:** A lineal orifice (cable hole) is provided on the back panel for convenient routing of power cords for electronic devices placed on the shelf or top surface.



End Table for Living Room



Side Table for Home Office

Image: The nightstand demonstrating its multiple storage options, including an open shelf and a closed cabinet.

MAINTENANCE

To ensure the longevity and appearance of your nightstand, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the surfaces with a dry, soft cloth. Avoid abrasive cleaners or harsh chemicals, which can damage the finish.

- **Spills:** Promptly wipe up any spills to prevent staining, especially on the wooden top surface.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the wood and finish.
- **Humidity:** Maintain a stable humidity level in the room to prevent warping or cracking of the wood.
- **Hardware Check:** Periodically check all screws and fittings to ensure they remain tight. Re-tighten if necessary, but do not over-tighten.

TROUBLESHOOTING

If you encounter any issues during assembly or use, refer to the following common solutions:

- **Difficulty with Assembly / Parts Not Fitting:**
 - Ensure you are using the correct parts for each step as indicated in the Assembly Guide.
 - Verify that all components are oriented correctly. Sometimes a panel may appear similar on all sides but has specific drill holes or cam lock placements.
 - Do not force parts together. If a part does not fit, re-check the instructions and the part's orientation.
- **Nightstand is Unstable/Wobbly:**
 - Ensure all screws, cam locks, and dowel pins are fully tightened. Loose connections are a common cause of instability.
 - Verify that the nightstand is placed on a level surface. Adjust furniture glides or use shims if the floor is uneven.
 - Check if any plastic angle brackets (if included) are properly installed and tightened, as these contribute to structural integrity.
- **Cam Bolts Not Tightening:**
 - Ensure the dowel pins are inserted correctly and fully into their respective holes before attempting to engage the cam bolt.
 - The cam bolt head should be aligned with the dowel pin. Turn the cam bolt clockwise a quarter turn to lock it. If it spins freely, the dowel pin may not be properly seated or aligned.
 - Avoid over-tightening, as this can strip the cam lock or damage the wood.
- **Missing or Damaged Parts:**
 - Carefully re-check all packaging materials to ensure no small parts were overlooked.
 - Contact YESHOMY customer support with your model number (YH-NSD0141-KL) and a description of the missing or damaged part for assistance.

SPECIFICATIONS

Detailed product specifications for the YESHOMY Farmhouse Modern Nightstand:

Brand	YESHOMY
Model Name	Farmhouse Modern Nightstand
Model Number	YH-NSD0141-KL

Color	White (with rustic brown top)
Material	Wood, Metal
Product Dimensions (D x W x H)	13.7" x 15.7" x 23.6" (34.8 cm x 39.9 cm x 59.9 cm)
Item Weight	Approximately 45 Pounds (20.4 kg)
Maximum Weight Recommendation	80 Pounds (36.3 kg)
Number of Items	1 (per unit, sold as set of 2)
Included Components	Assembly Guide, Installation Tool
Recommended People for Assembly	2
Recommended Tools for Assembly	Screw Driver (not included)
Product Care Instructions	Wipe with Dry Cloth
UPC	774816288944



Image: Detailed dimensions of the nightstand, including external and internal measurements.

WARRANTY AND SUPPORT

For warranty information, product support, or to order replacement parts, please contact YESHOMY customer service directly. Refer to the contact information provided with your purchase or visit the official YESHOMY website.

Please have your model number (YH-NSD0141-KL) and purchase details ready when contacting support.

