

[Manuals.plus](#) /

› [tectake](#) /

› tectake WoofRider Dog Trailer and Jogger Instruction Manual

tectake 404945

tectake WoofRider Dog Trailer and Jogger Instruction Manual

Model: 404945

INTRODUCTION

The tectake WoofRider is a versatile pet carrier designed for active lifestyles, allowing you to bring your dog along on bicycle rides or jogs. It easily converts between a bicycle trailer and a jogger/stroller. Key features include a foldable drawbar, quick-release front wheel, and an attachable push handle for seamless transitions. The design prioritizes your pet's comfort and safety with breathable mesh inserts for optimal ventilation and a non-slip bottom. Enhanced visibility is provided by reflective strips, reflectors, and a warning flag, ensuring safety during all your adventures.



tectake
pets



Facilmente convertibile
da rimorchio per bici
a carrozzina



Portata fino a 40 kg
ideale per cani di taglia
piccola e media



Grandi inserti in rete
per una visuale e un
ricambio d'aria ottimali



Ampia maniglia
con morbida imbottitura,
regolabile in altezza



Ruote gonfiabili
con profilo robusto per il
massimo comfort



Pratico aggancio
compatibile con i modelli
più comuni, E-Bike incluse

Image: The tectake WoofRider in jogger mode, providing a comfortable ride for your pet.

SAFETY INFORMATION

- Always ensure your pet is securely fastened inside the trailer using the integrated safety harness.
- Regularly check tire pressure and ensure all connections (to bicycle, wheels, handle) are secure before each use.
- Do not exceed the maximum recommended weight capacity of 40 kg.
- Ensure the warning flag is always attached when using as a bicycle trailer for increased visibility.
- Be aware of your surroundings and adjust your speed according to terrain and traffic conditions.
- Never leave your pet unattended in the trailer, especially on inclines or uneven surfaces.

WHAT'S IN THE BOX

Your tectake WoofRider package includes the following components:

- Dog Trailer main unit

- Safety harness
- Removable warning flag
- Assembly materials
- Assembly instructions

SETUP

Follow these steps to assemble your tectake WoofRider:

1. **Unfold the Frame:** Carefully unfold the main frame of the trailer until it locks into place.
2. **Attach Rear Wheels:** Insert the rear wheels into their respective axles until they click securely.
3. **Install Drawbar/Handle:** Depending on your intended use, attach either the bicycle drawbar or the push handle. The drawbar folds for compact storage.
4. **Attach Front Wheel (Jogger Mode):** For jogger mode, attach the quick-release front wheel to the designated slot.
5. **Secure Safety Flag:** Insert the warning flag into its mounting point for visibility.

PRATICITÀ e design

Grazie al meccanismo pieghevole, questo pratico rimorchio si richiude in un attimo per occupare il minimo spazio durante lo stoccaggio.




GRANDE **sicurezza**

Gli inserti riflettenti, gli 8 catarifrangenti e la banderuola garantiscono la massima visibilità durante la circolazione su strada.



Image: The trailer's folding mechanism and conversion to jogger mode.

TUTTI in gita



tectake
pets

Questo versatile trasportino per cani ti offre la possibilità di mantenere uno stile di vita attivo assieme al tuo amico a quattro zampe. La maniglia è imbottita e regolabile in altezza, mentre le 3 ruote ad alto profilo garantiscono una guida piacevole per lunghe e piacevoli passeggiate.

Image: Detail of the quick-release front wheel attachment for jogger configuration.

OPERATING INSTRUCTIONS

Using as a Bicycle Trailer

- Ensure the front wheel is removed and the bicycle drawbar is securely attached to your bicycle's rear axle.
- Place your dog inside the trailer and secure them with the internal safety harness.
- Close all openings securely, ensuring proper ventilation through the mesh inserts.
- Attach the warning flag for maximum visibility to other road users.
- Always ride cautiously, especially when turning or on uneven terrain.

PERFETTO PER
tutte le occasioni



Ammortizzatori
per il comfort



Grande tasca
per snack e oggetti


Image: The tectake WoofRider in use as a bicycle trailer.

Using as a Jogger/Stroller

- Ensure the bicycle drawbar is folded or removed, and the push handle and front wheel are securely attached.
- Place your dog inside and secure them with the safety harness.
- Adjust the height of the push handle for comfortable operation.
- The breathable mesh inserts provide optimal air circulation, and the non-slip bottom ensures stability for your pet.
- The transparent plastic covers on the front and rear can be used to protect against rain.



La **banderuola riflettente a incastro** migliora la visibilità in caso di maltempo.



Gli **8 catarifrangenti sui 4 lati** rendono questo trasportino riconoscibile anche al buio.



La **cinghia di sicurezza integrata** garantisce che il tuo cane si goda in tranquillità ogni viaggio.



Le **coperture trasparenti in plastica** sul davanti e sul retro impediscono alla pioggia di entrare.

Image: Safety features including the warning flag, reflectors, and internal leash.

COMODI, AL SICURO
e contenti



Image: The WoofRider ready for outdoor adventures.

MAINTENANCE

- **Cleaning:** Clean the fabric parts with a damp cloth and mild soap. Do not use harsh chemicals. The mesh inserts can be gently wiped.
- **Tires:** Maintain proper tire pressure as indicated on the tire sidewalls. Inspect tires regularly for wear and tear.
- **Frame:** Wipe the steel frame with a damp cloth to remove dirt. Check for any signs of rust or damage.
- **Storage:** When not in use, fold the trailer for compact storage in a dry, protected area to prevent damage from weather elements.
- **Fasteners:** Periodically check all screws, bolts, and quick-release mechanisms to ensure they are tight and secure.

TROUBLESHOOTING

- **Trailer feels unstable:** Ensure all wheels are properly attached and inflated to the correct pressure. Verify that

the frame is fully extended and locked.

- **Difficulty maneuvering:** Check that the front wheel (in jogger mode) is freely rotating. Ensure the handle is adjusted to a comfortable height. For bicycle mode, confirm the hitch is correctly installed and secured to the bike.
- **Pet discomfort:** Ensure the internal safety harness is not too tight or loose. Check for any obstructions inside the trailer. Provide adequate ventilation.
- **Folding mechanism is stiff:** Apply a small amount of silicone spray to the joints if they become stiff. Ensure no debris is obstructing the mechanism.

SPECIFICATIONS

tectake
pets

Dettagli prodotto

MISURE

Misure totali rimorchio
141 x 78,5 x 89 cm
Misure totali carrozzina
124 x 78,5 x 103 cm
Misure da chiuso senza ruote
74,5 x 83 x 25 cm
Maniglia 56 x 3 cm
Tasca esterna 23 x 16 cm
Lunghezza timone 60 cm
Ruote posteriori 16"
Ruota anteriore 10"
Aggancio 10 mm

DATI TECNICI

Capacità di carico 40 kg
Volume 240 l
Peso ca. 13,5 kg
Materiali acciaio verniciato, Nylon, gomma, cloruro di polivinile, 100% poliestere

Tutte le misure sono indicative

CONTENUTO

Rimorchio per cani
Cinghia di sicurezza
Banderuola
Materiale di montaggio
Istruzioni di montaggio

83 cm

74,5 cm

25 cm

124 cm

56 cm

89 cm

78,5 cm

103 cm

50 cm

41 cm

89 cm

146 cm

78,5 cm

141 cm

Image: Product dimensions and technical data.

Feature	Detail
Brand	tectake

Feature	Detail
Model Number	404945
Color	Beige
Item Weight	13.6 Kilograms
Product Dimensions (Trailer)	141L x 78.5W x 89H cm
Product Dimensions (Stroller)	124L x 78.5W x 103H cm
Folded Dimensions (without wheels)	74.5 x 83 x 24.5 cm
Frame Material	Steel
Fabric Material	Nylon, rubber, polyvinyl chloride, 100% polyester
Maximum Recommended Weight	40 Kilograms
Rear Wheels	16 inches
Front Wheel	10 inches
Hitch	10 mm
Safety Harness Type	3-point

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact tectake customer service directly. Keep your proof of purchase for any warranty claims.

You can typically find contact information on the manufacturer's official website or through the retailer where the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question