Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Fafeicy Fafeicyst81pom2xk

Fafeicy Smart Digital Multimeter User Manual

Model: Fafeicyst81pom2xk

Brand: Fafeicy

Product Overview

This Smart Digital Multimeter is designed for accurate and efficient electrical measurements. It features automatic recognition for various parameters, non-contact voltage testing, and a user-friendly interface, making it suitable for professional electricians, automotive technicians, and DIY enthusiasts.



Image: Front view of the Fafeicy Smart Digital Multimeter, showing the display, function buttons, and input jacks.

Key Features

- **Automatic Recognition:** Simplifies measurements by automatically identifying AC/DC voltage, resistance, and continuity.
- **Non-Contact Voltage (NCV) Testing:** Detects AC voltage without direct contact, enhancing safety.
- **Anti-Burn Protection:** Designed with safety features to prevent damage from incorrect operation.
- **Backlit Display & Flashlight:** Ensures clear readings and visibility in low-light conditions.
- **Data Hold:** Freezes the current reading on the display for easy recording.
- **Auto Power Off:** Conserves battery life by automatically shutting down after a period of inactivity.
- **Low Battery Indicator:** Alerts the user when the battery needs replacement.



Image: Close-up of the multimeter's digital display, showing "Auto" mode and a bright backlight, indicating its readability in various lighting conditions.

Setup

1. Battery Installation

The multimeter is powered by batteries. To install or replace batteries:

1. Locate the battery compartment cover on the back of the device.
2. Use a screwdriver to open the cover.
3. Insert the required batteries, ensuring correct polarity (+/-).
4. Securely close the battery compartment cover.



Image: Rear view of the multimeter, highlighting the integrated flashlight and the general area where the battery compartment is typically located.

2. Initial Power On

Press the power button (usually marked with a power symbol) to turn on the multimeter. The display will illuminate, and the device will typically enter "Auto" mode.

Operating Instructions

Smart Auto Mode

In Smart Auto Mode, the multimeter automatically detects and measures AC/DC voltage, resistance, and continuity without manual range selection. Simply connect the test leads to the circuit or component you wish to measure.

Measuring Voltage (AC/DC)

1. Ensure the multimeter is in Auto mode or select the appropriate voltage function (V~ for AC, V- for DC).

2. Insert the red test lead into the "VΩmA" input jack and the black test lead into the "COM" input jack.
3. Connect the test leads in parallel to the circuit or component you want to measure.
4. Read the voltage value on the display.



Image: Detailed view of the multimeter's input jacks, labeled "COM" and "VΩmA", where test leads are connected for measurements.

Non-Contact Voltage (NCV) Test

The NCV function allows for safe detection of AC voltage without direct contact with wires.

1. Select the NCV function (often marked with NCV or a lightning bolt symbol).
2. Bring the top of the multimeter close to the wire or outlet.
3. If AC voltage is detected, the multimeter will emit an audible beep and the LCD analog bar will display the induction strength.



Image: The multimeter's NCV sensor being used to detect voltage near an electrical outlet, illustrating the non-contact testing capability.

Other Functions

- **Resistance (Ω):** For measuring the electrical resistance of components.
- **Continuity ( ):** For checking if a circuit is complete (audible beep for continuity).
- **Data Hold (HOLD):** Press the HOLD button to freeze the current reading on the display. Press again to release.
- **Flashlight:** Activate the built-in flashlight for illumination in dark work areas.

Maintenance

Cleaning

Wipe the multimeter with a damp cloth. Do not use abrasive cleaners or solvents. Ensure the device is off and disconnected from any power source before cleaning.

Battery Replacement

When the low battery indicator appears on the display, replace the batteries promptly to ensure accurate readings. Refer to the "Battery Installation" section under Setup for instructions.

Storage

Store the multimeter in a cool, dry place away from direct sunlight and extreme temperatures. If storing for extended periods, remove the batteries to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution
Multimeter does not power on.	Dead or incorrectly installed batteries.	Check battery polarity or replace batteries.
Inaccurate readings.	Low battery, incorrect function selected, or poor test lead connection.	Replace batteries, ensure correct function is selected, or check test lead connections.
NCV not detecting voltage.	Voltage is too low, or sensor is not close enough to the source.	Ensure the voltage is within detectable range and bring the sensor closer to the source.

Specifications

Brand: Fafeicy

Model Number: Fafeicyst81pom2xk

Power Source: Battery Powered

Package Dimensions: 6.3 x 4.33 x 1.57 inches

Item Weight: 6.53 ounces

Safety Rating: TRUE RMS 600V CAT III

Display: Digital, 4000 counts

Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Fafeicy brand store on Amazon.

Visit the Fafeicy Store on Amazon

© 2023 Fafeicy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CN3FD7M8

More documents and user manuals: **https://manuals.plus/**