groov e GVSP500

Groov-e Serenity Sleep Aid Machine

Model: GVSP500

Introduction

The Groov-e Serenity Sleep Aid Machine is designed to assist with a restful night's sleep by providing a selection of soothing sounds and a gentle night light. This device features a rechargeable battery for portability and a timer function for customized use.

What's Included

- Groov-e Serenity Sleep Aid Machine
- Charging Cable
- Instruction Guide (this manual)

Product Overview



Figure 1: Top view of the Groov-e Serenity Sleep Aid Machine, showing the control panel with sound selection buttons, volume controls, timer, and light controls.



Figure 2: Side view of the Groov-e Serenity Sleep Aid Machine, illustrating the charging port location.

The Groov-e Serenity features a compact, cylindrical design with a top-mounted control panel. The control panel includes buttons for selecting different soundscapes, adjusting volume, setting a sleep timer, and controlling the integrated LED night light. A charging port is located on the side of the device.

Setup

1. Charging the Device

Before first use, fully charge the Groov-e Serenity. Connect the provided charging cable to the charging port on the side of the device and the other end to a compatible USB power adapter (not included) or a computer USB port. The battery indicator light will show charging status and turn off when fully charged.

2. Initial Placement

Place the device on a stable, flat surface, such as a bedside table, away from direct sunlight or heat sources. Ensure proper ventilation around the unit.

Operating Instructions

1. Power On/Off

- To power on, press and hold the **Power button** (usually indicated by a circle with a vertical line) on the control panel.
- To power off, press and hold the **Power button** again.

2. Sound Selection

The device offers six soothing sounds. Press the dedicated buttons on the control panel to select your desired sound:

- **Rain:** Gentle rainfall sound.
- **Forest:** Sounds of a tranquil forest.
- **Ocean:** Calming ocean waves.
- **Relax:** A soothing, ambient sound.
- **Calm:** A peaceful, serene sound.
- **White Noise:** A consistent, static-like sound.

3. Volume Adjustment

- Press the **'+' button** to increase the volume.
- Press the **'-' button** to decrease the volume.

4. Sleep Timer Function

The timer function allows the device to automatically turn off after a set duration. Press the **Timer button** (usually indicated by a clock icon) repeatedly to cycle through available timer settings (e.g., 15, 30, 60 minutes, or continuous play). The indicator light will confirm the selected timer setting.

5. LED Night Light

The integrated LED light can be used as a gentle night light.

- Press the **Light button** (usually indicated by a sun icon) to turn the night light on or off.
- Some models may allow for brightness adjustment by pressing and holding the Light button or pressing it multiple times. Refer to the specific button icons on your device.

Maintenance

Cleaning

To clean the device, gently wipe the exterior with a soft, dry cloth. Do not use abrasive cleaners, solvents, or immerse the device in water. Ensure the device is powered off and unplugged before cleaning.

Storage

When not in use for extended periods, store the device in a cool, dry place, away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Connect the device to a power source using the charging cable and allow it to charge for at least 30 minutes before attempting to power on again.
No sound or low volume.	Volume is set too low or muted.	Press the **'+' button** to increase the volume. Ensure a sound is selected.
Night light is not working.	Light function is off.	Press the **Light button** to activate the night light.
Device turns off unexpectedly.	Sleep timer is active or battery is low.	Check the timer setting. If the timer is not set, recharge the device.

Specifications

- **Model Name:** Serenity
- **Model Number:** GVSP500
- **Brand:** groov e
- **Color:** White
- **Material:** Plastic
- **Power Source:** Battery Powered (Rechargeable)
- **Item Weight:** 6 ounces
- **Package Dimensions:** 6.69 x 4.06 x 1.61 inches
- **Sounds:** 6 (Rain, Forest, Ocean, Relax, Calm, White Noise)
- **Features:** Sleep Timer, LED Night Light

Warranty and Support

The Groov-e Serenity Sleep Aid Machine comes with a standard manufacturer's warranty. For specific warranty details, please refer to the warranty card included with your purchase or visit the official groov e website. For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact groov e customer service through their official channels.
Please retain your proof of purchase for warranty claims.

© 2024 groov e. All rights reserved.