Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Black Shark Lucifer T10

Black Shark Lucifer T10 Wireless Earbuds

INSTRUCTION MANUAL

Model: Lucifer T10

Introduction

The Black Shark Lucifer T10 Wireless Earbuds are designed for an optimized audio experience, featuring low latency for gaming and dual modes for music and gaming. This manual provides essential information for setting up, operating, and maintaining your earbuds.

What's in the Box

Verify that all items are present in your package:

- Black Shark Lucifer T10 Wireless Earbuds
- USB-C Charging Case
- S/M/L Ear Tips (various sizes for optimal fit)
- USB-C Charging Cable
- User Manual




Image: Contents of the Black Shark Lucifer T10 Earbuds package.

Video: An unboxing demonstration of the Black Shark Lucifer T10 Wireless Earbuds, showing all included components.

Product Overview

The Lucifer T10 earbuds feature an ergonomic design with LED emoji indicators on the charging case. They are equipped with 10mm dynamic drivers for audio output.



Image: Black Shark Lucifer T10 Wireless Earbuds in their charging case.



Image: Detailed view of the earbuds and charging case.

Video: A promotional video showcasing the various color options and LED lighting display of the Black Shark Lucifer T10 Wireless Earbuds.

Setup

Pairing the Earbuds

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode.

3. On your device (smartphone, tablet, laptop), enable Bluetooth.
4. Search for available devices and select "Black Shark Lucifer T10" from the list.
5. Once connected, the earbuds will automatically pair with this device in the future when taken out of the case.




Image: One-step pairing process shown on a smartphone.

Operating Instructions

Touch Controls

The earbuds feature multiple function touch controls:

- **Power On:** Press and hold for 3 seconds.
- **Power Off:** Press and hold for 5 seconds.
- **Play/Pause Music:** Double-tap either earbud.
- **Next Track:** Press and hold the right earbud for 2 seconds.
- **Previous Track:** Press and hold the left earbud for 2 seconds.
- **Volume Up:** Single-tap the right earbud.
- **Volume Down:** Single-tap the left earbud.
- **Answer/End Call:** Double-tap either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.
- **Toggle Gaming Mode:** Triple-tap the right earbud (green indicator).
- **Toggle Music Mode:** Triple-tap the left earbud (white indicator).
- **Toggle Indicators On/Off:** Quadruple-tap either earbud.



Image: Hands-free call and buttonless controls diagram.

Dual Modes (Music and Gaming)

The earbuds offer distinct modes for music and gaming. In gaming mode, they provide an ultra-low latency of 45ms, ensuring audio-video synchronization for an immersive gaming experience. Switch between modes using the touch controls as described above.



Image: Dual-mode design for music and gaming.

Battery Information

The Black Shark Lucifer T10 earbuds offer extended playtime and convenient charging:

- **Earbud Playtime:** Up to 6 hours on a single charge (at 50% volume).
- **Total Playtime with Charging Case:** Up to 24 hours.
- **Charging Case Charging Time:** Approximately 1.5 hours via USB-C.

- **Single Earbud Use:** You can use one earbud while the other is charging in the case.



Image: Battery life details for the earbuds and charging case.

Maintenance and Care

- **Water Resistance:** The earbuds are IPX5 waterproof, meaning they are resistant to sweat and light splashes. Do not submerge them in water.
- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry cloth. Avoid using harsh chemicals.

- **Storage:** Store the earbuds in their charging case when not in use to protect them and keep them charged.
- **Ear Tips:** Use the provided S/M/L ear tips to ensure a secure and comfortable fit, which also helps optimize sound quality.

Troubleshooting

- **No Sound:** Ensure earbuds are charged, paired correctly, and volume is adjusted on both the earbuds and the connected device.
- **Pairing Issues:** Turn off Bluetooth on other nearby devices. Place earbuds back in the case, close, then reopen to re-enter pairing mode.
- **Unstable Connection:** Ensure you are within the 10-meter Bluetooth range and there are no significant obstructions between the earbuds and your device.
- **Charging Problems:** Check the USB-C cable and charging port for any damage. Ensure the charging case has power.

Specifications

Model Name	Lucifer T10
Connectivity Technology	Wireless (Bluetooth 5.1)
Audio Driver Type	Dynamic Driver
Audio Driver Size	10 Millimeters
Audio Latency	45 Milliseconds
Battery Life (Earbuds)	6 Hours
Total Playtime (with Case)	24 Hours
Charging Time (Case)	1.5 Hours
Bluetooth Range	10 Meters
Water Resistance Level	IPX5
Control Type	Multiple Function Touch Control
Included Components	Black Shark Lucifer T10 Wireless Earbuds, Eartip, USB-C Charging Case, User Manual

Warranty and Support

For warranty information and customer support, please refer to the warranty card included in your product package or visit the official Black Shark website. Keep your purchase receipt for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CN7F4XG4

More documents and user manuals: **https://manuals.plus/**