Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BoxWave FineTouch Capacitive Stylus

BoxWave FineTouch Capacitive Stylus User Manual

Model: FineTouch Capacitive Stylus

Introduction

The BoxWave FineTouch Capacitive Stylus is designed for precise interaction with capacitive touchscreens, including smartphones and tablets. It offers a natural writing and drawing experience without the need for Bluetooth pairing or batteries.



Image: The FineTouch Capacitive Stylus in Champagne Gold, shown alongside a compatible Infinix Hot 30 smartphone, highlighting its sleek design and compatibility.

Setup

The FineTouch Capacitive Stylus requires no complex setup. It operates passively, meaning there are no batteries to install or Bluetooth connections to establish. Simply uncap the stylus and it is ready for immediate use.



Image: The FineTouch Capacitive Stylus in use on a tablet, illustrating its precise and responsive interaction with the screen.

Operating Instructions

To use the stylus, gently touch the clear disc tip to your device's screen. The transparent disc allows you to see exactly where your input is registered, enhancing precision for writing, drawing, and tapping.

- **Precision Tip:** The innovative clear disc tip provides enhanced visibility, allowing for accurate placement of strokes and taps.
- **No Pairing Required:** The stylus functions immediately upon contact with any capacitive touchscreen.
- **Clip Design:** Utilize the integrated metal clip to secure the stylus to pockets, notebooks, or device cases for convenient portability.
- **Lightweight Design:** The stylus is designed to be compact and lightweight, fitting comfortably in hand for extended use.



Image: A user holding and operating the FineTouch Capacitive Stylus on a tablet, showcasing its ergonomic design and ease of use for various tasks.

Maintenance

Proper care of your FineTouch Capacitive Stylus will ensure its longevity and performance.

- **Protect the Tip:** Always replace the threaded cap when the stylus is not in use to protect the clear disc tip from dust, dirt, and damage.
- **Cleaning:** If the tip becomes dirty, gently wipe it with a soft, lint-free cloth. Avoid using abrasive materials or harsh chemicals.
- **Storage:** Store the stylus in a clean, dry place away from extreme temperatures.



Image: A detailed view of the FineTouch Capacitive Stylus with its protective threaded cap removed, revealing the clear disc tip, emphasizing the importance of capping for protection.

Troubleshooting

The FineTouch Capacitive Stylus is a passive device and typically requires no troubleshooting. If you experience issues, consider the following:

- **No Response:** Ensure the clear disc tip is clean and free of debris. Gently press the tip against the screen.
- **Inaccurate Input:** Verify that the clear disc tip is fully intact and not damaged. A damaged tip may affect precision.
- **Device Compatibility:** Confirm your device has a capacitive touchscreen. This stylus is not compatible with resistive screens.

Specifications

Feature	Detail

Item Weight	1 ounce
Color	Champagne Gold
Manufacturer	BoxWave
Country of Origin	China
Batteries Required	No
Bluetooth Required	No

Support

For technical assistance or inquiries regarding your BoxWave FineTouch Capacitive Stylus, please contact BoxWave Corporation. Limited third-party technical support for your device (up to 3 inquiries via messaging) is included. Please note that this support is not affiliated with or endorsed by Infinix.
For more information, visit the official BoxWave website or refer to your purchase documentation.

© 2024 BoxWave Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CN84DCZF

More documents and user manuals: **https://manuals.plus/**