

ELENKER HFK-9240B

ELENKER Upright Walker Instruction Manual

Model: HFK-9240B

INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use, assembly, and maintenance of your ELENKER Upright Walker, Model HFK-9240B. Please read all instructions carefully before use to ensure proper operation and to prevent injury.

SETUP

Follow these steps to assemble your ELENKER Upright Walker. No tools are required for assembly.

Step-by-Step Assembly

1. **Unbox Components:** Carefully remove all parts from the packaging and place them on a clean, flat surface.
2. **Open the Main Frame:** Gently unfold the main frame of the walker until it locks into place.
3. **Attach Front Wheels:** Insert the 10-inch front wheels into their designated slots on the front legs of the walker. Ensure they click securely into place.
4. **Install Handle Bars:** Slide the main handle bars into the vertical posts. Adjust to your desired height and secure with the locking pins.
5. **Attach Handgrips:** Secure the handgrips to the top of the handle bars, ensuring the brake cables are correctly routed.
6. **Assemble Sit-to-Stand Handles:** Attach the lower sit-to-stand handles to the main frame, ensuring they are firmly secured.
7. **Attach Storage Bag:** Secure the detachable polyester storage bag to the frame beneath the seat.
8. **Install Backrest:** Attach the backrest to the rear support bars, ensuring it is stable for sitting.
9. **Attach Cane Holder:** Secure the cane holder to the side of the frame.
10. **Install Cup Holder:** Attach the cup holder to the handle bar.
11. **Secure Brake Cables:** Use the provided hook and loop straps to secure any loose brake cables to the frame, preventing entanglement.

Your browser does not support the video tag.

Video: "How to Set-up HFK-9240B Upright Walker" - This video demonstrates the step-by-step assembly process for the ELENKER Upright Walker, including attaching wheels, handles, and accessories.

Your browser does not support the video tag.

Video: "How to assemble 9240" - This video provides a visual guide to assembling the ELENKER Upright Walker, model 9240, covering key components and their installation.

OPERATING INSTRUCTIONS

Walking with the Upright Walker

Position yourself between the padded armrests, ensuring your forearms rest comfortably. Maintain an upright posture, looking forward, not down. Push the walker forward smoothly as you walk.



Image: Padded armrests support the forearms at a natural level, reducing stress on shoulders and back for an upright walking posture.

Using the Dual Braking System

- **To Slow Down:** Gently squeeze the handbrake levers towards the handles.
- **To Lock Wheels (for sitting):** Push the handbrake levers down until they click into the locked position. Ensure both rear wheels are locked before sitting.
- **To Release Brakes:** Pull the handbrake levers up from the locked position.




Image: The dual braking system allows for easy slowing and locking of the rear wheels for safety and stability.

Sitting and Standing

- **To Sit:** Ensure the rear wheels are locked using the handbrakes. Turn around and slowly lower yourself onto the breathable mesh seat. The wide backrest provides support.
- **To Stand:** Use the sit-to-stand handles located on the lower frame to assist in pushing yourself up to a standing position.

Comfortable Seat & Backrest

Allows you to take a break anytime and anywhere

Push handbrake down to lock the rear wheels

Wide Backrest

Breathable Seat

Image: The comfortable seat with a wide backrest and locked rear wheels provides a secure resting spot.



Sit-to-stand Handles

Sit-to-stand Handles

Make stand up from a seated position easier

Image: Sit-to-stand handles are designed to make transitioning from a seated to a standing position easier and safer.

Folding for Storage and Transport

To fold the walker, pull up the strap located on the center of the seat. The walker will collapse into a compact size, suitable for storage or transportation in most car trunks.

Compact Size for Storage and Transportation



Suitable for most car trunks




Image: The walker features a compact folding design, making it easy to store and transport, ideal for travel.

Your browser does not support the video tag.

Video: "Upright Walker Compact Folding Frame" - This video demonstrates how to easily fold the walker for compact storage and transport.

FEATURES

- **Upright Posture Support:** Padded armrests (height 38" - 47") keep forearms at a natural level, reducing strain on shoulders and back, promoting an upright walking position.
- **Enhanced Stability and Security:** Equipped with 10" front wheels that swivel 360° for easy maneuvering on various terrains. Ergonomic dual hand brakes provide reliable stopping power and a sturdy frame ensures overall safety.
- **Convenient Folding Design:** Tool-free assembly and a compact folding size for effortless storage and transport.
- **Comfortable Seating:** Features a wide backrest and a breathable mesh seat for comfortable resting. Rear wheels can be locked for stability when seated.
- **Practical Accessories:** Includes a detachable polyester storage bag for personal items and a cane holder to keep your hands free.



10"
Front

PVC wheels, durable and wear-resistant,
suitable for various terrains

Image: The 10-inch front wheels provide smooth rolling and easy maneuverability indoors and outdoors.



Image: The zippered storage bag offers convenient space for personal belongings, keeping them secure and within reach.



Image: A convenient cup holder ensures beverages are always accessible during use.

MAINTENANCE

- **Regular Cleaning:** Wipe down the frame and padded surfaces with a damp cloth and mild detergent. Avoid abrasive cleaners.
- **Wheel Inspection:** Periodically check the wheels for wear and tear. Ensure they spin freely and are free of debris.
- **Brake Check:** Test the handbrakes regularly to ensure they engage and disengage properly. Adjust if necessary (refer to assembly video for brake cable routing).
- **Fastener Security:** Ensure all screws, bolts, and locking pins are tight and secure before each use.
- **Storage:** Store the walker in a dry, clean place when not in use.

TROUBLESHOOTING

- **Walker does not roll smoothly:** Check wheels for debris or damage. Ensure all wheel fasteners are secure.
- **Brakes are not engaging/disengaging:** Inspect brake cables for kinks or damage. Ensure handbrake levers are properly adjusted and not stuck.
- **Unstable feeling during use:** Verify that all frame components are fully extended and locked. Ensure handle bars are at an appropriate height for your posture.

SPECIFICATIONS

Feature	Detail
Product Dimensions	28 x 25 x 47 inches
Item Weight	24 Pounds
Material Type	Aluminum
Weight Capacity Maximum	300 Pounds
Wheel Size (Front)	10 inches
Armrest Height Range	38" - 47" from ground
Foldable	Yes

Walker Type	Rollator Walker
-------------	-----------------

WARRANTY AND SUPPORT

ELENKER products are 100% tested before leaving the factory to ensure high performance and safety. For any questions or concerns, please contact our customer service. We offer 24-hour friendly email customer service.

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

© 2026 ELENKER. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question