



[Manuals.plus](#) /

> [Heybly](#) /

> Heybly 4-Bag Laundry Hamper with Desktop Sorter Instruction Manual (Model HLH004SG)

## Heybly HLH004SG

# Heybly 4-Bag Laundry Hamper with Desktop Sorter

Model: HLH004SG

Brand: Heybly

## INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Heybly 4-Bag Laundry Hamper with Desktop Sorter. Please read these instructions carefully before assembly and use to ensure proper function and longevity of the product.



Image: The Heybly 4-Bag Laundry Hamper with Desktop Sorter, featuring a greige finish and black bags, positioned in a modern room setting, showcasing its organizational capabilities.

## SAFETY INFORMATION

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the product on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly, as this may damage components.
- Always use the included anti-tip device to secure the unit to a wall, especially in households with children or pets, to prevent accidental tipping.
- Do not exceed the maximum static load capacity of 132 lbs (60 kg) for the entire unit and 77 lbs (35 kg) for the top shelf.
- Keep small parts away from children during assembly.

## PACKAGE CONTENTS

---

Verify that all components listed below are included in your package. If any parts are missing, please contact customer support.

Component	Quantity	Description
Metal Frame Parts	Set	Pre-drilled metal tubes for the main structure.
Particleboard Top Shelf	1	The main desktop surface.
Laundry Bags (Greige)	4	Removable Oxford fabric bags with handles and front pockets.
Bottom Plastic Panels	4	Support panels for the bottom of each laundry bag.
Adjustable Feet	4	For leveling the unit and protecting the floor.
Anti-Tip Device	1 Set	Hardware to secure the unit to a wall.
Assembly Hardware	Set	Screws, Allen wrench, etc. (extra screws typically included).
Instruction Manual	1	This document.

## SETUP AND ASSEMBLY

---

Follow these steps for proper assembly. It is recommended to have two people for assembly.

- 1. Unpack and Identify Parts:** Carefully unpack all components and lay them out on a soft, clean surface. Refer to the "Package Contents" section to ensure all parts are present.
- 2. Assemble the Metal Frame:** Connect the metal frame parts according to the diagrams in the included graphical instructions. Ensure all connections are secure but do not fully tighten screws until the frame is complete.
- 3. Attach Adjustable Feet:** Screw the adjustable feet into the bottom of the frame. Tighten them gently; overtightening can cause the rubber feet to detach.
- 4. Install Top Shelf:** Place the particleboard top shelf onto the assembled metal frame. Ensure the shelf is oriented correctly, especially if there are pre-drilled holes for securing the laundry bags. Secure the top shelf to the frame using the provided screws.
- 5. Prepare Laundry Bags:** Insert the plastic bottom panels into the base of each laundry bag to prevent sagging.
- 6. Hang Laundry Bags:** Attach the laundry bags to the designated rails or hooks on the frame. The bags are designed to be pull-out and removable.
- 7. Install Anti-Tip Device:** Secure the anti-tip device to the back of the unit and to a sturdy wall stud using the provided hardware. This is a critical safety step.
- 8. Final Tightening and Leveling:** Once the entire unit is assembled, gently tighten all screws. Adjust the feet to ensure the unit is stable and level on your floor.

# Solid and Long-lasting

Built with a steel frame and particleboard for dependable support



**132lb (60 kg)**

Total Max. Static Load Capacity

**77 lb (35 kg)**

Max. Static Load Capacity of the Top Shelf

**0.6" (1.5 cm)**

Sturdy steel tubes




Image: Diagram showing the overall dimensions (53.54" L x 13.4" W x 28.3" H) and static load capacities (132 lbs total, 77 lbs for top shelf) of the laundry hamper.

Ours

## Stays Upright

Bottom plastic panel support



Plastic Panel

Others

## Sags

Lacks a supportive base



Image: Visual comparison demonstrating how the included plastic bottom panel prevents the laundry bags from sagging, ensuring they stay upright and maintain their shape.

## OPERATING INSTRUCTIONS

### Using the Laundry Bags

- **Sorting Laundry:** Utilize the four individual bags to sort laundry by color, fabric type, or any other preferred method. Each bag has a capacity of 15 gallons (57.1 liters).
- **Pull-Out Design:** The bags are designed to slide out smoothly for easy access to contents.
- **Removable Bags:** Each bag features sturdy handles, allowing it to be easily lifted and carried to the washing machine.
- **Front Pockets:** Use the integrated front pockets on each bag to store small items such as delicates, socks, or laundry accessories.

# 60 Gal.(228 L) Large Capacity

Provides plenty of storage space for various items



20-24



24-31



24-31



28-32



**4** Front Pockets

Image: The laundry hamper displaying its 60 Gallon (228 L) total capacity across four 15 Gallon (57 L) bags, with examples of items like clothes, detergents, and towels, and highlighting the four front pockets.



## Divided Storage

4 fabric bags for sorting laundry by color & type to keep items organized

Image: The laundry hamper with its four fabric bags partially pulled out, demonstrating the divided storage capability for sorting laundry by color and type, and showing items stored in the front pockets.

### Using the Desktop Sorter

- The large desktop surface (27.2" x 13.4") provides additional space for folding clothes, placing laundry detergents, or organizing other items.
- The top surface is designed to be waterproof and scratch-resistant for durability and easy cleaning.

## Handy top surface

Waterproof and scratch-resistant desktop makes some items more convenient to access




Image: A close-up view of the top surface of the laundry hamper, demonstrating its waterproof and scratch-resistant properties with water droplets visible on the surface.

### MAINTENANCE

- **Cleaning the Frame and Shelf:** Wipe the metal frame and particleboard top shelf with a soft, damp cloth. Avoid harsh chemicals that may damage the finish.
- **Cleaning the Laundry Bags:** The Oxford fabric bags can be spot cleaned with a mild detergent and water. Allow them to air dry completely before reinserting. Do not machine wash or tumble dry.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.

### TROUBLESHOOTING

**Issue: Unit is wobbly or unstable.**

**Solution:** Check that all screws are securely tightened. Adjust the leveling feet on the bottom of the frame to compensate for uneven floors. Ensure the anti-tip device is properly installed and secured to a wall.

**Issue: Laundry bags sag or do not hold shape.**

**Solution:** Verify that the plastic bottom panels are correctly inserted into the base of each laundry bag. These panels are crucial for maintaining the bag's structure.

**Issue: Difficulty sliding bags in and out.**

**Solution:** Ensure the bags are correctly aligned with the rails. Check for any obstructions. If a screw under the tabletop is intended to prevent the hamper from sliding out completely, ensure it is not overtightened or misaligned, which could hinder smooth operation.

**Issue: Adjustable feet rubber caps detach.**

**Solution:** When installing the adjustable feet, tighten them only until snug. Overtightening can cause the rubber caps to pop off. If they detach, they can usually be reinserted.

## SPECIFICATIONS

Feature	Detail
Model Number	999HLH004SG
Product Dimensions (L x W x H)	53.5" x 13.39" x 28.27" (136cm x 34cm x 71.8cm)
Color	Greige
Material	Alloy Steel, Engineered Wood, Oxford Fabric
Number of Laundry Bags	4
Individual Bag Capacity	15 Gallons (57.1 Liters)
Total Capacity	60 Gallons (228 Liters)
Max. Static Load Capacity (Total)	132 lbs (60 kg)
Max. Static Load Capacity (Top Shelf)	77 lbs (35 kg)
Special Features	Removable Liner, Adjustable Feet, Anti-Tip Device, Front Pockets on Bags
Item Weight	11.98 Kilograms

## WARRANTY AND SUPPORT

For warranty information, replacement parts, or technical support, please contact Heybly customer service. Refer to your purchase documentation for specific warranty terms and contact details.

You can typically find support contact information on the Heybly official website or through the retailer where you purchased the product.

