

[Manuals.plus](#) /

› [INFANS](#) /

› INFANS Kids Ride-on ATV User Manual

INFANS TQ10114

INFANS Kids Ride-on ATV User Manual

MODEL: TQ10114



1. Important Safety Information

This product is designed for children over 3 years old and can support a maximum weight of 77 pounds. Always ensure adult supervision during operation. The ATV is constructed from new PP and iron materials, and is certified by ASTM and CPSIA, ensuring it is free from harmful substances like BPA, PVC, Phthalates, Lead, Latex, and Formaldehyde. It has passed tests for stability, asphyxiation, load, and shear.

The ATV features a **slow start function** to prevent sudden acceleration, enhancing safety for young riders. Its four large-diameter wheels contribute to overall stability. This product also complies with DOE & CEC electrical energy efficiency regulations.

— Slow Start Function —

Start at a uniform speed to ensure your baby's safety



Image: Diagram illustrating the slow start function for enhanced safety.

2. Product Overview

The INFANS Kids Ride-on ATV is a 12V electric toy vehicle designed to provide an engaging and safe driving experience for children. It features LED headlights, a horn, music functions, and high/low-speed settings.



Image: Front view of the INFANS Kids Ride-on ATV, highlighting its robust design and LED headlights.

Key Components:

- **LED Headlights:** Located at the front to illuminate the path.
- **Operation Panel:** Contains controls for speed, direction, horn, and music.
- **Foot Pedal:** Used for acceleration.
- **Cool Taillights:** Located at the rear for visibility.
- **Safety Handle:** Ergonomically designed for secure grip.
- **Comfortable Cushion:** Provides a comfortable seating position.
- **Durable Wheels:** Wear-resistant wheels suitable for various terrains.



1

LED lights

Operation Panel

2



3

Foot Pedal

Cool Taillights

4



Image: Detailed view of the ATV's LED lights, operation panel, foot pedal, and taillights.

— CORE FUNCTIONS —

PREMIUM QUALITY & HIGH APPEARANCE



Start & Stop Button



Safety Handle



Comfortable Cushion



Extra handle

Image: Illustration of the ATV's core functions including the start/stop button, safety handle, and comfortable seat.

3. Setup and Charging

Assembly:

Some assembly is required for the INFANS Kids Ride-on ATV. Please refer to the included assembly guide for detailed step-by-step instructions. Ensure all parts are securely fastened before initial use.

Charging the Battery:

The ATV is powered by a 12V battery. Before first use, and after each play session, ensure the battery is fully charged. A full charge typically takes 8-12 hours and provides 1-2 hours of playtime. Use only the charger provided with the product.



FAST & FURIOUS DRIVING EXPERIENCE



① FAST/SLOW

② FORWARD/BACKWARD/PAUSE

③ ON/OFF

④ HORN BUTTON

⑤ MUSIC BUTTON



Image: The INFANS Kids Ride-on ATV shown with its dedicated charger.

4. Operating Instructions

Familiarize yourself with the controls located on the operation panel before riding.

Controls:

- **ON/OFF Button:** Powers the ATV on or off.
- **Fast/Slow Speed Switch:** Allows selection between high and low speeds.
- **Forward/Backward Switch:** Controls the direction of movement.
- **Horn Button:** Activates the horn sound.
- **Music Button:** Plays built-in music.

Riding the ATV:

1. Ensure the ATV is on a flat, safe surface.

2. Press the ON button to power on the vehicle.
3. Select desired speed (slow for beginners, high for experienced riders).
4. Press the foot pedal to move forward. Release to stop.
5. Use the Forward/Backward switch to change direction.
6. The durable wheels are designed to adapt to various surfaces including road, grass, and sand, providing a smooth driving experience.



Image: A child enjoying a ride on the INFANS Kids Ride-on ATV in an outdoor setting.

DURABLE WHEEL



Image: Close-up of the ATV's durable wheel, illustrating its suitability for various terrains like road, grass, and sand.

Official Product Video:

Your browser does not support the video tag.

Video: An official demonstration of the INFANS Kids Ride-on ATV, showcasing its features and operation.

5. Maintenance

- **Cleaning:** Wipe the ATV with a damp cloth. Avoid using harsh chemicals or abrasive cleaners. Do not spray water directly onto electrical components.
- **Battery Care:** Always fully charge the battery after each use. If storing for an extended period, charge the battery at least once a month to prolong its lifespan. Store the ATV and battery in a dry, cool place.
- **General Inspection:** Regularly check all screws, nuts, and connections to ensure they are tight. Inspect wheels and tires for wear and tear.

6. Troubleshooting

- **ATV Not Starting/Moving:**
 - Check if the power switch is in the ON position.
 - Ensure the battery is fully charged.
 - Verify all electrical connections are secure.
 - Confirm the foot pedal is fully depressed.
- **Battery Not Holding Charge:**
 - Ensure the charger is properly connected and functioning.
 - Confirm charging time is sufficient (8-12 hours).
 - Battery may need replacement if it's old or frequently over-discharged.

7. Specifications

Feature	Detail
Product Dimensions	36.8" x 23.2" x 28.5" (L x W x H)
Item Weight	38 pounds
Item Model Number	TQ10114
Manufacturer Recommended Age	3+ years
Maximum Weight Capacity	77 pounds
Input	AC120V, 0.25A, 60Hz
Output	12V 0.9A
Motor	35W*2
Play Time	1-2 hours (after 8-12 hours charge)

Product Data



- Play Time : 1-2 hours
- Max Weight : 77 lbs
- Input : AC120V,0.25A,60Hz
- Output : 12V 0.9A
- Motor : 35W*2
- Age : 3 + years



Image: Visual representation of the product data and specifications.

8. Warranty and Customer Support

For warranty information or any product-related inquiries, please contact INFANS customer support. Keep your purchase receipt for any warranty claims.

Visit the official INFANS store for more information: [INFANS Store](#)

© 2025 INFANS. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question