

Manuals.plus /

› Meentek /

› Meentek Original TVIP Remote Control User Manual for TVIP 525, 605, 705, 706, 416, 405, SBOX 300

Meentek 7b4ee8fd-8fad-43b8-88fb-7c7e23ddcd39

Meentek Original TVIP Remote Control User Manual

Models: TVIP 525, 605, 705, 706, 416, 405, SBOX 300

INTRODUCTION

This manual provides comprehensive instructions for the Meentek Original TVIP Remote Control. It covers setup, operation, and troubleshooting for seamless control of your compatible TVIP set-top box models, including TVIP 525, 605, 705, 706, 416, 405, and SBOX 300.

The remote supports both Infrared (IR) and Bluetooth (BT) connectivity, offering flexible control options.

PACKAGE CONTENTS

- Meentek Original TVIP Remote Control
- (Batteries not included - requires 2 AAA batteries)

SETUP

1. Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover, sliding it back into place until it clicks securely.






Figure 1: Back view of the remote control, illustrating the battery compartment location.

2. Pairing with TVIP Media Center (Bluetooth Connection)

This remote control supports Bluetooth connectivity for enhanced functionality. Follow these steps to pair it with your TVIP media center:

1. Ensure your TVIP media center is powered on.
2. Locate the small reset/pairing button on the bottom of your TVIP media center.
3. Using a thin tool (e.g., a paperclip), press and hold this button for approximately 10 seconds. The media center will enter pairing mode and begin searching for a new Bluetooth remote.
4. On the Meentek remote control, simultaneously press and hold the **INFO** and **EPG** keys. Continue holding until the LED indicator on the remote starts to blink.
5. The media center's indicator will blink rapidly for a few seconds once it detects the remote.
6. Release the **INFO** and **EPG** keys. The connection should now be established.

Note: A single LED blink after a key press indicates a successful Bluetooth connection. Multiple LED blinks indicate an IR connection. Fast LED blinking during pairing indicates the remote is connecting to the media center.

OPERATING INSTRUCTIONS

The Meentek TVIP Remote Control features a standard layout for intuitive navigation and control of your TVIP set-top box.





Figure 2: Front view of the remote control with key functions labeled.

Key Functions

- **STB Power (Red Button):** Powers the TVIP set-top box on or off.
- **TV Power (Blue Button):** Powers the connected TV on or off (IR function).
- **Navigation Pad (Up, Down, Left, Right, OK):** Used for menu navigation and selection.
- **OK Button:** Confirms selections or opens menus.
- **Back/Return Button:** Returns to the previous screen or menu.
- **Home Button:** Returns to the main home screen of the TVIP media center.
- **Volume Up/Down (+/- VOL):** Adjusts the volume level.
- **Mute Button (Speaker Icon):** Mutes or unmutes the audio.
- **Page Up/Down (PG Up/Down):** Navigates through pages or channels.
- **Numeric Keypad (0-9):** Enters channel numbers or other numerical inputs.
- **Playback Controls (Rewind, Fast Forward, Play/Pause, Stop):** Controls media playback.
- **FN Button:** Function key, may activate secondary functions depending on the TVIP model.
- **Menu Button (Three Horizontal Lines):** Opens context-sensitive menus.

MAINTENANCE

Cleaning

To clean your remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials, as these can damage the remote's surface or internal components.

Battery Replacement

Replace batteries when the remote's response becomes sluggish or the LED indicator fails to light up consistently. Always replace both AAA batteries at the same time with new ones. Do not mix old and new batteries or different types of batteries.

TROUBLESHOOTING

Remote Not Responding

- **Check Batteries:** Ensure batteries are correctly installed and not depleted. Replace with fresh AAA batteries if necessary.
- **Line of Sight (IR Mode):** If using IR, ensure there is a clear line of sight between the remote and the TVIP media center. Remove any obstructions.
- **Re-pair Bluetooth:** If the remote is connected via Bluetooth and stops responding, try re-pairing it by following the "Pairing with TVIP Media Center" instructions in the Setup section.
- **Restart Devices:** Power cycle both the TVIP media center and the remote (by removing and reinserting batteries).

LED Indicator Behavior

- **Single Blink:** Indicates a successful Bluetooth connection.
- **Multiple Blinks:** Indicates an IR connection.
- **Fast Blinking:** Occurs when the remote is actively connecting to the media center during pairing.
- **No Blink:** Check batteries or if the remote is faulty.

SPECIFICATIONS

Feature	Detail
Brand	Meentek
Model Number	7b4ee8fd-8fad-43b8-88fb-7c7e23ddcd39
Connectivity	Infrared (IR), Bluetooth (BT)
Compatible Devices	TVIP set-top boxes (Models: 525, 605, 705, 706, 416, 405, SBOX 300)
Power Source	2 x AAA Batteries (not included)
Special Feature	No Programming Required (for basic IR functions)
Max Supported Devices	1
Item Weight	2.11 ounces
Package Dimensions	6.65 x 1.89 x 1.06 inches
Manufacturer	CHINA GS TECHNOLOGY CO LIMITED

WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in the available data. Please refer to the retailer or manufacturer's website for details regarding warranty coverage and customer support.

For technical assistance or further inquiries, please contact the vendor or the manufacturer, CHINA GS TECHNOLOGY CO LIMITED.