

[Manuals.plus](#) /

› [OttLite](#) /

› OttLite LED Soft Touch Desk Lamp User Manual

OttLite CSR3051C-SHPR

OttLite LED Soft Touch Desk Lamp

USER MANUAL

1. INTRODUCTION

Product Overview

The OttLite LED Soft Touch Desk Lamp is designed to provide optimal lighting for various tasks, from reading and studying to crafting and office work. Featuring OttLite's Natural Daylight LEDs, it aims to reduce eyestrain and show colors accurately. Its flexible neck and touch controls offer versatile and user-friendly operation.



Figure 1: OttLite LED Soft Touch Desk Lamp in a typical desk setup.

Key Features

- **3 Brightness Levels:** Easily switch between three distinct brightness settings using the touch-sensitive control.
- **Adjustable Flexible Neck:** The rubberized flexible neck allows for precise positioning of the light, extending height from 8 to 18 inches.
- **Natural Daylight LEDs:** Equipped with OttLite's unique LEDs that simulate natural daylight, reducing glare and eyestrain while rendering colors accurately.
- **Energy Efficient:** LEDs are rated to last up to 40,000 hours, providing long-lasting, bright illumination.
- **Versatile Use:** Suitable for various environments including home offices, computer desks, dorms, and for activities like reading, crafting, and studying.



Figure 2: Overview of the lamp's design and features.

2. SETUP

Unpacking

Carefully remove the OttLite LED Soft Touch Desk Lamp from its packaging. Ensure all components, including the lamp unit and the power adapter, are present and undamaged. Retain packaging for future storage or transport if needed.

Power Connection

1. Locate the power input port on the back of the lamp base.
2. Insert the provided power adapter into the lamp's power input port.
3. Plug the power adapter into a standard electrical outlet (120 Volts).



Shows Colors with Incredible Accuracy



Figure 3: The lamp's compact design allows for easy placement on any tabletop.

3. OPERATING INSTRUCTIONS

Power On/Off and Brightness Control

The lamp features intuitive touch controls located on its base:

- To turn the lamp **ON**, gently touch the power icon on the base.
- To cycle through the **three brightness levels** (low, medium, high), continue to touch the power icon.
- To turn the lamp **OFF**, touch the power icon after the highest brightness setting.



Great for **reading, studying, crafts, puzzles,**
and any other tabletop work.

Figure 4: The lamp offers three distinct brightness settings for various lighting needs.

Adjusting the Lamp Position

The lamp is equipped with a flexible, rubberized neck that allows for easy adjustment of the light's height and angle. Gently bend the neck to direct the light precisely where it is needed. The height can be adjusted from approximately 8 inches to 18 inches.



Space-saving design

Flexible neck allows you to move the light exactly where you need it.



Touch-sensitive controls allow you to switch between **3 brightness levels**.

Figure 5: The flexible neck provides versatile positioning for optimal illumination.

4. MAINTENANCE

Cleaning

To maintain the appearance and functionality of your OttLite lamp, follow these cleaning guidelines:

- Ensure the lamp is unplugged from the power outlet before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth.
- Avoid using abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish.
- Do not immerse the lamp in water or spray liquids directly onto it.

Storage

When not in use for extended periods, store the lamp in a cool, dry place. If possible, use the original packaging to protect it from dust and damage.

5. TROUBLESHOOTING

If you encounter any issues with your OttLite LED Soft Touch Desk Lamp, please consider the following general troubleshooting steps:

- **Lamp does not turn on:**
 - Ensure the power adapter is securely plugged into both the lamp and a working electrical outlet.
 - Test the outlet with another device to confirm it is receiving power.
- **Light flickers or is dim:**
 - Verify the power connection is stable.
 - Cycle through the brightness settings to ensure it's not on the lowest setting.
- **Touch controls are unresponsive:**
 - Ensure your finger is making full contact with the touch sensor.
 - Unplug the lamp for a few seconds and then plug it back in to reset the controls.

For persistent issues not resolved by these steps, please contact OttLite customer support.

6. SPECIFICATIONS

Attribute	Value
Brand	OttLite
Model Number	CSR3051C-SHPR
Color	Dark Grey
Light Source Type	LED
Brightness	450 lumens (max output) / 463 Lumen (from specs)
Wattage	6.2 watts
Voltage	120 Volts
Color Temperature	5000 Kelvin
Product Dimensions	6.25"D x 6.25"W x 13.5"H

Attribute	Value
Adjustable Height	8" to 18"
Switch Type	Touch
Material	Plastic, Acrylonitrile Butadiene Styrene (Base/Shade)
Included Components	Adapter
UPC	761712022062

ClearSun Technology

The spectral output of most LED light sources looks like a roller coaster — full of big peaks and deep valleys that leave your eye muscles strained.

ClearSun LEDs are different. Our revolutionary technology creates a comparable experience to natural daylight, with no gaps for your eyes to fill in. ClearSun creates balanced, smooth lighting that **reduces eyestrain up to 51%.**




Figure 6: ClearSun LED Technology provides a natural daylight spectrum for reduced eyestrain.

7. WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official OttLite website or contact OttLite customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims. You can visit the official OttLite store for more information and products:[OttLite Store on Amazon](#)

© 2024 OttLite. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question