

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Arteck](#) /
- › [Arteck HW193 2.4G Wireless Keyboard User Manual](#)

Arteck HW193

Arteck HW193 2.4G Wireless Keyboard User Manual

Model: HW193

1. INTRODUCTION

The Arteck HW193 2.4G Wireless Keyboard offers a seamless typing experience with its Japanese layout, durable stainless steel construction, and lightweight design. This full-size keyboard includes a numeric keypad and is compatible with various devices running Windows 11/10/8, desktops, PCs, laptops, Surface devices, and smart TVs. Featuring a long-lasting rechargeable battery, it ensures extended usage.

2. PACKAGE CONTENTS

- Arteck 2.4G Wireless Keyboard
- USB Receiver
- USB Charging Cable
- User Manual

3. SETUP

3.1 Simple Connection

To connect your Arteck HW193 keyboard, simply plug the included USB receiver into an available USB port on your PC or compatible device. No additional drivers or complex setup is required.




Image: The Arteck HW193 keyboard shown with its compact USB receiver, illustrating the simple plug-and-play connection process.

3.2 Visual Setup Guide

Video: This video demonstrates the quick and easy setup process for the Arteck 2.4G Wireless Keyboard, including plugging in the USB receiver and basic operation.

4. OPERATING INSTRUCTIONS

4.1 Numeric Keypad Usage

The keyboard includes a dedicated numeric keypad. To activate numeric input, ensure the **Num Lock** function is enabled. An indicator light on the keyboard will confirm its status.

4.2 Function Keys

The top row of keys features various function keys (F1-F12) that can be used for multimedia control, volume adjustment, and screen brightness control. These functions are typically accessed by pressing the **Fn** key in combination with the desired function key.



簡単接続

USB レシーバーを挿入するだけで設定なしで使えます。

Image: A detailed view of the Arteck HW193 keyboard layout, highlighting the function keys and numeric keypad for efficient use.

5. FEATURES

5.1 Superior Design and Typing Feel

The Arteck HW193 features a durable stainless steel construction that provides a robust and premium feel. Its low-profile, scissor-switch keys are designed for quiet and comfortable typing, making it ideal for various environments.

長寿命バッテリー

1日2時間の使用で、6ヶ月使えるバッテリーを搭載しています。



Image: A close-up showing the scissor-switch mechanism of the Arteck HW193 keyboard, which contributes to its comfortable and quiet typing experience.



Image: The underside of the Arteck HW193 keyboard, showcasing its brushed stainless steel back and non-slip silicone pads for stability.

5.2 Long-Life Rechargeable Battery

Equipped with a high-capacity rechargeable lithium-ion battery, the keyboard can last up to 6 months on a single full charge, based on 2 hours of continuous daily use. This ensures long periods of productivity without frequent recharging.



打ち心地が良い

Xの構造は、普通のキーボードと比較で等しい圧力とキーストロークを低くされる作用を発揮しています。

Image: The Artek HW193 keyboard displaying its battery indicator lights, which provide a visual cue for the remaining charge.

5.3 Ultra-Lightweight and Slim Design

The keyboard boasts a compact size of 14.5 x 4.9 x 0.6 inches and a lightweight design of approximately 12.7 ounces (360g). Despite its slim profile, it includes full-size arrow keys, shortcut keys, and a numeric keypad for comprehensive functionality.



Image: The Arteck HW193 keyboard with its compact dimensions and light weight clearly indicated, emphasizing its portability and space-saving design.

6. SPECIFICATIONS

Feature	Detail
Brand	Arteck
Model Number	HW193-JP
Package Dimensions	37.6 x 16.2 x 2.2 cm
Item Weight	550 g
Batteries Included	Yes
Lithium Battery Energy Content	1 Watt Hours
Lithium Battery Packaging	Battery contained in equipment
Lithium Battery Weight	1 Grams
Compatible Devices	Laptop, Desktop, PC, Surface, Smart TV
Keyboard Description	Integrated
Special Feature	Rechargeable
Included Components	USB Cable
Switch Type	Scissor Switch

Keyboard Layout	QWERTY (Japanese)
Hand Orientation	Ambidextrous
EU Spare Part Availability Period	6 Months

7. MAINTENANCE

7.1 Cleaning

To clean your keyboard, use a soft, dry, lint-free cloth. Avoid using liquid cleaners, abrasive materials, or aerosol sprays directly on the keyboard, as these can damage the keys or internal components.

7.2 Storage

When not in use, store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures. Avoid placing heavy objects on the keyboard to prevent damage.

8. TROUBLESHOOTING

8.1 Connection Issues

- Ensure the USB receiver is securely plugged into a working USB port on your device.
- Check the keyboard's power switch to ensure it is in the 'ON' position.
- Verify the keyboard's battery level. If low, connect the USB charging cable.
- Try plugging the USB receiver into a different USB port on your device.
- Restart your computer or device.

8.2 Keys Not Responding

- Recharge the keyboard using the provided USB cable.
- If using the numeric keypad, ensure the **Num Lock** is activated.
- Check for any physical obstructions under the keys.
- If specific keys are not working, try cleaning around them gently.

9. WARRANTY AND SUPPORT

The Artek HW193 2.4G Wireless Keyboard comes with a 2-year warranty. For any product-related inquiries, technical support, or warranty claims, please contact Artek customer service. Refer to the contact information provided in your product packaging or on the official Artek website.