

Muse M-1982

Muse M-1982 DJ Sono Party Box 600W Instruction Manual

1. INTRODUCTION

Thank you for purchasing the Muse M-1982 DJ Sono Party Box. This powerful 600W audio system is designed to provide high-quality sound and vibrant multi-color lighting for your events and gatherings. Featuring versatile connectivity options including Bluetooth, USB, and auxiliary inputs, along with dedicated microphone and guitar inputs, the M-1982 offers a comprehensive solution for your audio entertainment needs. Please read this manual carefully to ensure proper setup, operation, and maintenance of your device.

2. SAFETY INFORMATION

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Do not expose the unit to rain, moisture, or extreme temperatures.
- Ensure proper ventilation around the unit to prevent overheating.
- Do not block ventilation openings.
- Use only the provided power cable and connect to a compatible power outlet.
- Avoid placing the unit on unstable surfaces.
- Do not open the casing; refer all servicing to qualified personnel.
- Keep the unit away from strong magnetic fields.
- Unplug the unit during lightning storms or when unused for long periods.

3. PACKAGE CONTENTS

Please check that all items listed below are included in your package:

- Muse M-1982 DJ Sono Party Box
- Remote Control
- Wired Microphone
- 32GB USB Stick

- Power Cable
- Instruction Manual (this document)

4. PRODUCT OVERVIEW

The Muse M-1982 is a powerful audio system designed for dynamic sound and visual effects. Below is an overview of its main features and components.

4.1 Key Features

- 600W Output Power for robust sound.
- Multi-color Ambient Lighting for visual effects.
- Bluetooth V5.0 for wireless audio streaming.
- Stereo Pairing capability (with another compatible unit).
- Adjustable Treble and Bass controls.
- USB 2.0 Port for MP3 playback and USB charging.
- Multiple Auxiliary Inputs: RCA (Left/Right) and 3.5mm jack.
- Dedicated Microphone Input.
- Combined Microphone/Guitar Input.
- White LED Display.

4.2 Unit Diagram and Controls

Refer to the image below for a visual representation of the Muse M-1982 unit and its control panel.





Figure 1: Front view of the Muse M-1982 DJ Sono Party Box, showcasing its multi-color ambient lighting and the included 32GB USB stick.



Figure 2: Detailed view of the top control panel, showing various buttons, knobs, and input ports for operation.

5. SETUP

Follow these steps to set up your Muse M-1982 DJ Sono Party Box:

1. **Unpacking:** Carefully remove the unit and all accessories from the packaging. Retain the packaging for future transport or storage.
2. **Placement:** Place the unit on a stable, flat surface. The M-1982 is designed for floor mounting. Ensure there is adequate space around the unit for ventilation.
3. **Power Connection:** Connect the power cable to the AC IN port on the back of the unit, then plug the other end into a standard 100-240V, 50/60Hz wall outlet.
4. **Initial Power On:** Press the Power button on the control panel or remote control to turn on the unit. The LED display will illuminate.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off

Press the **POWER** button on the top panel or remote control to turn the unit ON or OFF.

6.2 Mode Selection

Press the **MODE** button repeatedly to cycle through available input modes: Bluetooth, USB, AUX1 (RCA), AUX2

(3.5mm).

6.3 Bluetooth Connection

1. Turn on the unit and select **Bluetooth** mode. The LED display will show "BT" and flash, indicating it's in pairing mode.
2. Enable Bluetooth on your smartphone, tablet, or computer.
3. Search for "M-1982" in your device's Bluetooth list and select it to connect.
4. Once connected, the "BT" indicator will stop flashing, and you can stream audio wirelessly.

6.4 USB Playback

1. Insert a USB flash drive (pre-formatted with MP3 audio files) into the **USB 2.0** port.
2. The unit will automatically switch to USB mode and begin playing MP3 files. If not, select **USB** mode using the **MODE** button.
3. Use the **PLAY/PAUSE**, **PREVIOUS**, and **NEXT** buttons to control playback.
4. The USB port also supports charging for compatible devices.

6.5 AUX Input (RCA & 3.5mm)

Connect external audio devices (e.g., CD player, TV, non-Bluetooth smartphone) using the auxiliary inputs:

- **AUX1 (RCA):** Use an RCA cable to connect your device to the red and white RCA jacks on the unit.
- **AUX2 (3.5mm):** Use a 3.5mm audio cable to connect your device to the 3.5mm AUX IN jack.

Select the corresponding **AUX** mode using the **MODE** button.

6.6 Microphone and Guitar Inputs

The unit features dedicated inputs for live performance or karaoke:

- Plug your microphone into the **MIC IN** jack.
- Plug your guitar or a second microphone into the **MIC/GUITAR IN** jack.

Adjust the individual volume levels for the microphone and guitar using their respective control knobs on the top panel.

6.7 Adjusting Sound (Treble & Bass)

Use the **TREBLE** and **BASS** control knobs on the top panel to fine-tune the audio output to your preference.

6.8 Stereo Pairing

If you have two Muse M-1982 units, you can pair them for a stereo sound experience. Refer to the specific instructions in the full manual for detailed stereo pairing procedures, typically involving a dedicated pairing button or sequence.

6.9 Multi-color Ambient Lighting

The unit features dynamic multi-color ambient lighting. Use the dedicated **LIGHT** button on the control panel or remote to cycle through different lighting modes or turn the lights off.





Figure 3: The Muse M-1982 unit displaying blue ambient lighting, suitable for various moods and events.



Figure 4: The M-1982 unit with blue lighting integrated into a stage or event setup, demonstrating its visual impact.



Figure 5: The M-1982 unit with green lighting, showcasing another color option for its ambient light effects in an event environment.

7. MAINTENANCE

Proper maintenance ensures the longevity and performance of your Muse M-1982:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the unit. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use for extended periods, store the unit in a cool, dry place, preferably in its original packaging.
- **Ventilation:** Ensure that the ventilation openings are free from dust and debris.

8. TROUBLESHOOTING

If you encounter any issues with your Muse M-1982, refer to the following common problems and solutions:

- **No Power:**
 - Check if the power cable is securely connected to both the unit and the wall outlet.
 - Verify that the wall outlet is functioning correctly by plugging in another device.
- **No Sound:**

- Ensure the master volume is turned up.
- Check the volume level on your connected audio source (e.g., smartphone, USB).
- Verify that the correct input mode (Bluetooth, USB, AUX) is selected.
- For microphone/guitar, ensure their individual volume knobs are adjusted.

- **Bluetooth Not Connecting:**

- Make sure the unit is in Bluetooth pairing mode (LED display shows "BT" flashing).
- Ensure your device's Bluetooth is enabled and within range (typically 10 meters).
- Try unpairing "M-1982" from your device's Bluetooth list and re-pairing.
- Restart both the M-1982 and your Bluetooth device.

- **USB Playback Issues:**

- Ensure the USB drive is formatted correctly and contains compatible MP3 files.
- Try a different USB drive to rule out a faulty drive.

If the problem persists after trying these solutions, please contact customer support.

9. SPECIFICATIONS

Feature	Specification
Output Power	600W
Bluetooth Version	V5.0
Connectivity Technology	Bluetooth, USB
Inputs	USB 2.0, AUX (RCA L/R, 3.5mm), Microphone, Microphone/Guitar
Power Source	AC 100-240V, 50/60Hz (Integrated SMPS Transformer)
Display	White LED Display
Dimensions (H x D x L)	1018 mm x 292 mm x 330 mm
Net Weight	12.3 kg
Compatible Devices	Guitar, Microphone, Computer, Smartphone, Tablet
Mounting Type	Floor Mount

10. WARRANTY AND SUPPORT

The Muse M-1982 DJ Sono Party Box comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, service, or further inquiries, please contact your retailer or the official Muse customer service channels.

Keep your proof of purchase for warranty claims.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question