Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SteFik Compatible with Silvercrest SSR1, SSRA1, Ilife A9s/A9/A7/A80 Plus, A10s, L100 Robotic Vacuum Cleaners

SteFik Replacement Roller and Side Brushes User Manual

For Silvercrest SSR1, SSRA1, Ilife A9s/A9/A7/A80 Plus, A10s, L100 Robotic Vacuum Cleaners

1. Introduction

This manual provides instructions for the installation, maintenance, and general use of SteFik replacement roller and side brushes. These brushes are designed to maintain the optimal cleaning performance of your compatible robotic vacuum cleaner.

2. Package Contents

Upon opening the package, please verify that all components are present and undamaged:

- 1 x Roller Brush
- 4 x Side Brushes



Image: The package includes one main roller brush and four three-armed side brushes. The roller brush features black bristles arranged in a V-pattern on a light gray core. The side brushes are black with three bristles each, designed for corner cleaning.

3. Product Features

- **Durable Construction:** All accessories are manufactured from durable materials, ensuring long-lasting use and consistent cleaning performance.
- **Effective Cleaning:** The roller brush, vacuuming brush, and side brushes work together to effectively remove dust and debris from various floor surfaces.
- **Optimized Design:** Roller and main brushes are designed for cleaning large floor areas, while side brushes are specifically shaped to reach deep into narrow areas and corners.
- **Easy Replacement:** These accessories are designed for simple and quick replacement, requiring no special skills.

4. Compatibility

These replacement brushes are compatible with the following robotic vacuum cleaner models:

- Silvercrest SSR1
- Silvercrest SSRA1
- Ilife A9s

- Ilife A9
- Ilife A7
- Ilife A80 Plus
- Ilife A10s
- Ilife L100

Please ensure your vacuum cleaner model is listed above to guarantee proper fit and function.

5. Installation and Setup

Follow these steps to replace the roller brush and side brushes in your robotic vacuum cleaner. Refer to your vacuum cleaner's original manual for specific instructions on accessing the brush compartments, as procedures may vary slightly by model.

5.1. Replacing the Roller Brush

1. **Power Off:** Ensure your robotic vacuum cleaner is powered off and unplugged (if applicable) before beginning any maintenance.
2. **Access Brush Compartment:** Turn the vacuum cleaner over. Locate and open the roller brush cover, usually secured by latches or screws.
3. **Remove Old Brush:** Carefully lift out the old roller brush. Note its orientation for correct installation of the new brush.
4. **Install New Brush:** Insert the new SteFik roller brush into the compartment, ensuring the ends align with the designated slots.
5. **Secure Cover:** Close the roller brush cover and secure it properly.

5.2. Replacing the Side Brushes

1. **Power Off:** Ensure your robotic vacuum cleaner is powered off.
2. **Locate Side Brushes:** Turn the vacuum cleaner over. The side brushes are typically located on the front corners.
3. **Remove Old Brushes:** Depending on your model, the side brushes may be held by a single screw or simply snap into place. Unscrew or gently pull off the old side brushes.
4. **Install New Brushes:** Align the new SteFik side brushes with the corresponding posts. If screw-on, secure with the screw. If snap-on, press firmly until it clicks into place.

6. Maintenance

Regular maintenance of your brushes ensures optimal cleaning performance and extends their lifespan.

6.1. Cleaning the Roller Brush

- Remove the roller brush as described in Section 5.1.
- Use a cleaning tool (often provided with your vacuum) or scissors to cut and remove any hair, string, or debris tangled around the brush bristles and ends.
- Wipe the brush with a dry cloth. Avoid washing with water unless specifically instructed by your vacuum cleaner's manual.
- Reinstall the clean roller brush.

6.2. Cleaning the Side Brushes

- Remove the side brushes as described in Section 5.2.
- Gently pull off any hair or debris wrapped around the bristles or the base of the brush.
- If the bristles are bent, you can try soaking them in warm water for a few minutes to help them regain their shape. Allow them to dry completely before reinstallation.
- Reinstall the clean side brushes.

6.3. Replacement Frequency

For optimal performance, it is recommended to replace the roller brush every 6-12 months and the side brushes every 3-6 months, depending on usage frequency and cleaning environment. Inspect brushes regularly for wear and tear.

7. Troubleshooting

If your robotic vacuum cleaner's cleaning performance seems reduced after installing new brushes, consider the following:

- **Brushes Not Spinning:** Ensure the brushes are correctly installed and fully seated. Check for any obstructions or debris preventing rotation.
- **Reduced Debris Pickup:** Verify that the brushes are clean and free of tangles. Ensure the vacuum's dustbin is not full and filters are clean.
- **Unusual Noise:** Remove and re-install the brushes to ensure they are properly seated. Check for any foreign objects caught in the brush mechanism.

If issues persist, consult your robotic vacuum cleaner's original user manual or contact the vacuum cleaner manufacturer's support.

8. Specifications

Component	Quantity
Roller Brush	1
Side Brushes	4

Package Dimensions: 1.18 x 0.79 x 0.39 inches
Item Weight: 1.76 ounces
Assembly Required: No (for the brushes themselves)
Manufacturer: zhangmeifengf (SteFik brand)

9. Warranty and Support

For questions regarding the SteFik replacement brushes, please refer to the retailer where the product was purchased. For issues related to your robotic vacuum cleaner, please consult its original manufacturer's support channels.

© 2023 SteFik. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CND55NX8

More documents and user manuals: **https://manuals.plus/**