

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [WILLED](#) /

> [WILLED 3W Rechargeable Light Bar Instruction Manual](#)

WILLED B0CND6SSZW

WILLED 3W Rechargeable Light Bar Instruction Manual

Brand: WILLED | Model: B0CND6SSZW

1. PRODUCT OVERVIEW

The WILLED 3W Rechargeable Light Bar is a versatile lighting solution designed for various indoor applications. It features 120 energy-saving LEDs, a built-in 2000mAh rechargeable battery with a battery level display, and offers both touch and remote control options. Users can adjust between three color temperatures (3000K, 4500K, 6000K) and five brightness levels to suit different lighting needs. Its magnetic mounting system allows for easy installation and adjustable lighting angles, making it ideal for cabinets, closets, bunk beds, kitchens, and makeup mirrors.



Figure 1: WILLED 3W Rechargeable Light Bar with Remote Control and color temperature samples.

2. WHAT'S IN THE BOX

- 1 x LED Light Bar
- 2 x Magnetic Base
- 1 x Remote Control
- 1 x Type-C Charging Cable
- 1 x User Manual

3. SETUP AND INSTALLATION

The WILLED Light Bar offers easy, tool-free installation thanks to its magnetic mounting system. Follow these steps for quick setup:

1. **Prepare the Surface:** Ensure the desired installation surface (e.g., wall, cabinet, mirror) is clean, dry, and smooth.
2. **Attach Magnetic Bases:** The light bar comes with two sturdy magnetic mounts. Peel off the adhesive tape from the back of the magnetic bases.
3. **Stick Bases:** Firmly press the magnetic bases onto the prepared surface. Apply pressure for a few seconds

to ensure strong adhesion.

4. **Mount Light Bar:** Align the light bar with the magnetic bases. The strong magnets will securely hold the light bar in place.
5. **Adjust Angle:** The exclusive magnetic mount allows you to adjust the lighting angle up to 135 degrees to direct light precisely where needed.




Figure 2: Magnetic installation and adjustable angle feature.

4. OPERATING INSTRUCTIONS

The WILLED Light Bar offers dual control modes: touch control directly on the light bar and remote control for convenience.

4.1 Touch Control

The light bar features intuitive touch buttons for basic functions:

- **Power Button ():** Press to turn the light ON or OFF.
- **Brightness Adjustment (- / +):** Use the minus (-) and plus (+) buttons to cycle through 5 brightness levels (10%, 30%, 50%, 70%, 100%).

- **Color Temperature Adjustment ():** Press the circle button to switch between 3 color temperatures: 3000K (Warm White), 4500K (Natural White), and 6000K (Cool White).



Figure 3: Visual representation of 5 brightness levels and 3 color temperatures.

4.2 Remote Control

For added convenience, use the included remote control to operate the light bar from a distance:

- **ON/OFF:** Dedicated buttons to turn the light ON or OFF.
- **Brightness Levels:** Direct buttons for 10%, 30%, 50%, 70%, and 100% brightness.
- **Color Temperatures:** Direct buttons for 3000K, 4500K, and 6000K.
- **Timer Function:** Set the light to automatically turn off after 15, 30, or 60 minutes.

4.3 Battery and Charging

The light bar is equipped with a 2000mAh rechargeable battery. A digital display on the light bar shows the exact percentage of remaining battery life, indicating when it's time to recharge. Use the provided Type-C charging cable to recharge the device. A full charge typically takes approximately 4 hours and provides up to 30 hours of light at 10% brightness or 4 hours at 100% brightness.



Long Battery Life

Lasts 30 hours at 10% brightness
and 4 hours at 100%



Battery Level Display

Type-C Rechargeable
Fully charged within 4 hours



Figure 4: Battery level display and Type-C charging feature.

5. MAINTENANCE

To ensure the longevity and optimal performance of your WILLED Light Bar, follow these simple maintenance guidelines:

- **Cleaning:** Gently wipe the light bar with a soft, dry cloth. Avoid using abrasive cleaners or solvents that may damage the surface or electronic components.
- **Charging:** Recharge the battery when the display indicates a low percentage to maintain battery health. Use only the provided Type-C cable or a compatible charger.
- **Storage:** If storing for an extended period, ensure the battery is partially charged (around 50%) and store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Water:** This product is not water resistant. Avoid exposure to water or high humidity to prevent damage.

6. TROUBLESHOOTING

If you encounter any issues with your WILLED Light Bar, please refer to the following common troubleshooting tips:

- **Light Not Turning On:**

- Check if the battery is charged. Recharge the light bar if the battery level is low.
- Ensure the power button is pressed firmly.

- **Remote Control Not Working:**

- Ensure there are no obstructions between the remote and the light bar.
- Check the remote control's battery.

- **Light Flickering or Dim:**

- The battery might be low. Recharge the light bar.
- Ensure the light bar is not exposed to extreme temperatures.

- **Magnetic Mount Not Holding:**

- Ensure the installation surface is clean and smooth.
- Re-apply the magnetic bases with new adhesive tape if necessary.

If the issue persists after trying these steps, please contact customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	WILLED
Model	B0CND6SSZW
Power Source	Battery Powered
Wattage	3 watts
Brightness	1000 Lumen
Number of Light Sources	120 LEDs
Color Temperature	3000K, 4500K, 6000K (Adjustable)
Control Method	Remote, Touch
Battery Capacity	2000mAh Lithium Polymer
Product Dimensions	1.45"L x 0.5"W x 11.8"H
Item Weight	10.56 ounces
Installation Type	Magnetic Stick On
Special Features	Memory Function, Dimmable, Timer, Battery Level Display

For more detailed specifications, please refer to the product packaging or official website.

Energy Label Information: <https://eprel.ec.europa.eu/qr/1507970>

8. WARRANTY AND SUPPORT

WILLED provides a **12-month warranty** for this product, as stated in the specifications. Additionally, we offer **1**

year free replacement services for any questions or issues you may encounter after receiving or using your light bar. If you experience any problems or have inquiries, please do not hesitate to contact our customer support team for assistance.

For further support, visit the official WILLED Store: [WILLED Store on Amazon](#).