

Kumtel B66-SF2

Kumtel B66-SF2 Built-in Electric Oven Instruction Manual

Model: B66-SF2

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the appliance. Keep this manual for future reference.

- **Electrical Safety:** Ensure the oven is properly grounded. Do not operate with a damaged power cord or plug. Disconnect power before servicing.
- **Burn Hazard:** Oven surfaces become hot during operation. Use oven mitts when handling hot items. Keep children away from the oven.
- **Fire Hazard:** Do not store flammable materials in or near the oven. Clean grease and food spills regularly to prevent fires.
- **Installation:** Installation must be performed by a qualified technician in accordance with local codes and this manual.
- **Ventilation:** Ensure adequate ventilation around the oven as specified in the installation section.

2. PRODUCT OVERVIEW AND FEATURES

The Kumtel B66-SF2 is a high-performance built-in electric oven designed for efficient and versatile cooking. It features a sleek design and user-friendly controls.

Key Features:

- 2000 Watt power for rapid heating and consistent cooking.
- Four distinct cooking functions to suit various culinary needs.
- Integrated turbo fan (convection) for even heat distribution.
- Adjustable timer with an audible bell alarm for precise cooking control.
- Adjustable thermostat for accurate temperature management.
- Durable wire rack system for flexible placement of dishes.
- Easily removable inner glass for convenient cleaning.

- Simple-to-clean glass control panel.
- Powerful interior lighting for clear visibility of food during cooking.
- Non-rust enamel tray for durability and easy maintenance.
- Chrome grid for additional cooking options.
- Energy efficient design.

3. INSTALLATION INSTRUCTIONS

Proper installation is crucial for the safe and efficient operation of your Kumtel B66-SF2 oven. Refer to the diagrams below for precise measurements and cabinet requirements.

Cabinet Dimensions:

- Minimum Width: 560 mm
- Minimum Depth: 570 mm
- Height: 600 mm

Electrical Connection:

The oven requires a 220V electrical supply. Ensure the electrical circuit is capable of handling a 2000W appliance and is protected by an appropriate circuit breaker. All electrical connections must comply with local electrical codes.



Image Description: This diagram illustrates the necessary cabinet dimensions for installing the Kumtel B66-SF2 built-in oven. It shows the minimum width (Min. 560), minimum depth (Min. 570), and height (600) required for the oven cavity. Additional views provide detailed measurements of the oven's front (595mm width, 598.3mm height), side (566.2mm depth, 575.2mm height), and an isometric view showing the overall structure. These measurements are critical for ensuring a proper and secure fit within your kitchen cabinetry.

4. OPERATING YOUR OVEN

Familiarize yourself with the control panel before first use.

Control Panel:

The oven features control knobs for function selection, temperature adjustment, and a digital timer display.

Cooking Functions:

Select one of the four available cooking functions using the function selector knob. These functions typically include:

- **Conventional Heating:** Top and bottom heating elements for traditional baking and roasting.
- **Convection (Turbo Fan):** Utilizes the turbo fan to circulate hot air, ensuring even cooking and faster results. Ideal for multiple dishes.
- **Grill:** Top heating element for grilling and browning.
- **Bottom Heating:** For dishes requiring more heat from the base.

Temperature Adjustment:

Turn the thermostat knob to set the desired cooking temperature. The oven will preheat to this temperature.

Timer Setting:

Use the timer controls to set the cooking duration. An audible bell alarm will sound once the set time has elapsed.

5. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your oven.

Interior Cleaning:

- Allow the oven to cool completely before cleaning.
- The inner glass can be easily removed for thorough cleaning. Refer to the specific instructions for glass removal in the full manual (if applicable).
- Use a soft cloth and non-abrasive oven cleaner for the interior surfaces and enamel tray.
- Wipe down the chrome grid and wire racks with warm, soapy water.

Exterior Cleaning:

- Clean the glass control panel and exterior surfaces with a soft, damp cloth and mild detergent.
- Avoid using abrasive cleaners or scouring pads, as they can scratch the surface.

6. TROUBLESHOOTING GUIDE

Before contacting customer service, please check the following common issues:

Problem	Possible Cause	Solution
Oven does not turn on	No power supply; Door not closed properly	Check power connection and circuit breaker; Ensure oven door is fully closed.
Uneven cooking	Incorrect rack position; Overcrowding; Fan malfunction	Adjust rack position; Avoid overcrowding; Contact service if fan is not working.
Oven light not working	Bulb burnt out	Replace oven light bulb (ensure oven is unplugged).

7. TECHNICAL SPECIFICATIONS

Feature	Detail
Brand	Kumtel

Feature	Detail
Model Number	B66-SF2 (Part No: 362-10-B66-SF2)
Power	2000 Watt
Voltage	220 Volt
Installation Type	Built-in
Heating Method	Electric
Material	Stainless Steel
Finish Type	Polished
Product Dimensions (D x W x H)	62 cm x 63 cm x 62 cm
Item Weight	1 Kilogram
Special Features	Turbo fan, Time setting
Included Components	Built-in oven
Batteries Required	No

8. WARRANTY AND SUPPORT

For warranty information, service requests, or technical support, please refer to the warranty card included with your product or contact Kumtel customer service. Keep your purchase receipt as proof of purchase. For further assistance, visit the official Kumtel website or contact your local authorized service center.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question