

[Manuals.plus](#) /

› [Haam Electric](#) /

› Haam HM710SSD-O23INV Side-by-Side Refrigerator User Manual

Haam Electric HM710SSD-O23INV

Haam HM710SSD-O23INV Side-by-Side Refrigerator User Manual

Model: HM710SSD-O23INV | Brand: Haam Electric

1. INTRODUCTION

Thank you for choosing the Haam HM710SSD-O23INV Side-by-Side Refrigerator. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your appliance. Please read these instructions thoroughly before using the refrigerator and keep them for future reference.



Image 1: Front view of the Haam HM710SSD-O23INV Side-by-Side Refrigerator with its four doors open, showcasing the spacious interior and organized compartments for fresh food and freezer items.

2. SAFETY INFORMATION

Always follow basic safety precautions when using this appliance to reduce the risk of fire, electric shock, or injury. This refrigerator is designed for household use only.

- Ensure the power cord is not damaged and is properly grounded.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Keep ventilation openings clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.




Image 2: Energy efficiency label for the Haam HM710SSD-O23INV refrigerator, showing a 5-star rating, 390 kWh annual energy consumption, 268 liters refrigerator capacity, and 133 liters freezer capacity. For more details, visit sls.gov.sa.

3. SETUP

3.1 Unpacking

Carefully remove all packaging materials, including foam and adhesive tape. Dispose of packaging responsibly. Check the appliance for any damage during transit.

3.2 Placement

- Place the refrigerator on a firm, level floor. Use the adjustable feet to ensure stability and proper door alignment.
- Allow adequate space around the appliance for proper ventilation (at least 10 cm at the back and sides).
- Avoid direct sunlight and heat sources (e.g., stoves, radiators) to ensure optimal performance and energy efficiency.

3.3 Electrical Connection

Connect the refrigerator to a dedicated, grounded power outlet. Ensure the voltage and frequency match the specifications on the rating label of the appliance. Do not use extension cords or multiple socket adapters.

3.4 Initial Cleaning

Before first use, clean the interior and exterior of the refrigerator with a soft cloth and a mild detergent solution. Rinse with clean water and dry thoroughly.

3.5 First Use

After placement and cleaning, allow the refrigerator to stand upright for at least 2-4 hours before plugging it in. This allows the refrigerant to settle. Once plugged in, let it run for several hours (e.g., 4-6 hours) to reach its operating temperature before storing food.

4. OPERATING INSTRUCTIONS

4.1 Temperature Control

Your Haam HM710SSD-O23INV refrigerator features adjustable temperature control. The control panel, typically located inside the fresh food compartment or on the exterior door, allows you to set the desired temperature for both the refrigerator and freezer sections. Refer to the specific markings on your appliance for precise adjustments. The recommended fresh food temperature is between 2°C and 5°C, and the freezer temperature is -18°C or colder.



Image 3: Interior view of the Haam HM710SSD-O23INV refrigerator, showing multiple shelves, door bins, and crisper drawers for organized storage of fresh and frozen items.

4.2 Food Storage Guidelines

- **Fresh Food Compartment:** Store fruits and vegetables in the crisper drawers. Dairy products, cooked foods, and beverages should be placed on shelves. Ensure food is covered to prevent drying out and odor transfer.
- **Freezer Compartment:** Use for long-term storage of frozen foods. Package items tightly to prevent freezer burn. Do not place hot food directly into the freezer.
- **4-Door Design:** The multi-door design allows for better organization and reduces cold air loss when opening specific sections.

4.3 No Frost Technology

This refrigerator is equipped with No Frost technology, which prevents ice build-up in the freezer compartment. This means manual defrosting is not required.

5. MAINTENANCE

5.1 Cleaning

- **Interior:** Clean regularly with a solution of mild detergent and warm water. Avoid abrasive cleaners. Remove shelves and drawers for thorough cleaning.

- **Exterior:** Wipe down with a soft cloth and mild soap. For stainless steel surfaces, use a specialized stainless steel cleaner.
- **Door Seals:** Clean door gaskets regularly to ensure a tight seal. A dirty or sticky gasket can prevent the door from closing properly, leading to energy loss.
- Always unplug the refrigerator before cleaning.

5.2 Power Outage

In case of a power outage, keep the refrigerator doors closed to maintain the internal temperature for as long as possible. Food can remain safely frozen for several hours depending on the ambient temperature and how full the freezer is.

6. TROUBLESHOOTING

Before contacting service, check the following common issues:

Problem	Possible Cause	Solution
Refrigerator is not cooling	Power cord unplugged; temperature setting too high; door not closed properly; poor ventilation.	Check power connection; adjust temperature; ensure doors are sealed; clear obstructions around the appliance.
Unusual noises	Appliance not level; items vibrating inside; compressor noise (normal).	Adjust leveling feet; rearrange items; normal compressor sounds are expected.
Water on floor or inside	Drain tube blocked; door not sealed; high humidity.	Clear drain tube; check door seals; this is normal in high humidity.

If the problem persists after checking these points, please contact qualified service personnel.

7. SPECIFICATIONS

Feature	Detail
Brand	Haam Electric
Model Name	HM710SSD-O23INV
Product Dimensions (Depth x Width x Height)	70 cm x 70 cm x 79.5 cm
Total Net Capacity	Approx. 401 Liters (268L Refrigerator + 133L Freezer)
Fresh Food Capacity	268 Liters
Freezer Capacity	133 Liters
Configuration	Side-by-Side
Color	Silver
Special Feature	Flat Design
Installation Type	Freestanding
Number of Doors	4
Defrost System	No Frost
Finish Type	Stainless Steel
Door Material Type	Stainless Steel
Cooling Method	Compressor

Feature	Detail
Number of Shelves	4
Adjustable Temperature Control	Yes
Door Orientation	Left (for one section, typical for side-by-side)
Convertible Freezer	No
Customizable	No
Electric	Yes
Lock Type	Electronic
Style	Plain
Annual Energy Consumption	390 kWh/year
Energy Efficiency Rating	5 Stars

8. WARRANTY AND SUPPORT

This product comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase or contact the retailer for specific details regarding warranty coverage and duration. For technical support or service inquiries, please contact the authorized Haam Electric service center in your region. Keep your purchase receipt and model information handy when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

