

BEASTCOM Q3-515

BEASTCOM Q3 Essential Gaming PC User Manual

Model: Q3-515

1. INTRODUCTION

This manual provides essential information for the setup, operation, and maintenance of your BEASTCOM Q3 Essential Gaming PC. Please read this manual thoroughly before using your new computer to ensure proper functionality and longevity.

2. SAFETY INFORMATION

- Ensure the computer is placed on a stable, flat surface with adequate ventilation.
- Do not block ventilation openings on the computer case.
- Keep the computer away from direct sunlight, heat sources, and liquids.
- Use only the power supply unit provided with your computer.
- Disconnect the power cable before cleaning or performing any maintenance.
- Avoid opening the computer case unless instructed by support personnel to prevent electric shock or voiding the warranty.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- BEASTCOM Q3 Essential Gaming PC (Q3-515)
- Power Cable
- Keyboard
- Mouse
- Documentation (this manual)

4. SETUP GUIDE

4.1 Unpacking and Placement

Carefully remove the computer from its packaging. Place the PC tower on a flat, stable surface, ensuring sufficient space around the unit for proper airflow.

4.2 Connecting Peripherals

1. **Monitor Connection:** Connect your monitor to the appropriate video output port (HDMI, DisplayPort) on the rear of the PC.
2. **Keyboard and Mouse:** Connect the keyboard and mouse to the available USB ports on the rear or top panel of the PC.
3. **Network Connection:** For wired internet, connect an Ethernet cable to the LAN port on the rear. For wireless internet, ensure the Wi-Fi antenna (if external) is connected or that the internal Wi-Fi is enabled.
4. **Audio Devices:** Connect speakers or headphones to the audio output jacks on the rear or front panel.
5. **Power Connection:** Connect the power cable to the power input on the rear of the PC, then plug the other end into a grounded electrical outlet.





Figure 4.2.1: Rear panel connections for peripherals.



Figure 4.2.2: Top panel with accessible ports and power button.

4.3 Initial Power On

After connecting all necessary peripherals, press the power button located on the top panel of the PC. The system will boot into Windows 11 Pro. Follow the on-screen instructions for initial setup, including language, region, and user account creation.



Figure 4.3.1: Complete PC setup ready for use.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- **To Power On:** Press the power button on the top panel of the PC.
- **To Shut Down:** Click the Start button in Windows, then select Power > Shut down.
- **To Restart:** Click the Start button in Windows, then select Power > Restart.

- **To Sleep:** Click the Start button in Windows, then select Power > Sleep.

5.2 Windows 11 Pro Basics

Your BEASTCOM Q3 PC comes pre-installed with Windows 11 Pro. Familiarize yourself with the operating system's interface, including the Start Menu, Taskbar, and File Explorer. Microsoft provides extensive online resources for learning Windows 11.

5.3 RGB Lighting Control

The BEASTCOM Q3 series features customizable RGB lighting. Control of the RGB lighting is typically managed via a dedicated software application pre-installed on your system or through a physical button/remote control provided with the PC. Refer to the specific RGB controller's instructions for detailed customization options.

6. MAINTENANCE

6.1 Cleaning

- **Exterior:** Use a soft, dry, lint-free cloth to wipe down the exterior of the PC. Avoid abrasive cleaners or solvents.
- **Ventilation:** Periodically inspect and clean the ventilation grilles to prevent dust buildup, which can impede airflow and cause overheating. Use compressed air to gently clear dust from vents.

6.2 Software Updates

Regularly update your Windows 11 operating system and device drivers to ensure optimal performance, security, and compatibility. Windows Update can be accessed via Settings > Windows Update.

7. TROUBLESHOOTING

If you encounter issues with your BEASTCOM Q3 PC, refer to the following common solutions:

Problem	Possible Solution
PC does not power on	Ensure the power cable is securely connected to both the PC and the wall outlet. Verify the power outlet is functional.
No display on monitor	Check that the monitor is powered on and correctly connected to the PC's video output. Try a different video cable or port if available.
Slow performance	Close unnecessary applications. Check for background processes consuming resources. Ensure Windows and drivers are up to date. Verify sufficient free storage space.
Wi-Fi not working	Check Wi-Fi settings in Windows. Ensure Wi-Fi is enabled. Restart your router. Update Wi-Fi drivers.
Peripherals (keyboard/mouse) unresponsive	Try connecting the peripheral to a different USB port. Ensure drivers are installed (Windows usually handles this automatically).

If these steps do not resolve your issue, please contact BEASTCOM customer support.

8. SPECIFICATIONS

Key technical specifications for the BEASTCOM Q3 Essential Gaming PC (Model: Q3-515):

Component	Detail
Processor	AMD Ryzen 7 8X 4.60GHz (16 Threads)
Graphics	Integrated Vega Radeon Graphics (8 GB RAM)
RAM	16 GB DDR4 (800 MHz Memory Speed)
Storage	1 TB SSD
Operating System	Windows 11 Pro
Max Screen Resolution	3840 x 2160 pixels
Connectivity	HDMI, WiFi, USB ports (various types)
Item Weight	19.16 pounds
Dimensions (L x W x H)	19.75 x 17.25 x 10.5 inches (Package)



Figure 8.1: Internal components of the BEASTCOM Q3 PC.

9. WARRANTY AND SUPPORT

9.1 Warranty Information

Your BEASTCOM Q3 Essential Gaming PC comes with a **1-year all-in warranty**. Additionally, BEASTCOM offers a **30-day free replacement** for any PC causing problems or not starting as expected after delivery.

9.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your BEASTCOM product, please contact our support team:

- **Email:** support@beastcom.eu
- **Website:** www.beastcom.eu