

LivePure LP500APHTR

LivePure LP500 Clean Heat Air Purifier & Electric Heater User Manual

1. INTRODUCTION

Thank you for choosing the LivePure LP500 3-in-1 Clean Heat Air Purifier & Electric Heater. This device combines an air purifier, fan, and electric heater into a single unit, designed to enhance your indoor environment. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your new appliance. Please read all instructions carefully before operation and retain this manual for future reference.

2. IMPORTANT SAFETY INFORMATION

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. Read all instructions before using this heater.

- Do not use this heater with a damaged cord or plug, or after the heater malfunctions, has been dropped or damaged in any manner.
- Do not use outdoors.
- This heater is not intended for use in bathrooms, laundry areas, and similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect heater, turn controls to OFF, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or

relocatable power tap (outlet/power strip).

- This heater includes an automatic tip-over safety switch that shuts off the unit if it is accidentally knocked over.


3. PACKAGE CONTENTS

- LivePure LP500 3-in-1 Clean Heat Air Purifier & Electric Heater
- Remote Control
- User Manual

4. PRODUCT OVERVIEW

Familiarize yourself with the components and controls of your LivePure LP500 unit.

Control Panel and Indicators



This image illustrates the control panel of the LivePure LP500. Key features include the On/Off Power button, Fan Speed & Sleep Mode button, Heating Mode button, Accent Light button, Timer button, Rotation Mode button, and Filter Indicator Light. These controls allow you to manage all functions of the device.

Air Purification Capabilities

The image features a central black and silver LivePure LP500 air purifier. The device has a digital display at the top showing '79°'. Below the display is a large vertical grille. At the bottom, there is a silver-colored circular grille. The LivePure logo is visible on the front panel. Surrounding the purifier are six circular icons, each with a purple border and a green center, representing different air purification capabilities: Smoke & Odors (top left), Pollen (top right), Household Dust (middle left), Mold Spores (middle right), Pet Hair & Dander (bottom left), and Bacteria (bottom right). At the bottom center of the image is the LivePure logo, which consists of a stylized blue and green wave icon followed by the text 'LivePure®'.

The LivePure LP500 is designed to address various airborne particles and odors. This image highlights its effectiveness against smoke & odors, pollen, household dust, mold spores, pet hair & dander, and bacteria, contributing to cleaner indoor air.

Key Functions

Functions

- + Powerful Air Purifier and Heater
- + Low, High, Auto Heat Modes
- + Remote Included
- + Space-Saving Design



This image summarizes the primary functions of the LivePure LP500: it acts as a powerful air purifier and heater, offers Low, High, and Auto heat modes, includes a remote control for convenience, and features a space-saving design suitable for various room sizes.

5. SETUP

1. **Unpacking:** Carefully remove the unit from its packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the unit on a firm, level surface. Ensure there is at least 12 inches (30 cm) of clear space around the unit to allow for proper airflow. Do not place the unit directly under a power outlet.
3. **Power Connection:** Plug the power cord directly into a 120V AC, 60Hz electrical outlet. Do not use extension cords or power strips.
4. **Initial Use:** The unit is ready for operation once plugged in.

6. OPERATING INSTRUCTIONS

The LivePure LP500 can be operated using the control panel on the unit or the included remote control.

Power On/Off

- Press the **On/Off** button once to turn the unit on. The unit will start in fan mode.
- Press the **On/Off** button again to turn the unit off.

Fan Speed Adjustment

- Press the **Fan Speed** button repeatedly to cycle through Low, Medium, High, and Turbo fan speeds.
- The corresponding indicator light on the display will illuminate.

Heat Modes

- Press the **Heating Mode** button to activate the heating function.
- Press repeatedly to cycle through Low Heat, High Heat, and Auto Heat modes.
- The unit will display the current temperature setting.

Rotation Mode

- Press the **Rotation** button to activate oscillation, distributing air across a wider area.
- Press again to stop oscillation.

Timer Function

- Press the **Timer** button to set the operating duration.
- Each press will increase the timer by 1 hour, up to a maximum of 8 hours. The unit will automatically turn off once the set time expires.

Accent Light

- Press the **Accent Light** button to turn the ambient light on or off.

Remote Control

The remote control provides access to all functions available on the main control panel. Ensure the remote has working batteries and is pointed towards the unit for effective operation.


7. FILTRATION SYSTEM

The LivePure LP500 utilizes a 2-stage filtration system to purify the air.

2 Stage Filtration

Coconut Carbon Pre-Filter

The pre-filter captures large particles, such as dust, pet dander, and pollen, from the air before they reach the HEPA filter. Carbon pre-filter also helps reduce odors from the air caused by cooking, smoking, and pets.



True HEPA Filter

H13 True HEPA filter removes up to 99.97% of airborne particles as small as 0.3 microns - smoke, dust, pollen, pet hair and dander, mold spores and dust mites.



This image details the two stages of filtration: the Coconut Carbon Pre-Filter and the True HEPA Filter.

- **Coconut Carbon Pre-Filter:** This filter captures larger particles such as dust, pet dander, and pollen before they reach the HEPA filter. It also helps reduce odors from cooking, smoking, and pets.
- **H13 True HEPA Filter:** This filter removes up to 99.97% of airborne particles as small as 0.3 microns, including smoke, dust, pollen, pet hair, dander, mold spores, and dust mites.

8. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your unit.

Filter Replacement

The Filter Indicator Light will illuminate when it is time to replace the filter. Filter life varies depending on usage and air quality.

1. Unplug the unit from the power outlet.
2. Locate the filter compartment, typically at the base of the unit.
3. Open the compartment and remove the old filter.
4. Insert a new LivePure LP500 replacement filter, ensuring it is correctly oriented.

5. Close the filter compartment securely.
6. Plug the unit back in. To reset the filter indicator, press and hold the Filter Indicator button for 3-5 seconds until the light turns off.

Cleaning the Unit

- Always unplug the unit before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Use a vacuum cleaner with a brush attachment to gently clean the air intake and exhaust vents.
- Do not allow water to enter the internal components.

Storage

If storing the unit for an extended period, unplug it, clean it thoroughly, and store it in a cool, dry place, preferably in its original packaging.

9. TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Unit does not turn on.	No power supply; Unit tipped over; Power cord not fully plugged in.	Check power outlet; Ensure unit is upright on a flat surface; Plug power cord firmly into outlet.
No heat output.	Heating mode not selected; Temperature setting too low.	Press the Heating Mode button to select a heat setting; Increase the desired temperature.
Weak airflow or purification.	Filter is dirty or clogged; Air intake/exhaust blocked.	Replace the filter; Ensure no obstructions around air vents.
Unit makes unusual noise.	Foreign object inside; Unit not on a level surface.	Unplug and inspect for foreign objects (if safe); Place unit on a stable, level surface.
Remote control not working.	Batteries are dead; Obstruction between remote and unit.	Replace remote control batteries; Ensure clear line of sight to the unit.

If the problem persists after attempting these solutions, please contact customer support.

10. SPECIFICATIONS

Detailed technical specifications for the LivePure LP500.

- **Model Number:** LP500APHTR
- **Product Dimensions:** 8.38"D x 8.38"W x 24.5"H (21.3 cm D x 21.3 cm W x 62.2 cm H)
- **Item Weight:** 9.37 Pounds (4.25 kg)
- **Power Source:** Corded Electric
- **Voltage:** 120V AC, 60Hz

- **Filter Type:** H13 True HEPA with Coconut Carbon Pre-Filter
- **Coverage Area:** Up to 400 sq ft

Coverage and Air Exchange



This image indicates that the LivePure LP500 can clean the air in rooms up to 400 sq ft, exchanging the air 28 times per day under optimal conditions.

Unit Dimensions

Elegant & Efficient



a 400 sq. ft. room



28 times per day



This image provides a visual representation of the unit's dimensions, showing a height of 28.9 inches and a base width of 11.1 inches.

Room Size Chart

LivePure LP500APHTR 3-in-1 Clean Heat Air Purifier/Heater

Room Size Chart

This chart indicates how many times per hour the air purifier exchanges the air within a room.



This chart illustrates the approximate air exchange rates per hour for different room sizes (assuming an 8-foot ceiling height). For example, a 10'x15' bedroom has an exchange rate of 3.2 times per hour, while a 20'x20' living room has an exchange rate of 1.2 times per hour.

11. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official LivePure website. Please have your model number (LP500APHTR) and purchase date available when contacting support.