

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Polly Pocket](#) /
- › [Polly Pocket Lil' Styles Travel Toy Collection Playset HRD64 - Instruction Manual](#)

Polly Pocket HRD64

Polly Pocket Lil' Styles Travel Toy Collection Playset

MODEL: HRD64

Introduction

This instruction manual provides essential information for the Polly Pocket Lil' Styles Travel Toy Collection Playset, Model HRD64. It covers unboxing, setup, play instructions, maintenance, and product specifications to ensure a complete and enjoyable experience. This playset offers a unique multi-layer unboxing experience, revealing a 3-inch doll, surprise accessories, and a water reveal feature.

What's Included

Each Polly Pocket Lil' Styles Travel Toy Collection Playset includes the following components:

- One (1) Themed Compact Playset
- One (1) 3-inch Doll
- Seven (7) Surprise Accessories
- One (1) Dissolvable Paper Bag for Water Reveal





Image: The product packaging, illustrating the compact, doll, and accessories included, along with a "4+" age recommendation and a warning about small parts.



Image: A visual representation of three distinct Polly Pocket Lil' Styles compact designs, each paired with a unique 3-inch doll, demonstrating the variety available in the collection.

Setup and Unboxing

Follow these steps to unbox and set up your Polly Pocket Lil' Styles Playset:

1. **Open the Packaging:** Carefully remove the playset from its outer packaging.
2. **Unveil the Compact:** The playset features a multi-layer unboxing experience. Open the adorable exterior of the compact to reveal the play area and closet space.
3. **Locate the Doll and Accessories:** Inside the compact, you will find the 3-inch doll and a dissolvable paper bag containing surprise accessories.
4. **Perform the Water Reveal:** To discover the hidden fashions, place the dissolvable paper bag into a small container of water. Swirl the bag gently until it dissolves, revealing the surprise accessories.



Swirl the dissolvable bag in water to reveal accessories.

Image: A hand demonstrating the water reveal process, showing a dissolvable bag being swirled in a glass of water, with a doll and revealed accessories (top, skirt, shoes) nearby.

Operating and Play

Once unboxed, the Polly Pocket Lil' Styles Playset offers various play possibilities:

- **Explore the Playset:** The compact opens to a themed play area. Utilize the built-in features and designs for imaginative play scenarios.
- **Dress the Doll:** Use the revealed accessories to dress and style your 3-inch doll. The compact includes closet space for storing doll clothing and accessories.
- **Mix and Match:** Combine different fashion accessories to create unique looks for your doll.
- **On-the-Go Fun:** The compact design allows for easy portability, enabling play anywhere.



Collect them all!

Image: A collection of open Polly Pocket Lil' Styles compacts, each revealing a unique themed play area, a 3-inch doll, and various fashion accessories, encouraging collection and diverse play.





Image: A hand holding a closed Polly Pocket Lil' Styles compact, shaped like a pink milk carton with strawberries, highlighting its compact size and portability for travel.

Maintenance and Care

To ensure the longevity of your Polly Pocket playset, follow these care instructions:

- **Cleaning:** Wipe the compact and doll with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Drying:** Ensure all parts are completely dry before closing the compact or storing.
- **Storage:** Store the playset in a clean, dry place away from direct sunlight and extreme temperatures.
- **Small Parts:** Keep all small accessories contained within the compact or a designated storage area to prevent loss.

Troubleshooting

If you encounter any issues with your playset, consider the following:

- **Accessories Not Revealing:** Ensure the dissolvable paper bag is fully submerged in water and given sufficient time to dissolve. Gentle swirling can assist the process.
- **Compact Not Closing Properly:** Check for any accessories or doll parts obstructing the closing mechanism. Ensure all items are correctly placed within the designated storage areas.

Specifications

Model Number	HRD64
Product Dimensions	1.31 x 3.5 x 4.5 inches (3.33 x 8.89 x 11.43 cm)
Item Weight	3.89 ounces (110.28 grams)
Manufacturer	Mattel Shop
Recommended Age	4 years and up



Image: A side profile of a Polly Pocket Lil' Styles compact, illustrating its height (6.7 inches / 170 mm) and width (4.0 inches / 107 mm) for reference.

Safety Information

Please observe the following safety guidelines:




- **Choking Hazard:** This product contains small parts and is not suitable for children under 3 years of age.
- **Adult Supervision:** Adult supervision is recommended during play, especially during the water reveal process.
- **Intended Use:** Use this product only as intended for play. Do not ingest any parts or accessories.




Warranty and Support

For product support, inquiries, or information regarding warranty, please contact the manufacturer, Mattel Shop. Refer to the product packaging for specific contact details or visit the official Mattel website.
Manufacturer: **Mattel Shop**
Website: www.mattel.com (General Mattel website for support)

© 2025 Polly Pocket. All rights reserved. This manual is for informational purposes only.

Related Documents - HRD64

	<p>Alwyn Home Boxed Pocket Spring Mattress User Manual and Warranty Information</p> <p>Comprehensive guide for Alwyn Home boxed pocket spring mattresses, covering unboxing, cleaning, maintenance, and limited warranty policy. Includes instructions for setup and care.</p>
	<p>Chicco Polly Magic Relax High Chair User Manual</p> <p>Comprehensive instructions for the Chicco Polly Magic Relax high chair, covering assembly, usage, safety, cleaning, and maintenance for both the high chair and recliner modes.</p>
	<p>Chicco Polly Highchair Owner's Manual: Assembly, Use, and Care</p> <p>Comprehensive owner's manual for the Chicco Polly Highchair, providing detailed instructions on assembly, safe usage, adjustments, cleaning, and maintenance. Learn how to use the safety harness, adjust height and recline, and store the highchair.</p>

	<p>How to Use the Galaku WAVE Masturbation Cup</p> <p>Step-by-step instructions and advanced usage tips for the Galaku WAVE masturbation cup. This guide details how to prepare, use, and control the device for optimal experience, replacing visual aids with clear textual descriptions.</p>
	<p>VTech Console Magi'Pocket Gabby's Dollhouse User Manual</p> <p>User manual for the VTech Console Magi'Pocket, featuring Gabby's Dollhouse. Learn how to set up, play games, and maintain your Magi'Pocket console.</p>
	<p>TravelArim Carry-On Luggage and Cosmetic Bag: Features, Dimensions, and TSA Lock Instructions</p> <p>Detailed overview of the TravelArim carry-on luggage and cosmetic bag, including features, material, dimensions, available colors, and step-by-step instructions for the TSA lock.</p>

Documents - Polly Pocket – HRD64

no relevant documents