

[Manuals.plus](#) /

> [NineSky](#) /

> NineSky Dehumidifier User Manual

## NineSky h3

# NineSky Dehumidifier User Manual

Model: h3

## IMPORTANT SAFETY INSTRUCTIONS

---

Please read all instructions carefully before operating the dehumidifier. Keep this manual for future reference.

- Ensure the dehumidifier is placed on a stable, level surface.
- Do not block the air inlet or outlet. Maintain at least 8 inches (20 cm) clearance from walls or furniture.
- Do not operate the unit with a damaged power cord or plug.
- Always unplug the dehumidifier before cleaning or performing any maintenance.
- Do not immerse the unit, power cord, or plug in water or other liquids.
- This appliance is for indoor use only.
- Keep out of reach of children and pets.

## PRODUCT OVERVIEW

---

The NineSky Dehumidifier (Model h3) is designed to efficiently remove excess moisture from your indoor environment, improving air quality and preventing issues like mold, mildew, and musty odors. It features semiconductor condensation technology for quiet operation and includes an auto shut-off function when the water tank is full.



Figure 1: Front view of the NineSky Dehumidifier, showing the control panel and visible water tank.

### Key Components:

- **Control Panel:** On/Off button, Full indicator, Running indicator, Light control.
- **Water Tank:** 70 oz (2.07 L) capacity, transparent for easy monitoring.
- **Air Inlet/Outlet:** Located on the back and top of the unit for air circulation.
- **Power Cord:** For connecting to an electrical outlet.
- **Handle:** Built-in for easy portability.



Figure 2: Exploded view showing the dual semiconductor dehumidification system and the 70oz water tank.

## SPECIFICATIONS

Feature	Detail
Brand	NineSky
Model Name	h3

Coverage Area	Up to 800 sq.ft
Water Tank Capacity	70 oz (approx. 2.07 Liters)
Moisture Removal	Up to 27 oz/D (at 30°C, 80% RH)
Product Dimensions (L x W x H)	9.1" x 5.4" x 12.5" (approx.)
Item Weight	6.47 pounds
Special Features	Auto Shutoff, 5 Colors LED Light, Sleep Mode
Operation Mode	Sleep
Material	Plastic

*Note: Dimensions are approximate and may vary slightly.*

## SETUP

---

- Unpacking:** Carefully remove the dehumidifier from its packaging. Retain packaging materials for future storage or transport.
- Placement:** Place the unit on a firm, level surface in the desired location. Ensure there is at least 8 inches (20 cm) of clear space around all sides of the dehumidifier to allow for proper airflow. Avoid placing it directly against walls or furniture. This dehumidifier is suitable for living rooms, bedrooms, basements, bathrooms, and closets.
- Power Connection:** Plug the power cord into a standard electrical outlet. Ensure the voltage matches the specifications of the unit.
- Water Tank:** Ensure the water tank is correctly seated in the unit. The unit will not operate if the tank is not properly installed or is full.

# Auto Shut Off Protection




Figure 3: Example of proper placement in a living room, ensuring adequate space for air circulation.

## OPERATION

### Power On/Off:

- To turn the dehumidifier **ON**, press the **ON/OFF** button on the control panel. The running indicator light will illuminate.
- To turn the dehumidifier **OFF**, press the **ON/OFF** button again.

# Widely Used in Various Indoor Places



Living Room



Bedroom



Bathroom



Basement



Cloak Room



Rv

Figure 4: Detailed view of the control panel, showing the On/Off button and indicator lights.

## Auto Shut-off Function:

The dehumidifier is equipped with an automatic shut-off feature. When the water tank is full or not properly positioned, the unit will automatically turn off. The **FULL** indicator light will turn red, and an alarm beep will sound to alert you to empty the water tank.

# Solving Dampness Problems for Healthier Living



Figure 5: Illustration of the dehumidifier in normal operation (blue light) and with a full water tank (red light and alarm).

## 5 Colorful LED Lights:

Upon powering on, the LED light will automatically illuminate. You can change the color of the light by gently touching the metal ring on the control panel for 2 seconds. Continue touching to cycle through the available colors: Blue (Default), Purple, Orange, Changing Colorful Lights, and Light Off. You can choose to turn the light off completely if desired.

# Light Control Metal Ring



Figure 6: Diagram showing the light control metal ring and available LED light colors.

## MAINTENANCE

### Emptying the Water Tank:

When the water tank is full, the dehumidifier will automatically shut off, the **FULL** indicator will turn red, and an alarm will sound. To empty the tank:

1. Gently pull out the water tank from the front of the unit.
2. Carefully remove the lid of the water tank.
3. Pour out the collected water.
4. Replace the lid and slide the empty water tank back into the dehumidifier until it clicks into place. Ensure it is securely seated to resume operation.



Figure 7: Step-by-step guide for emptying and reinserting the water tank.

### Cleaning the Dehumidifier:

- Always unplug the unit before cleaning.
- Wipe the exterior of the dehumidifier with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Clean the water tank regularly with mild soap and water to prevent mold and mildew growth. Rinse thoroughly and dry before reinserting.
- Periodically check the air inlet and outlet for dust accumulation. Use a soft brush or vacuum cleaner attachment to gently remove any dust.

### TROUBLESHOOTING

If you encounter issues with your NineSky Dehumidifier, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Dehumidifier does not turn on.	No power supply; Water tank full or improperly seated.	Check if the power cord is securely plugged into a working outlet. Empty the water tank and ensure it is correctly reinserted.
Dehumidifier is running but not collecting water.	Humidity level is already low; Room temperature is too low; Air inlets/outlets are blocked.	Ensure the room humidity is above 48-60%. The unit operates best in temperatures above 50°F (10°C). Clear any obstructions from the air inlets and outlets.
Unit is making unusual noise.	Unit is not on a level surface; Internal component issue.	Ensure the dehumidifier is placed on a flat, stable surface. If the noise persists, contact customer support.
Full indicator light remains on after emptying tank.	Water tank not properly reinserted; Sensor malfunction.	Remove and reinsert the water tank, ensuring it is fully seated. If the issue continues, unplug the unit for 5 minutes and plug it back in. If the problem persists, contact customer support.

### WARRANTY AND SUPPORT

NineSky products are manufactured with high-quality materials and craftsmanship. For specific warranty details regarding

your NineSky Dehumidifier (Model h3), please refer to the warranty card included in your product packaging or visit the official NineSky website. Protection plans may also be available for extended coverage.

For technical assistance, troubleshooting beyond this manual, or general inquiries, please contact NineSky Customer Support:

- **Online Support:** Visit the [NineSky Store on Amazon](#) for FAQs and product information.
- **Email Support:** Refer to your product packaging or the official NineSky website for the most current email contact information.