Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > Retevis /
- > Retevis CP185 CP200D Covert Acoustic Tube Earpiece Instruction Manual

Retevis FC9257BX6

Retevis Covert Acoustic Tube Earpiece Instruction Manual

Model: FC9257BX6

INTRODUCTION

This manual provides detailed instructions for the proper use and maintenance of your Retevis Covert Acoustic Tube Earpiece. Designed for clear and discreet communication, this earpiece is compatible with various Motorola two-way radios. Please read this manual thoroughly before operating the device to ensure optimal performance and longevity.

KEY FEATURES

- Kevlar Reinforced Cable: Engineered for durability, providing extended service life and resistance to wear.
- **Electromagnetic Speaker:** Delivers clear sound quality and minimizes audio distortion, ensuring realistic reception even in noisy environments.
- **Volume Adjustment:** Features an integrated volume control for convenient adjustment of reception levels, ideal for varying ambient noise.
- Coiled Cable Design: Reduces tangling and offers flexibility in length, extending up to 88cm (35 inches) for comfortable use.
- M-Head 2-Pin Connector: Ensures broad compatibility with specified Motorola two-way radios.
- Push-to-Talk (PTT) Button: A full-size PTT button allows for accurate and easy operation, even when wearing gloves.
- **Detachable Acoustic Tube:** The 180° rotatable acoustic tube is easy to remove, clean, and replace, promoting hygiene and comfort.

PACKAGE CONTENTS

The package includes the following items:

- 6 x Retevis Covert Acoustic Tube Earpieces
- 6 x Spare Earbuds




Figure 1: Package Contents - Six earpieces and six spare earbuds are included.

DEVICE COMPATIBILITY

This earpiece is equipped with an M-head 2-pin connector and is compatible with a wide range of Motorola two-way radios, including but not limited to:

- Motorola CP185, CP100, CP100D, CP200, CP200D
- Motorola GP300, GP2000, BRP40, A8
- Motorola RMU2040, RMU2080, RMU2080D, RDU4100, RDU4160D, RDM2070D, RMV2080

- Motorola DTR550, DTR650, DTR700, DLR1020
- HYT TC610
- Motorola Mag One series

Note: This earpiece is not compatible with any Retevis brand walkie-talkies.



Figure 2: Earpiece with M-Head 2-Pin Connector.

SETUP INSTRUCTIONS

1. Prepare the Earpiece:

The acoustic tube is designed to be detachable for cleaning and replacement. To attach or detach, gently twist and pull the tube from the earpiece base. Ensure it is securely reattached before use.




Figure 3: Detaching and Reattaching the Acoustic Tube.

2. Wear the Earpiece:

Place the acoustic tube into your ear. The earpiece is designed for comfortable wear on either the left or right ear. Adjust the clear acoustic tube for a secure and comfortable fit.




Figure 4: Comfortable Earpiece Fit.

3. Connect to Radio:

Insert the M-head 2-pin connector firmly into the corresponding port on your compatible two-way radio. Ensure a snug connection for optimal audio transmission and reception.

OPERATING INSTRUCTIONS

1. Adjust Volume:

Use the integrated volume adjustment switch on the earpiece cable to set the desired listening volume. This allows for clear reception in various environments without needing to access the radio's controls.



Figure 5: Volume Adjustment Control.

2. Use Push-to-Talk (PTT):

To transmit, press and hold the large PTT button located on the earpiece cable. Speak clearly into the microphone. Release the button to stop transmitting and return to receive mode. The PTT button is designed for easy activation, even with gloved hands.



Figure 6: Push-to-Talk (PTT) Button.

MAINTENANCE

- Cleaning the Acoustic Tube: Regularly detach and clean the acoustic tube with a mild soap and water solution. Rinse thoroughly and allow to air dry completely before reattaching.
- **Replacing Earbuds:** For hygiene and optimal comfort, replace the earbud periodically. Spare earbuds are included in the package.




Figure 7: Replacing the Earbud.

• Cable Care: Avoid sharp bends or excessive pulling on the cable to prevent damage to the Kevlar reinforcement. The coiled section helps manage cable length and reduce stress.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound from earpiece.	Loose connection, radio volume too low, earpiece faulty.	Ensure the 2-pin connector is fully inserted. Increase radio volume. Test with another earpiece if available.
Unclear or distorted sound.	Acoustic tube blockage, loose connection, radio interference.	Clean the acoustic tube. Re-seat the connector. Move away from potential interference sources.
PTT button not transmitting.	Loose connection, PTT button malfunction.	Check the 2-pin connector. Ensure the PTT button is fully pressed.

SPECIFICATIONS

Feature	Detail
Model Number	FC9257BX6
Connector Type	M-Head 2-Pin
Cable Material	Kevlar Reinforced
Cable Length (Coiled)	Up to 88 cm (35 inches)
Speaker Type	Electromagnetic
Special Features	Volume Adjustment, Detachable Acoustic Tube, Large PTT Button
Product Dimensions	8.62 x 6.18 x 1.89 inches
Item Weight	11.1 ounces

OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video 1: Retevis Covert Acoustic Tube Earpiece Overview. This video demonstrates the features and usage of the earpiece, including its comfortable design, detachable tube, volume control, PTT key, M 2-pin connector, coiled cable, and Kevlar reinforced cable for durability.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your purchase or visit the official Retevis website. Keep your purchase receipt for warranty claims.

© 2024 Retevis. All rights reserved.

Related Documents - FC9257BX6



Retevis RT628 Kids Walkie Talkie User's Guide

User's guide for the Retevis RT628 Kids Walkie Talkie, covering setup, operation, features, safety information, and specifications. Includes instructions for installation, volume control, channel setting, special features like VOX and call tones, and safety precautions.

