

[manuals.plus](#) /

› [Mazda](#) /

› [Mazda Side Seat \(L\) Rear Buttk G06B57550C68 Instruction Manual](#)

Mazda G06B57550C68

Mazda Side Seat (L) Rear Buttk - Instruction Manual

Model: G06B57550C68 | Brand: Mazda

PRODUCT OVERVIEW

This manual provides detailed instructions for the installation, operation, and maintenance of the Genuine Mazda Side Seat (L) Rear Buttk, part number G06B57550C68. This component is designed as a genuine replacement part for specific Mazda models, including Attensa, Capella, and MAZDA6. Please read this manual thoroughly before attempting installation or use to ensure proper function and safety.

PRODUCT IMAGE



Image of the Mazda G06B57550C68 Side Seat (L) Rear Buttk. The image displays the Mazda brand name and the part number G06B57550C68, indicating it is a genuine Mazda replacement part.

SETUP AND INSTALLATION

The Mazda Side Seat (L) Rear Buttk (G06B57550C68) requires assembly and professional installation is recommended. Ensure you have the necessary tools and safety equipment before proceeding.

- Preparation:** Park the vehicle on a level surface and engage the parking brake. Turn off the engine and disconnect the negative terminal of the vehicle's battery to prevent electrical hazards.
- Access:** Carefully remove any existing seat components or trim panels that obstruct access to the installation area for the rear side seat. Refer to your vehicle's specific service manual for precise instructions on trim removal.
- Mounting:** Align the new Side Seat (L) Rear Buttk with the designated mounting points in the vehicle. Secure the component using the appropriate fasteners (not included, typically reused from original part or specified by Mazda). Ensure all bolts are tightened to the manufacturer's torque specifications.
- Connections:** If applicable, connect any electrical harnesses or seatbelt anchors to the new component. Ensure all connections are secure and properly routed.
- Reassembly:** Reinstall any removed trim panels or seat components. Reconnect the vehicle's battery.
- Verification:** Test the functionality of the newly installed seat component, including seatbelt operation and any integrated features, before driving the vehicle.

Note: This part is designed for specific Mazda models: Attensa, Capella, and MAZDA6. Verify compatibility with your vehicle's VIN before installation.

OPERATING INSTRUCTIONS

As a fixed seat component, the Mazda Side Seat (L) Rear Buttk does not have active operational controls. Its primary function is to provide structural support and seating for passengers. Ensure that seatbelts are properly fastened and adjusted for all occupants using this seat.

- Passenger Seating:** This component is designed for one passenger. Ensure the passenger is seated correctly and comfortably.
- Seatbelt Usage:** Always ensure that the vehicle's seatbelt is properly routed and buckled when a passenger is occupying this seat.
- Folding/Adjustments:** If your vehicle's original seat had folding or reclining features, ensure the new component integrates correctly with these mechanisms. Refer to your vehicle's owner's manual for specific seat adjustment instructions.

MAINTENANCE AND CARE

Proper maintenance will extend the lifespan of your Mazda Side Seat (L) Rear Buttk and ensure continued safety and comfort.

- Cleaning:** Regularly clean the seat surface with a soft, damp cloth and a mild automotive interior cleaner. Avoid harsh chemicals or abrasive materials that could damage the fabric or finish.
- Inspection:** Periodically inspect the seat for any signs of wear, tear, loose stitching, or damage to the frame or mounting points. Check that all fasteners remain tight.
- Spills:** Clean spills immediately to prevent staining. Blot liquids with a clean cloth and follow with appropriate cleaning agents for the seat material.
- Avoid Overloading:** Do not place excessive weight on the seat or use it for purposes other than passenger seating.

TROUBLESHOOTING

This section addresses common issues you might encounter with the Mazda Side Seat (L) Rear Buttk.

Problem	Possible Cause	Solution
Seat feels loose or wobbly after installation.	Mounting bolts are not sufficiently tightened.	Re-tighten all mounting bolts to the vehicle manufacturer's specified torque. If the issue persists, inspect mounting points for damage.
Difficulty with seatbelt latching or retraction.	Seatbelt mechanism obstructed or misaligned during installation.	Inspect the seatbelt path and ensure no fabric or components are obstructing its operation. Verify the seatbelt anchor is correctly installed.
Unusual noises (squeaks, rattles) from the seat.	Loose fasteners or improper fitment.	Check all fasteners for tightness. Ensure all trim pieces are securely snapped into place. If noises persist, professional inspection may be required.

If you encounter issues not listed here or if solutions do not resolve the problem, it is recommended to consult a certified Mazda service technician.

SPECIFICATIONS

Manufacturer	Mazda
Brand	Mazda
Model	Seat (Side Seat (L) Rear Buttk)
Product Dimensions	40 x 30 x 15 cm
Item Model Number	G06B57550C68
Manufacturer Part Number	G06B57550C68
Assembly Required	Yes
Item Weight	8 kg
ASIN	B0CNGFVHS8
Date First Available	22 November 2023


WARRANTY AND SUPPORT

As a genuine Mazda part, this component is typically covered by Mazda's standard parts warranty. Please refer to your original purchase documentation or contact your authorized Mazda dealer for specific warranty terms and conditions, as these may vary by region and purchase date.

For technical support, installation assistance, or to report any issues with this genuine Mazda part, please contact your local authorized Mazda service center or visit the official Mazda website for customer service contact information.

- **Official Mazda Website:** www.mazda.com (Please select your region for localized support)
- **Authorized Mazda Dealer:** Locate your nearest dealer for professional assistance.

Related Documents - G06B57550C68

	<p>Mazda6 Smart Start Guide: Features and Operation</p> <p>Explore the key features and functions of the Mazda6 with this Smart Start Guide. Learn about infotainment, safety systems, driving aids, and more for a quick and accessible overview.</p>
	<p>Mazda6 Owner's Manual: Your Guide to Driving Pleasure and Safety</p> <p>Explore the comprehensive owner's manual for the Mazda6. Discover essential safety features, operational guides, maintenance tips, and the 'Zoom-Zoom' driving philosophy from Mazda.</p>
	<p>2011 Mazda6 Owner's Manual: Features, Safety, and Operation Guide</p> <p>Comprehensive owner's manual for the 2011 Mazda6, covering vehicle features, essential safety equipment, operation, maintenance, and security systems. Learn how to use your Mazda safely and effectively.</p>
	<p>Mazda Navigation System User Manual: Operation, Features, and Safety</p> <p>Comprehensive guide to the Mazda Navigation System. Learn about setup, routing, voice control, Bluetooth, audio integration, safety precautions, and troubleshooting for your Mazda vehicle.</p>
	<p>2020 Mazda6 Owner's Manual</p> <p>This owner's manual provides comprehensive information for operating, maintaining, and ensuring the safety of your 2020 Mazda6. Mazda is dedicated to customer satisfaction, ensuring an enjoyable and trouble-free driving experience.</p>
	<p>2016 Mazda6 Owner's Manual</p> <p>Comprehensive guide for operating and maintaining the 2016 Mazda6, including safety features, driving instructions, and specifications.</p>

