

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ZGZUXO](#) /

› **ZGZUXO Air Hose Instruction Manual for Tire Inflator Models CZK-3691 and CZK-3640**

ZGZUXO CZK-3691, CZK-3640

ZGZUXO Air Hose Instruction Manual

FOR TIRE INFLATOR MODELS CZK-3691 AND CZK-3640

1. Introduction

This manual provides essential instructions for the proper use, setup, and maintenance of your ZGZUXO Air Hose. This air hose is designed as a replacement or accessory for ZGZUXO Tire Inflator Models CZK-3691 and CZK-3640. Please read this manual thoroughly before use to ensure safe and efficient operation.

2. Product Overview

The ZGZUXO Air Hose is constructed from durable Polyvinyl Chloride (PVC) and Rubber, designed for reliable performance with compatible ZGZUXO tire inflators. It features a quick-connect chuck for tire valves and a threaded connector for the inflator unit.



An image showing the ZGZUXO air hose. One end features a silver-colored quick-connect chuck with a lever for attaching to a tire valve. The other end has an orange threaded connector for attaching to a compatible ZGZUXO tire inflator. The hose itself is black and braided, forming a U-shape.

3. Setup

- 1. Connecting to the Inflator:** Locate the air outlet port on your ZGZUXO Tire Inflator (Models CZK-3691 or CZK-3640). Screw the orange threaded end of the air hose clockwise onto the inflator's air outlet until it is securely tightened. Ensure there are no gaps to prevent air leakage.
- 2. Connecting to the Tire Valve:** Remove the dust cap from the tire valve stem. Push the quick-connect chuck (silver end) firmly onto the tire valve stem. Press down the lever on the chuck to lock it in place. Ensure a secure connection to prevent air loss during inflation.

4. Operating Instructions

Once the air hose is securely connected to both the inflator and the tire valve, you can proceed with tire inflation according to your ZGZUXO Tire Inflator's specific operating instructions. Always refer to your vehicle's manufacturer recommendations for correct tire pressure.

- **Inflation:** Activate your ZGZUXO tire inflator. Monitor the pressure gauge on your inflator.
- **Disconnection:** Once the desired pressure is reached, turn off the inflator. Lift the lever on the quick-connect chuck to release it from the tire valve. Quickly remove the chuck from the valve stem and replace the tire valve dust cap.
- **Storage:** Disconnect the air hose from the inflator by unscrewing the orange threaded end counter-clockwise. Store the air hose in a clean, dry place, away from direct sunlight and extreme temperatures.

5. Maintenance

- **Cleaning:** Wipe the air hose with a damp cloth to remove dirt or debris. Avoid using harsh chemicals or abrasive cleaners.
- **Inspection:** Regularly inspect the entire length of the hose, including the connectors, for any signs of wear, cracks, cuts, or damage. Ensure the quick-connect chuck operates smoothly and locks securely.
- **Storage:** Store the air hose coiled loosely to prevent kinking. Keep it away from sharp objects or heavy items that could cause damage.

6. Troubleshooting

- **Air Leakage at Inflator Connection:** Ensure the orange threaded connector is fully tightened onto the inflator's air outlet. Check for any debris in the threads.
- **Air Leakage at Tire Valve Connection:** Verify that the quick-connect chuck is pushed firmly onto the tire valve stem and the lever is fully engaged. The rubber seal inside the chuck may be worn; inspect and replace if necessary.
- **Hose Damage:** If the hose itself is cut, cracked, or severely kinked, it may need to be replaced to ensure safe and effective operation.

7. Specifications

Feature	Detail
Part Number	3691-PJ01-US02
Item Weight	1.76 ounces (0.05 Kilograms)
Package Dimensions	8.07 x 6.93 x 0.71 inches
Material	Polyvinyl Chloride (PVC), Rubber
Color	Black
Included Components	Air hose
Manufacturer	ZGZUXO

8. Warranty and Support

This ZGZUXO Air Hose comes with a **2-year warranty** from the date of purchase. This warranty covers

manufacturing defects under normal use. For warranty claims, technical support, or further assistance, please visit the official [ZGZUXO Store on Amazon](#) or contact ZGZUXO customer service.

© 2023 ZGZUXO. All rights reserved.

Related Documents - CZK-3691, CZK-3640

	<p><u>ZGZUXO CZK-3691-R Portable Tire Inflator User Manual</u></p> <p>User manual for the ZGZUXO CZK-3691-R portable tire inflator, covering safety instructions, product description, operating procedures, specifications, and important notes for safe and effective use.</p>
	<p><u>ZGZUXO CZK-3691 Portable Tire Inflator User Manual</u></p> <p>Comprehensive user manual for the ZGZUXO CZK-3691 portable tire inflator, detailing safety instructions, operating procedures, product specifications, and customer support.</p>
	<p><u>ZGZUXO CZK-3640 Portable Tire Inflator User Manual</u></p> <p>User manual for the ZGZUXO CZK-3640 portable tire inflator, detailing product features, specifications, operating instructions, fuse replacement, and customer support.</p>
	<p><u>ZGZUXO Portable Tire Inflator User Manual</u></p> <p>User manual for the ZGZUXO Portable Tire Inflator, detailing safety instructions, product description, operating instructions for both battery and 12V DC power, product specifications, and customer service information.</p>
	<p><u>ZGZUXO CZK-3640 Portable Tire Inflator User Manual</u></p> <p>Comprehensive user guide for the ZGZUXO CZK-3640 portable tire inflator. Learn how to use, maintain, and replace fuses for this 150 PSI air compressor with LED light and LCD display, suitable for cars, motorcycles, bicycles, and balls.</p>
	<p><u>ZGZUXO T5 Baby Car Camera User Manual - HD 1440P Recording & Night Vision</u></p> <p>Comprehensive user manual for the ZGZUXO T5 Baby Car Camera. Learn about installation, operation, features like 1440P HD recording, full-color night vision, loop recording, and customer support.</p>