Devoko 0077

Devoko Standing Desk User Manual

Model: 0077

1. Introduction

Thank you for purchasing the Devoko Standing Desk. This electric height-adjustable desk is designed to provide a flexible and ergonomic workspace, allowing you to easily switch between sitting and standing positions. This manual provides essential information for assembly, operation, maintenance, and troubleshooting to ensure safe and efficient use of your new desk.

2. Safety Information

Please read all safety instructions carefully before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Weight Limit:** Always ensure the desk is within its maximum weight limit of**70kg (154 lbs)**. Exceeding this limit can cause instability and damage.
- **Movement Safety:** Be cautious when adjusting the desk's height. Keep hands, feet, and other objects clear of moving parts to avoid pinching or crushing. Ensure children and pets are at a safe distance during operation.
- **Electrical Safety:** Keep the desk's electrical components away from liquids. Do not attempt to repair or modify the electrical system yourself. Contact qualified personnel for any electrical issues.
- **Overheating Protection:** The electric motor is equipped with overheating protection. If the motor stops working during prolonged use, allow it to cool down before resuming operation.
- **Anti-Collision Technology:** The desk features anti-collision technology. If the desk encounters an obstacle during height adjustment, it will stop and reverse slightly.
- **Stable Surface:** Ensure the desk is placed on a level and stable surface to prevent tipping.
- **Cable Management:** Properly manage all cables to prevent tripping hazards and damage to the desk's components.

Note: This desk is designed for indoor use only.

3. Package Contents

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Desk Top (Multi-piece)
- Desk Legs (2)
- Control Panel
- Motor and Power Adapter
- USB Charging Port (Built-in)
- Cable Storage Box
- Hooks (2)
- Wheels (4)
- Assembly Hardware (Screws, Allen wrenches, etc.)
- User Manual

4. Setup and Assembly

Assembly is required for this product. It is recommended to assemble the desk with at least two people. Please follow the steps below carefully.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Desk Legs:** Attach the feet to the bottom of the desk legs using the provided screws. Ensure they are securely fastened.
3. **Attach Legs to Desk Top:** Position the desk top (multi-piece) upside down. Attach the assembled legs to the designated mounting points on the desk top using the appropriate screws. Ensure the desk top pieces are aligned correctly before securing.
4. **Install Control Panel and Motor:** Mount the control panel and motor unit to the underside of the desk top as indicated in the assembly diagram. Connect all necessary cables from the motor to the control panel and power adapter.
5. **Install Accessories:** Attach the cable storage box and hooks to the underside of the desk as desired. If using the wheels, replace the standard feet with the provided wheels.
6. **Cable Management:** Route all cables neatly using the cable management features, including the cable storage box and any integrated cable holes.
7. **Power Connection:** Plug the power adapter into a standard electrical outlet.
8. **Initial Calibration (if necessary):** Some models may require an initial calibration. Refer to the specific instructions provided with your desk for this step. Typically, this involves pressing and holding the 'down' button until the desk reaches its lowest point and slightly retracts.



Image: Fully assembled Devoko Standing Desk with electronic devices. This image illustrates the desk's spacious surface and ergonomic design.



Image: Devoko Standing Desk in a home office environment, highlighting its aesthetic integration.




Image: Product dimensions diagram, indicating the desk top size (160x80 cm) and height adjustment range (72-118 cm).

5. Operating Instructions

Your Devoko Standing Desk features an intuitive control panel for easy height adjustment and memory functions.

5.1 Control Panel Functions



Image: Smart Control Panel, showing buttons for height adjustment, memory presets, and a digital display.

- **Up/Down Buttons (^ / v):** Press and hold the up arrow to raise the desk, and the down arrow to lower it. Release the button at your desired height. The digital display will show the current height.
- **Memory Positions (1, 2, 3):** The desk can store three preferred height settings.
    a. **To Save a Position:** Adjust the desk to your desired height. Press the 'M' or 'Set' button (if available, otherwise directly press the number button) followed by the number button (1, 2, or 3) you wish to assign. The display may flash to confirm.
    b. **To Recall a Position:** Simply press the corresponding number button (1, 2, or 3). The desk will automatically move to the saved height.
- **USB Charging Port:** The built-in USB port allows you to charge your devices conveniently.
- **Sedentary Reminder (if applicable):** Some models may have a sedentary reminder function. Consult your specific manual for activation and settings.



Image: Height adjustment range illustration, showing the desk moving between its minimum (72 cm) and maximum (118 cm) heights.

5.2 Using the USB Charging Port

The desk is equipped with a USB charging port (Type-C) for your convenience. Simply plug your compatible device's charging cable into the port to begin charging.



Image: Integrated features including a wire collection hole, a hook for accessories, and an under-desk cable organizer.

6. Maintenance

Regular maintenance will help prolong the life of your Devoko Standing Desk.

- **Cleaning:** Wipe the desk surface and legs with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners that could damage the finish.
- **Cable Inspection:** Periodically check all cables for any signs of wear, fraying, or damage. Replace damaged cables immediately.
- **Fastener Check:** Occasionally check all screws and fasteners to ensure they are tight. Retighten if necessary.
- **Motor Care:** The motor is designed for long-term use and requires minimal maintenance. Keep the motor area free of dust and debris.

7. Troubleshooting

If you encounter any issues with your Devoko Standing Desk, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Desk does not move.	Power cable disconnected; Overload; Overheating; Motor error.	Check power connection. Reduce weight on desk. Allow motor to cool down. Perform a reset (refer to specific model instructions, usually by holding down button).
Desk moves unevenly or makes unusual noise.	Loose fasteners; Obstruction; Uneven weight distribution.	Check and tighten all screws. Remove any obstructions. Redistribute weight evenly on the desk surface.
Anti-collision feature frequently activates.	Obstruction in path; Sensitivity setting too high (if adjustable).	Ensure clear path during movement. Consult manual for anti-collision sensitivity adjustment if available.
USB charging port not working.	Device not compatible; Cable issue; Power issue.	Ensure device is compatible. Try a different USB cable. Check if desk is powered on.

If the problem persists after trying these solutions, please contact Devoko customer support for further assistance.

8. Specifications

Feature	Detail
Brand	Devoko
Model Number	0077
Desk Type	Electric Height Adjustable Standing Desk
Dimensions (L x W)	160 cm x 80 cm
Height Adjustment Range	72 cm - 118 cm
Maximum Weight Capacity	70 kg (154 lbs)
Material (Top)	Wood
Material (Base)	Metal
Color	Beige (Top), Beige (Base)

Feature	Detail
Special Features	Adjustable Height, Built-In USB Outlet (Type-C), Electric Lifting Mechanism, Ergonomic Design, Wheels (optional), 3 Memory Positions, Anti-Collision Technology, Overheating Protection.
Item Weight	29 Kilograms
Assembly Required	Yes

9. Warranty and Support

Devoko provides a limited warranty for this product. Please retain your proof of purchase for warranty claims.

- **Warranty Coverage:** The warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or exceeding the weight limit.
- **Customer Support:** For technical assistance, warranty claims, or to order replacement parts, please contact Devoko customer support.
- **Online Resources:** Visit the official Devoko website for additional resources, FAQs, and updated product information.

For customer support, please refer to the contact information provided on your purchase receipt or the Devoko brand store on Amazon: Devoko Store

© 2025 Devoko. All rights reserved.