Micool Y30

Micool Y30 Open Ear Headphones User Manual

Model: Y30

1. INTRODUCTION

Thank you for choosing the Micool Y30 Open Ear Headphones. These wireless Bluetooth 5.3 earbuds are designed to provide a comfortable and safe listening experience by resting gently on your ears without blocking the ear canal. This design allows you to remain aware of your surroundings while enjoying high-quality audio, making them ideal for sports and daily activities.

2. WHAT'S IN THE BOX

- Micool Y30 Open Ear Headphones (Left and Right)
- Wireless Charging Case
- USB-C Charging Cable
- User Manual

Figure 2.1: Micool Y30 Open Ear Headphones and their charging case. The image shows two black open-ear earbuds with ear hooks, positioned above a sleek black charging case with four LED indicator lights on the front.

3. Product Overview

3.1 Earbud Components

Each earbud features an ergonomic design with a soft silicone ear hook for secure and comfortable placement. The main body houses the speaker and touch control area.

Figure 3.1: Close-up view illustrating the ergonomic design of the Micool Y30 earbud. The image highlights the curved ear hook and the soft silicone material designed for comfort and secure fit, conforming to the ear's contour.

3.2 Charging Case

The charging case protects the earbuds and recharges them. It has a USB-C charging port and LED indicators to show battery status.

STRONGLY UPGRADE
BLUETOOTH 5.3

The new Bluetooth 5.3 solution reduces sound quality loss and latency
Simultaneously enhancing anti-interference ability and connection stability

Bluetooth 5.3 | Second by second response

Figure 3.2: Internal view of the Micool Y30 charging case, showcasing the earbuds nestled inside. The image highlights the Bluetooth 5.3 technology and the digital display indicating battery levels, emphasizing fast response and stable connection.

4. SETUP

4.1 Charging the Device

Before first use, fully charge the earbuds and the charging case.

1. **Charging the Case:** Connect the provided USB-C cable to the charging port on the case and to a USB power adapter (not included). The LED indicators on the case will show the charging status. A full charge takes approximately 1-2 hours.
2. **Charging the Earbuds:** Place the earbuds into the charging case. Ensure they are correctly seated. The earbuds will automatically begin charging. The case can charge the earbuds 4-5 times, providing up to 6 hours of playback per single earbud charge.

4.2 Bluetooth Pairing

To connect your Micool Y30 headphones to your device:

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (e.g., smartphone, tablet), go to Bluetooth settings and turn Bluetooth on.
4. Search for available devices. Select "Micool Y30" from the list.

5. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.

The headphones support Bluetooth 5.3 for stable and efficient connection.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- **Power On:** Open the charging case, and the earbuds will automatically power on.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically power off and begin charging.

5.2 Music Playback

The Micool Y30 headphones feature touch controls for media management.

- **Play/Pause:** Tap once on either earbud.
- **Next Track:** Double-tap the right earbud.
- **Previous Track:** Double-tap the left earbud.
- **Volume Up:** Triple-tap the right earbud.
- **Volume Down:** Triple-tap the left earbud.

5.3 Call Management

- **Answer/End Call:** Tap once on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.

5.4 Single and Dual Earbud Mode

The Micool Y30 headphones support seamless switching between using a single earbud or both earbuds.

- **Single Earbud Mode:** You can use either the left or right earbud independently. Simply take one earbud out of the case, and it will connect to your device.
- **Dual Earbud Mode:** Take both earbuds out of the case, and they will automatically connect to each other and then to your device for a stereo audio experience.

Figure 5.1: Illustration of the Micool Y30's flexible usage modes. The diagram shows how the earbuds can be used independently in "Single Earphone Mode" or together in "Dual Headphone Mode" for a synchronized connection.

6. MAINTENANCE

6.1 Cleaning

- Use a soft, dry, lint-free cloth to clean the earbuds and charging case.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.
- The earbuds have an IPX6 waterproof rating, meaning they are resistant to strong jets of water. However, they are not

designed for submersion. Wipe them dry after exposure to sweat or water.

6.2 Storage

- Store the earbuds in their charging case when not in use to protect them and keep them charged.
- Avoid storing the device in extreme temperatures (hot or cold) or in highly humid environments.

7. TROUBLESHOOTING

Problem	Solution
Earbuds not pairing with device.	• Ensure earbuds are charged and out of the case. • Turn off and on Bluetooth on your device. • Forget "Micool Y30" from your device's Bluetooth list and try pairing again. • Ensure earbuds are within Bluetooth range (approx. 10 meters).
No sound from one earbud.	• Place both earbuds back into the charging case, close the lid, then open it again to reset. • Check device's audio balance settings.
Earbuds not charging.	• Ensure the charging cable is securely connected to both the case and the power source. • Check if the charging case itself has power. • Clean the charging contacts on the earbuds and inside the case with a dry cotton swab.
Poor sound quality or connection drops.	• Move closer to your connected device to reduce interference. • Avoid physical obstructions between the earbuds and your device. • Ensure no other strong wireless signals are interfering.

8. SPECIFICATIONS

Feature	Detail
Model Name	Y30
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3
Ear Placement	Open Ear
Earbud Battery Capacity	100mAh (each)
Charging Case Battery Capacity	450mAh
Playback Time (single charge)	Up to 6 hours

| Feature	Detail
Total Playback Time (with case)	Up to 30 hours (4-5 full charges from case)
Charging Time (case)	1-2 hours
Charging Port	USB Type-C
Waterproof Rating	IPX6
Material	Plastic
UPC	776584469303

9. WARRANTY AND SUPPORT

Micool products are designed with quality and reliability in mind. For warranty information or technical support, please refer to the warranty card included in your product packaging or visit the official Micool website. You may also contact your retailer for assistance.

For further assistance, please visit the Micool Store on Amazon.

Related Documents - Y30

	Y30 Car Camera: Quick Start Guide and Features Comprehensive yet concise instructions for the Y30 car camera, detailing functional settings, video playback, and device components. This guide is optimized for English readers and covers multiple languages.
	Y30 True Wireless Stereo Earbuds User Manual Comprehensive user manual for the Y30 True Wireless Stereo Earbuds by Shenzhen Xiang Xiang Yu Technology Co.,Ltd, detailing features, specifications, Bluetooth pairing, operation, LED indicators, and important precautions.
	Smartwatch Y30 User Manual - Features, Setup, and Usage Guide Comprehensive user manual for the Smartwatch Y30, covering setup, device connection, features like heart rate monitoring, sleep tracking, sport modes, and app integration. Includes important usage precautions.
	Y30 Car Camera: Quick Start Guide and Features Comprehensive yet concise instructions for the Y30 car camera, detailing functional settings, video playback, and device components. This guide is optimized for English readers and covers multiple languages.

YABER YABER Y30 **Instruction manual**	**YABER Y30 1080P Full HD Projector Instruction Manual** Comprehensive instruction manual for the YABER Y30 1080P Full HD Projector, covering setup, operation, remote control functions, troubleshooting, and connectivity options for various devices.
Smartwatch Y30 **Manuel de l'utilisateur** Mode d'emploi Lire de la mesure, approchez le capteur de la peau et évitez de le déplacer. Les résultats des mesures du produit sont donnés à titre de référence et non à des fins médicales. Chargez complètement l'appareil avant de l'utiliser. Le temps de charge est d'environ 2 heures. Utilisez des accessoires standard pour le chargement afin d'éviter les accidents. Ne chargez pas l'appareil dans des conditions humides ou à proximité d'éclaboussures d'eau. Installation et connexion de l'APP Scanner le code QR ou entrez dans l'APP Store et recherchez "Xband" dans l'App Store pour télécharger et installer l'APP	**Smartwatch Y30 User Manual: Features, Setup, and App Guide** Comprehensive user manual for the Smartwatch Y30, covering setup, app connection, features like health monitoring, sports tracking, and Bluetooth functionality. Learn how to pair your watch and use its various modes.