

[Manuals.plus](#) /

› [FEZIBO](#) /

› FEZIBO Electric Standing Desk with Double Drawer and Anti-fatigue Mat Bundle User Manual

FEZIBO Electric Standing Desk with Double Drawer

FEZIBO Electric Standing Desk with Double Drawer and Anti-fatigue Mat Bundle

Model: Electric Standing Desk with Double Drawer

Brand: FEZIBO

1. INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your FEZIBO Electric Standing Desk with Double Drawer and Anti-fatigue Mat Bundle. Please read this manual thoroughly before assembly and use to ensure proper function and safety. Retain this manual for future reference.

2. IMPORTANT SAFETY INFORMATION

To prevent injury or damage to your product, observe the following safety precautions:

- Always follow the assembly instructions carefully.
- Keep the desk away from water and heat sources.
- Do not use the desk if the cord is damaged.
- Always use the desk with caution when adjusting the height. Ensure no obstructions are present in the desk's path.
- Keep the desk away from children and pets when in use or when adjusting height.
- Do not overload the desk. The maximum weight capacity is **176 lbs**.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning assembly. If any parts are missing or damaged, contact customer support.

- Electric Standing Desk Frame
- Desktop (55" x 24", two pieces)
- Double Drawers
- Control Panel
- Power Adapter and Cable

- Assembly Hardware (screws, tools)
- Standing Desk Mat
- User Manual



Image 3.1: Overview of the FEZIBO Electric Standing Desk and Anti-fatigue Mat.

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your standing desk. It is recommended to have two people for assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Desk Frame:** Attach the lifting columns to the foot supports using the provided screws. Ensure all connections are secure.
3. **Attach Desktop:** Place the two desktop pieces onto the assembled frame. Align the pre-drilled holes and secure

the desktop to the frame using the designated screws.

4. **Install Control Box and Motor:** Mount the control box and motor to the underside of the desktop as indicated in the detailed diagram (refer to the included paper manual for specific locations).
5. **Connect Cables:** Connect the motor cables, control panel cable, and power adapter cable to the control box. Ensure all connections are firm.
6. **Install Drawers:** Slide the double drawers into their designated slots beneath the desktop. Ensure they operate smoothly.
7. **Initial Power-Up and Calibration:** Plug the desk into a power outlet. Follow the instructions in the operating section to calibrate the desk for the first time.





Image 4.1: Desk dimensions and weight capacity (176 lbs).



FREE ACCESSORIES

Image 4.2: Detail of the control panel and other desk features.

5. OPERATING INSTRUCTIONS

5.1. Electric Height Adjustment

Your FEZIBO standing desk features an electric height adjustment system with a range from **28 inches to 45.5 inches**. The control panel is located on the front edge of the desk.

- **Adjusting Height:** Use the **Up (▲)** and **Down (▼)** buttons to manually adjust the desk to your desired height.
- **Setting Presets:** The desk has 3 programmable memory presets (S1, S2, S3).
 - a. Adjust the desk to your desired height using the Up/Down buttons.
 - b. Press the **"S"** button, then immediately press the desired preset number (**"1"**, **"2"**, or **"3"**). The display will show "S-" followed by the number, indicating the height is saved.
- **Using Presets:** Press a saved preset number (1, 2, or 3) to automatically move the desk to the stored height.

- **Initial Calibration (First Use or After Power Loss):** If the desk does not move or displays an error, perform a reset. Press and hold the **Down (▼)** button until the desk reaches its lowest point, then release and press it again until it moves slightly down, then up, and stops. This indicates successful calibration.

5.2. Double Drawers

The two integrated wooden drawers provide convenient storage for your office supplies, helping to keep your workspace organized and clutter-free.

- Simply pull the handles to open the drawers.
- Push firmly to close them completely.
- Avoid placing excessively heavy items in the drawers to ensure smooth operation and prevent damage.



Image 5.1: The spacious wooden drawers for storage.

5.3. Standing Desk Mat

The included anti-fatigue mat is designed to enhance comfort and promote movement while standing. It features an **8.5°**

tilting angle to encourage subtle shifts in posture.

- Place the mat on the floor in front of your standing desk.
- Stand on the mat while working to experience its ergonomic benefits.
- The mat's design includes massage points and a massage bar for foot stimulation.
- The non-slip natural rubber base ensures stability.



Image 5.2: Users benefiting from the anti-fatigue mat.



Image 5.3: Key features of the anti-fatigue mat.



Tilting Angle **8.5°**



Image 5.4: The 8.5° tilting angle of the anti-fatigue mat.

6. MAINTENANCE

Regular maintenance helps prolong the life and performance of your desk.

- **Cleaning:** Wipe the desk surface and frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Cable Management:** Periodically check and organize cables to prevent tangles and damage.
- **Inspection:** Regularly inspect all screws and connections to ensure they remain tight. Retighten if necessary.
- **Anti-fatigue Mat Care:** Clean the mat with a damp cloth and mild soap if needed. Allow it to air dry completely.

7. TROUBLESHOOTING

If you encounter issues with your desk, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Desk does not move.	Power cable disconnected, motor cable loose, overload, or system needs reset.	Check all cable connections. Reduce weight on the desk. Perform a system reset (refer to Section 5.1).

Problem	Possible Cause	Solution
Desk moves unevenly.	Uneven load, loose connections, or calibration issue.	Distribute weight evenly. Check and tighten all screws. Perform a system reset.
Error code displayed.	Specific system fault.	Refer to the detailed error code list in the included paper manual. Often, a system reset can resolve minor errors. If the error persists, contact customer support.
Drawers stick or are difficult to open/close.	Overloaded, obstruction, or misaligned.	Remove some items from the drawers. Check for any obstructions. Ensure drawers are properly installed.

If the problem persists after attempting these solutions, please contact FEZIBO customer support for further assistance.

8. SPECIFICATIONS

Feature	Detail
Brand	FEZIBO
Product Dimensions (D x W x H)	24"D x 55"W x 28"H
Maximum Height	45.5 Inches
Minimum Height	28 Inches
Working Surface Diagonal Length	55 Inches
Weight Capacity	176 lbs
Number of Drawers	2 (Double Drawer)
Top Material Type	Fir
Base Material	Stainless Steel, Alloy Steel, Carbon Steel, or Iron
Finish Type	Wooden
Included Components	Electric Standing Desk, Double Drawers, Standing Desk Mat
Required Assembly	Yes
Anti-fatigue Mat Tilting Angle	8.5 Degrees

9. WARRANTY AND SUPPORT

Your FEZIBO Electric Standing Desk comes with a**Limited Warranty**. Please refer to the warranty card included in your package for specific terms and conditions, including coverage duration and limitations.

For technical support, missing parts, or warranty claims, please contact FEZIBO customer service. You can typically find

contact information on the FEZIBO official website or through your purchase platform.
When contacting support, please have your product model number and purchase information readily available.

© 2024 FEZIBO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question