



---

[Manuals.plus](#) /

› [Topyond](#) /

› Topyond Hilda Rotary Tools Kit User Manual

**Topyond Topyond1ds9ugyrpz**

# Topyond Hilda Rotary Tools Kit User Manual

Model: Topyond1ds9ugyrpz

## INTRODUCTION

---

Thank you for choosing the Topyond Hilda Rotary Tools Kit. This versatile and compact cordless rotary tool is designed for precision work, including carving, grinding, drilling, and polishing. Its portable design, variable speed settings, and comprehensive accessory kit make it ideal for a wide range of applications from intricate crafts to light home repairs. Please read this manual thoroughly before operation to ensure safe and effective use of your new tool.



4. Tighten the chuck nut clockwise until the accessory is securely held. Do not overtighten.



Brass thick wall chuck  
Clamping range from 0.5-3.2mm

Image: A hand demonstrating the installation of an accessory into the brass chuck of the rotary tool, highlighting the secure clamping mechanism.

## OPERATING INSTRUCTIONS

### Powering On/Off

To turn the tool on or off, press the power button located on the body of the tool. The indicator lights will show the current speed setting when powered on.

### Adjusting Speed

The Topyond Hilda Rotary Tool offers three variable speed levels to suit different materials and tasks:

- **Level 1:** 5000 RPM (for delicate work, polishing, or soft materials)
- **Level 2:** 10000 RPM (for general carving, grinding, or medium-density materials)

- **Level 3:** 15000 RPM (for aggressive material removal, drilling, or hard materials)

Press the speed adjustment button to cycle through the three speed settings. The corresponding indicator light will illuminate.

## Application Tips

- Always wear appropriate safety gear, including eye protection.
- Start with a lower speed setting and gradually increase if needed.
- Apply light, consistent pressure. Let the tool do the work.
- For fine carving and engraving, use precise, controlled movements.
- The tool is suitable for household use, egg carvings, fine carving, and jewelry work, among other applications.



# Electric Carving Pen

Portable Design: The electric grinder pen is small and compact, light in weight, easy to operate and carry.

Image: A user holding the Topyond Hilda Rotary Tool, demonstrating its ergonomic design and ease of use while performing a carving task on a small, light-colored object.

## Cleaning

- After each use, disconnect the tool from any power source.
- Use a soft, dry cloth to wipe down the tool's body.
- Remove any dust or debris from the chuck and ventilation openings using a small brush or compressed air.
- Do not use harsh chemicals or abrasive cleaners.

## Storage

- Store the tool and its accessories in a clean, dry place, away from direct sunlight and extreme temperatures.
- Keep out of reach of children.
- Ensure the battery is partially charged (around 50%) before long-term storage to preserve battery health.

## TROUBLESHOOTING

If you encounter issues with your Topyond Hilda Rotary Tools Kit, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Tool does not turn on.	Battery is depleted.	Charge the tool using the provided USB cable.
Accessory slips in chuck.	Chuck not tightened sufficiently; accessory shank too small.	Ensure chuck is tightened securely. Use accessories with shanks within the 0.5-3.2mm range.
Tool loses power quickly.	Battery not fully charged; battery degradation.	Ensure full charge before use. If problem persists, battery may need replacement (contact support).
Excessive vibration or noise.	Accessory not properly seated or bent; internal issue.	Check accessory for proper seating and straightness. If issue persists, discontinue use and contact support.

## SPECIFICATIONS

Feature	Specification
Model Number	Topyond1ds9ugyrpz
Power Supply Type	Rechargeable, Lithium Battery Technology
Rated Voltage	3.6V
Built-in Lithium Battery	3.6V 700mAh
Charging Mode	USB
Chuck Size	Approx. 3.2mm (0.13in)
No Load Speed (Three Levels)	5000-10000-15000 RPM
Item Weight	9.9 ounces

Feature	Specification
Material	ABS + Brass
Included Accessories	30 Pcs/set

## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact the seller directly. The seller for this product is YouXink. Keep your proof of purchase for any warranty claims.

For further assistance or technical inquiries, please reach out to the manufacturer or authorized service center.