

[Manuals.plus](#) /

> [CKIKH](#) /

> CKIKH Handheld Steamer for Clothes Instruction Manual

## CKIKH GS002

# CKIKH Handheld Steamer Instruction Manual

Model: GS002

## 1. INTRODUCTION

Thank you for purchasing the CKIKH Handheld Steamer. This powerful and portable garment steamer is designed to quickly and effectively remove wrinkles from a variety of fabrics, making your clothes look fresh and presentable. Please read this manual thoroughly before first use to ensure safe and optimal performance.

## 2. IMPORTANT SAFETY INSTRUCTIONS

- Always unplug the steamer from the electrical outlet immediately after use and before cleaning.
- Do not leave the steamer unattended while it is plugged in or operating.
- Use the steamer only for its intended household use as described in this manual.
- To reduce the risk of electric shock, do not immerse the steamer in water or other liquids.
- Do not direct steam at people, animals, or electrical appliances. Steam is hot and can cause burns.
- Use caution when refilling the water tank. Hot water or steam may be present.
- Keep the steamer out of reach of children.
- Do not operate the steamer with a damaged cord or plug, or if the appliance has been dropped or damaged.

## 3. PACKAGE CONTENTS

Verify that all items are included in your package:

- CKIKH Handheld Steamer Unit

- Removable Water Tank
- Fabric Brush Attachment
- Instruction Manual

## 4. PRODUCT OVERVIEW

Familiarize yourself with the components of your CKIKH Handheld Steamer.



Figure 4.1: CKIKH Handheld Steamer emitting steam.

# 2000W Handheld Garment Steamer



**20S**  
Fast Heat-up



**300ML**  
Large-capacity



**22MIN**  
Continuous Steam



Brush included



Figure 4.2: Key features of the CKIKH Handheld Steamer including fast heat-up, large water capacity, and continuous steam duration.



Figure 4.3: Detailed views of the steamer head, steam button, water tank, and power cord.

## 5. SETUP

Follow these steps for initial setup:

1. **Attach Water Tank:** Ensure the water tank is securely connected to the main unit.

- 2. Fill Water Tank:** Remove the water tank and fill it with appropriate amount of distilled or purified water. Do not exceed the 'MAX' fill line. The 300ml capacity provides up to 22 minutes of continuous steam.
- 3. Connect Power:** Plug the steamer into a standard 110V electrical outlet. The indicator light will illuminate.
- 4. Heat-up:** Allow approximately 20 seconds for the steamer to heat up. The indicator light may change or turn off when ready.
- 5. Attach Fabric Brush (Optional):** For thicker fabrics or to remove lint, attach the fabric brush to the steamer head.



Our Steamer	VS	Ordinary Steamer
2000W	Power	900W
20 Sec	Heating Time	2Min
Yes	Leak-proof	No
Yes	Vapour Lock	No
22 Min	Endurance	15 Min
300ML	Tank Capacity	200ML

Figure 5.1: Simple steps to prepare and use the steamer.



**Ultra-Penetrating Pulsed Steam**  
Instantly penetrates fabrics

- 25G/MIN**  
Highly efficient steam
- Steam Lock**  
For continuous steam use

Figure 5.2: The removable 300ml water tank is easy to refill and provides extended steaming time.

## 6. OPERATING INSTRUCTIONS

Once the steamer is ready, you can begin steaming your garments.

- 1. Activate Steam:** Press the steam button to activate steam mode. For continuous steam, slide the steam lock switch (if available on your model).
- 2. Steaming Technique:** Hold the steamer upright for vertical steaming or at any angle for horizontal steaming. The 360° leak-proof design prevents water leakage.
- 3. Fabric Compatibility:** The steamer is suitable for a wide range of fabrics including cotton, wool, linen, nylon,

and silk.

4. **Effective Wrinkle Removal:** Move the steamer slowly over the wrinkled area, allowing the strong penetrating pulse steam to relax the fabric fibers.



Figure 6.1: The steamer supports both horizontal and vertical steaming without leakage.



# Strong Penetrating Pulse Steam

Easily penetrates any fabric

Figure 6.2: The steamer is effective on diverse fabric types due to its strong penetrating steam.



## Instantly Smooths Out Wrinkles

Figure 6.3: Visual demonstration of instant wrinkle removal.

### Convenient Home Life

- quicker
- simpler
- more efficient



Bedding



Plush Doll



Draperies

Figure 6.4: The steamer is versatile for use on bedding, plush dolls, and draperies.

## **7. MAINTENANCE**

Proper maintenance ensures the longevity and efficiency of your steamer.

### **7.1 Cleaning**

- Always unplug the steamer and allow it to cool completely before cleaning.
- Empty any remaining water from the tank after each use.
- Wipe the exterior of the steamer with a soft, damp cloth. Do not use abrasive cleaners.
- Clean the steam nozzle regularly to prevent mineral buildup. Use a cotton swab or a soft brush.

### **7.2 Descaling**

Mineral buildup from tap water can affect performance. Descale your steamer every few months or as needed.

1. Mix a solution of 50% white vinegar and 50% water.
2. Fill the water tank with the solution (do not exceed MAX line).
3. Plug in the steamer and allow it to heat up.
4. Run the steamer until half of the solution has been used.
5. Unplug and let it cool for 30 minutes.
6. Repeat the steaming process with the remaining solution.
7. Empty the tank and rinse thoroughly with fresh water. Run a tank of fresh water through the steamer to flush out any remaining vinegar.

### **7.3 Storage**

Store the steamer in a cool, dry place. Ensure the water tank is empty before storage.

# Compact & Space-Saving

The water tank is removable and fits easily into backpacks and suitcases



1.83lb



6.56ft



Figure 7.1: The compact design allows for easy storage and portability.

# Compact Dimension

Suitable for All Types of Storage



Figure 7.2: The steamer's compact size makes it suitable for various storage options.

## 8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No steam or low steam output	Water tank empty Steamer not heated up Mineral buildup	Refill water tank Allow 20 seconds for heat-up Perform descaling procedure
Water leaking from nozzle	Overfilled water tank Steamer not fully heated Mineral buildup	Do not overfill tank Wait for full heat-up Perform descaling procedure
Steamer not turning on	Not plugged in correctly Power outlet issue Appliance malfunction	Check plug connection Try a different outlet Contact customer support

## 9. SPECIFICATIONS

Feature	Detail
Brand	CKIKH
Model	GS002
Color	White
Product Dimensions	9.65"L x 4.57"W x 3.5"H
Item Weight	1.8 Pounds (0.82 kg)
Wattage	2000 watts
Voltage	110 Volts
Heat Time	20 seconds
Product Benefits	Fabric Refreshening, Remove Wrinkle, Eliminate Odor
Water Tank Capacity	300 Milliliters
UPC	747086440022
Country of Origin	China

## 10. WARRANTY AND SUPPORT

CKIKH provides a worry-free after-sales service. If you encounter any problems with your clothes steamer, please contact our customer service team. We are committed to providing support within 24 hours.

For assistance, please refer to the contact information provided with your purchase or visit the official CKIKH website.