



[Manuals.plus](#) /

> [GYMAX](#) /

> GYMAX Gaming Recliner, Massage Gaming Chair with Bluetooth Speaker, Adjustable Footrest & Lumbar Support, Single Ergonomic Gaming Sofa, Video Gaming Chair for Adults, Home Theatre (Red) Instruction Manual

GYMAX CA-GM1759

GYMAX Gaming Recliner Instruction Manual

Model: CA-GM1759

Brand: GYMAX

1. INTRODUCTION

Thank you for purchasing the GYMAX Gaming Recliner. This manual provides essential information for the safe and efficient use of your new gaming chair. Please read it thoroughly before assembly and operation, and retain it for future reference.



Figure 1.1: The GYMAX Gaming Recliner, featuring integrated massage and Bluetooth audio capabilities.

2. SAFETY INFORMATION

WARNING: To reduce the risk of injury, please adhere to the following safety guidelines:

- This chair is designed for use by a single person only.
- Do not exceed the maximum weight capacity of 181 kg (400 lbs).
- Ensure all connections are secure before use.
- Keep hands and feet clear of moving parts during adjustment.
- Do not allow children to play on or around the chair unsupervised.

3. PACKAGE CONTENTS

Please check the package contents to ensure all parts are present and undamaged. If any items are missing or damaged, contact customer support.

- Gaming Recliner Base Unit
- Backrest Assembly
- Power Adapter for Massage/Bluetooth
- Massage Remote Control
- User Manual (this document)

4. SETUP AND ASSEMBLY

The GYMAX Gaming Recliner is designed for quick and easy assembly, requiring no tools or screws. Follow these 4 simple steps:

1. Carefully remove all components from the packaging.
2. Align the backrest with the base unit and slide it into place until it clicks securely.
3. Connect the power cable for the massage and Bluetooth functions.
4. Place the massage remote control in the side pocket for easy access.

Your browser does not support the video tag.

Video 4.1: This video demonstrates the simple assembly process of the GYMAX Gaming Recliner, including attaching the backrest and connecting the power for the electronic features.

Product Dimension

Weight Capacity: 400 lbs



Figure 4.1: Product dimensions and weight capacity for proper placement and safe use.

5. OPERATING INSTRUCTIONS

5.1 Reclining Function

The recliner offers 3 adjustable positions, with a back angle ranging from 100 to 160 degrees, and the footrest adjustable from 0 to 90 degrees. To recline, simply push back on the backrest while seated. To return to an upright position, push forward with your body weight.



Figure 5.1: The chair's versatile 3-position adjustment for various activities like gaming, watching movies, or napping.

5.2 Massage Function

The chair features 2 built-in massage motors for lumbar support. Use the wired remote control to activate and customize your massage experience:

- **Power Button:** Turn the massage function on/off.
- **Mode Selection:** Choose from 8 different massage modes.
- **Intensity Adjustment:** Increase or decrease the massage intensity.
- **Timer:** Set the massage duration to 15 or 30 minutes.



Figure 5.2: The massage function remote control, allowing selection of 8 modes, adjustable intensity, and a timer.

5.3 Bluetooth Speaker Connection

Enhance your gaming or entertainment experience with the integrated Bluetooth speakers. The speakers provide a 360-degree stereo sound effect.

1. Ensure the chair is powered on.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for available devices and select "**LN-M02**" to connect.
4. Once connected, audio from your device will play through the chair's speakers.

The maximum operating distance for Bluetooth connection is approximately 32 feet (10 meters).

Massage Function

2 Built-in Bluetooth Speakers



USB Power
Support



Effective
Distance: 32FT



Bluetooth Name:
LN-M02



Figure 5.3: The built-in Bluetooth speakers provide immersive audio, easily connectable via your device's Bluetooth settings.

6. MAINTENANCE

To ensure the longevity and appearance of your GYMAX Gaming Recliner, follow these simple maintenance guidelines:

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the PU leather.
- **Spills:** Immediately blot any spills with a clean, dry cloth.
- **Inspection:** Periodically check all connections and moving parts for wear or looseness. Tighten as necessary.
- **Storage:** If storing for an extended period, ensure the chair is clean and dry, and store in a cool, dry place away from direct sunlight.

7. TROUBLESHOOTING

If you encounter any issues with your GYMAX Gaming Recliner, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Massage function not working.	Power cable disconnected; remote control battery low (if applicable); function not activated.	Ensure power cable is securely connected. Check remote control for power. Press the power button on the remote.
Bluetooth speakers not connecting.	Chair not powered on; Bluetooth not enabled on device; incorrect device selected.	Verify chair is powered. Enable Bluetooth on your device. Select "LN-M02" from the list of available devices. Ensure device is within 32ft range.
Chair does not recline smoothly.	Obstruction; mechanism needs lubrication.	Check for any objects obstructing the reclining mechanism. Apply a silicone-based lubricant to moving parts if necessary.

If the problem persists after attempting these solutions, please contact customer support for further assistance.

8. SPECIFICATIONS

Feature	Detail
Brand	GYMAX
Model Name	Massage Gaming Recliner
Model Number	CA-GM1759
Color	Red
Product Dimensions	34"D x 25"W x 41"H
Maximum Weight Recommendation	400 Pounds (181 kg)
Material	PU Leather, Sponge Fill
Reclining Positions	3 (100-160 degrees back angle)
Footrest Adjustment	0-90 degrees
Massage Function	2-point vibrating lumbar massage, 8 modes, 15/30 min timer
Bluetooth Speakers	2 built-in speakers, Bluetooth Name: LN-M02, Effective Distance: 32FT

Feature	Detail
Item Weight	57.5 pounds
Assembly Required	Minimal (4 steps, no tools)

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product's purchase documentation or contact GYMAX customer service directly. Keep your proof of purchase for any warranty claims.

For general inquiries or to explore other GYMAX products, visit the official GYMAX store: [GYMAX Store on Amazon](#).