

[Manuals.plus](#) /

› [Victiv](#) /

› Victiv AT26 Professional 78-inch Aluminum Camera Tripod Monopod Instruction Manual

Victiv AT26

Victiv AT26 Professional 78-inch Aluminum Camera Tripod Monopod Instruction Manual

Model: **AT26** | Brand: **Victiv**

1. INTRODUCTION

Thank you for choosing the Victiv AT26 Professional 78-inch Aluminum Camera Tripod Monopod. This versatile and robust support system is designed for photographers and videographers seeking stability and flexibility. It can be used as a tripod, monopod, or even a trekking pole, accommodating a wide range of devices including DSLR cameras, spotting scopes, telescopes, and binoculars. Please read this manual thoroughly before use to ensure proper operation and longevity of your equipment.



Image 1.1: Victiv AT26 Tripod Monopod and included accessories.

2. SAFETY INFORMATION

- Do not exceed the maximum load capacity of 22 lbs (10 kg).
- Ensure all locks and adjustments are securely tightened before mounting equipment.
- Avoid placing the tripod on unstable or slippery surfaces.
- Do not leave equipment unattended on the tripod, especially in windy conditions.
- Keep hands and fingers clear of moving parts during adjustment to prevent pinching.
- Clean the tripod with a soft, dry cloth. Avoid harsh chemicals.

3. PRODUCT OVERVIEW AND COMPONENTS

The Victiv AT26 tripod features a robust aluminum construction and a versatile design. Key components include:

- **Ball Head:** Provides 360° panning and +90°/-70° tilt for flexible positioning.
- **Quick Release Plate:** Standard 1/4"-20 screw mount for easy attachment and detachment of devices.
- **Center Column:** Extendable for additional height, reversible for low-angle/macro shots.
- **Leg Sections:** Multi-section legs with flip locks for quick height adjustment.
- **Leg Angle Adjusters:** Allows setting legs at various angles (20°, 50°, 80°) for stability on uneven terrain.
- **Monopod Leg:** One leg detaches to form a monopod.
- **Accessory Threads:** 1/4" threaded holes on legs for attaching accessories like magic arms (not included).
- **Retractable Hook:** Located on the center column for hanging additional weight to enhance stability.



Image 3.1: The Victiv AT26 tripod supporting a DSLR camera and a smartphone, demonstrating its sturdy design and the 1/4" screw holes on the legs for accessories.

- 1 Packing Box*1
- 2 Carrying Bag*1
- 3 VICTIV Tripod*1
- 4 Phone Holder*1
- 5 International Standard Screw*2



Image 3.2: Contents of the Victiv AT26 package, including the tripod, carrying bag, phone holder, and international standard screws.

4. SETUP

4.1 Unpacking and Initial Inspection

Carefully remove all components from the packaging. Verify that all parts listed in the product overview are present and undamaged. The package typically includes the tripod, a carrying bag, a phone holder, and international standard screws.

4.2 Extending the Tripod Legs

1. Release the leg flip locks on each leg section.
2. Extend the legs to the desired length.
3. Securely close the flip locks to prevent the legs from collapsing.

4.3 Adjusting Leg Angles

Each leg has an angle adjustment mechanism. Press the leg angle adjuster and move the leg to one of the preset angles (20°, 50°, or 80°) to adapt to various terrains and shooting heights.



Image 4.1: Detail of the leg angle adjustment mechanism on the Victiv AT26 tripod.

4.4 Attaching Your Device

1. Ensure the quick release plate is securely attached to your camera or device using the 1/4"-20 screw.
2. Open the quick release clamp on the ball head.
3. Slide the quick release plate with your device into the clamp until it clicks into place.
4. Tighten the clamp knob to secure the device.

Sturdy DSLR Tripod with Magic Arm Hole



More Sturdy



360° Panorama View



More Stable



Max Load 22LB/10KG



Image 4.2: The Victiv AT26 tripod supporting a DSLR camera and a smartphone, demonstrating its sturdy design and the 1/4" screw holes on the legs for accessories.

5. OPERATING INSTRUCTIONS

5.1 Adjusting the Ball Head

The ball head allows for precise positioning of your camera. Loosen the main locking knob to adjust the angle and tilt. Tighten the knob to lock the position. The separate panning lock allows for smooth 360° rotation without affecting the tilt angle.

360° Ball Head Tripod

It supports various angle adjustments



Image 5.1: The Victiv AT26 tripod on a beach, illustrating the various angle adjustments possible with its 360° ball head, including landscape, portrait, low angle, and high angle modes, along with two types of foot mats.

5.2 Converting to Monopod

1. Identify the leg with the foam grip. This is the detachable monopod leg.
2. Unscrew this leg from the tripod body.
3. Unscrew the center column from the tripod body.
4. Attach the ball head (or your camera directly) to the top of the detached leg.
5. Alternatively, attach the center column to the detached leg for extended height.



Image 5.2: Step-by-step illustration of converting the Victiv AT26 tripod into a monopod.

5.3 Macro Photography (Inverted Center Column)

For low-angle or macro photography, the center column can be inverted:

1. Fully extend and remove the center column from the tripod.
2. Reinsert the center column upside down into the tripod body.
3. Mount your camera to the quick release plate on the inverted column.



Image 5.3: Instructions for setting up the Victiv AT26 tripod for macro photography by inverting the center column.

5.4 Using the Phone Holder

The included phone holder can be attached to the quick release plate for smartphone photography or videography.

Video Recording



Macro photography



Monopods



Trekking poles

Image 5.4: The Victiv AT26 tripod demonstrating its versatility for video recording, macro photography, use as a monopod, and as trekking poles.

6. MAINTENANCE

- **Cleaning:** Wipe down the tripod with a soft, damp cloth after each use, especially if used in dusty or sandy

environments. Avoid using abrasive cleaners or solvents.

- **Lubrication:** Periodically check the leg locks and ball head for smooth operation. If necessary, apply a small amount of silicone-based lubricant to moving parts, avoiding excessive application.
- **Storage:** Store the tripod in its carrying bag in a dry, cool place away from direct sunlight and extreme temperatures.
- **Inspection:** Regularly inspect all screws, bolts, and moving parts for tightness and wear. Tighten any loose components using the provided hex wrenches.

7. TROUBLESHOOTING

- **Issue: Tripod is unstable.**
Solution: Ensure all leg sections are fully extended and their flip locks are securely closed. Verify that the leg angle adjusters are properly engaged. For added stability, hang a weight from the retractable hook on the center column.
- **Issue: Ball head movement is not smooth.**
Solution: Ensure the main locking knob is sufficiently loosened. Clean any dust or debris from the ball head mechanism. If necessary, apply a small amount of silicone lubricant.
- **Issue: Quick release plate is difficult to attach/detach.**
Solution: Ensure the quick release clamp is fully open. Check for any obstructions or debris in the clamp mechanism.
- **Issue: Monopod leg is difficult to detach/reattach.**
Solution: Ensure the leg is fully unscrewed or properly aligned for reattachment. Do not force the connection.

8. SPECIFICATIONS

Feature	Specification
Model Number	AT26
Brand	Victiv
Material	Aluminum
Maximum Height	78 Inches (200 cm)
Minimum Height	19 Inches (48 cm)
Folded Length	16.7 Inches (42.4 cm)
Item Weight	4.31 pounds (1.96 kg)
Weight Limit	22 Pounds (10 kg)
Tripod Head Type	Ball Head
Compatible Devices	Cameras, Binoculars, Spotting Scopes, Telescopes, Smartphones, Tablets

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the product packaging or contact Victiv customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question