

Bellemave LED TV Stand for 70 inch TV

Bellemave LED TV Stand User Manual

Model: LED TV Stand for 70 inch TV

1. INTRODUCTION

Thank you for choosing the Bellemave LED TV Stand. This manual provides detailed instructions for the assembly, operation, and maintenance of your new entertainment center. Please read this manual thoroughly before assembly and use to ensure safe and proper functionality. This TV stand is designed to accommodate televisions up to 70 inches and features integrated LED lighting for enhanced ambiance.

2. SAFETY INFORMATION

- Always follow assembly instructions carefully.
- Do not overtighten screws, as this may damage the material.
- Ensure the TV stand is placed on a flat, stable, and level surface to prevent tipping.
- Do not exceed the maximum weight capacity for the top surface or shelves.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Disconnect the LED light power supply before cleaning or maintenance.
- Avoid exposing the unit to excessive moisture or direct sunlight.

3. PACKAGE CONTENTS

Before beginning assembly, please verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer service.

- MDF and Particle Board Panels (various sizes)
- Glass Partition/Shelf
- Acrylic Lamp Posts
- LED Light Strip and Power Adapter
- Wireless Remote Control for LED Lights

- Assembly Hardware (screws, dowels, cam locks, hinges, drawer slides, etc.)
- Instruction Manual



SHOW DETAILS

Figure 3.1: Detailed view of key components including acrylic lamp posts, glass partition, LED light strip, and side open storage.

4. ASSEMBLY INSTRUCTIONS

Assembly of the Bellemave LED TV Stand requires two adults and basic household tools (e.g., screwdriver). Follow the step-by-step instructions provided in the separate assembly guide included in your package. Ensure all parts are correctly oriented before tightening screws.

1. **Unpack and Identify Parts:** Lay out all panels and hardware. Match them with the parts list in the assembly guide.
2. **Assemble Base Structure:** Connect the bottom and side panels as indicated.
3. **Install Shelves and Partitions:** Secure the glass partition and any other internal shelves.
4. **Attach Acrylic Posts:** Mount the acrylic lamp posts that support the upper shelf.
5. **Assemble Drawers/Cabinets:** Construct the sliding drawer and side cabinet doors, then install them onto the

main frame.

6. **Install LED Lighting:** Adhere the LED light strip to the designated area and connect it to the power adapter.
7. **Final Checks:** Ensure all connections are secure and the stand is stable.



Figure 4.1: Fully assembled Bellemave LED TV Stand with integrated blue LED lighting.



Figure 4.2: The TV stand accommodating a television and various media devices.

5. SETUP

Once assembled, position your Bellemave LED TV Stand in your desired location. Ensure there is adequate space for ventilation around your television and other electronic devices. The stand is designed to accommodate TVs up to 70 inches.

- **Placement:** Choose a flat, stable surface away from direct heat sources or excessive moisture.
- **Cable Management:** Utilize the open back design of the shelves to route cables neatly, preventing tangles and ensuring safety.
- **TV Placement:** Carefully place your television on the top surface. Ensure it is centered and stable.

ACCOMMODATES TV UP TO 60"




Figure 5.1: Dimensions of the TV stand and TV size accommodation.

6. OPERATING THE LED LIGHTS

The Bellemave LED TV Stand features a 16-color LED lighting system controlled by a wireless remote. This allows you to customize the ambiance of your living space.

- **Power On/Off:** Press the power button on the remote to turn the LED lights on or off.
- **Color Selection:** Use the color buttons on the remote to select from 16 different colors.
- **Brightness Adjustment:** Adjust the brightness levels using the dedicated brightness control buttons.
- **Mode Selection:** Cycle through various lighting modes (e.g., flash, strobe, fade, smooth) using the mode buttons.

16 COLOR LED LIGHTS SYSTEM

Lights with remote on/off adjustable lights depends on you



Figure 6.1: The 16-color LED light system with remote control.



Figure 6.2: Close-up of the LED lighting and acrylic lamp posts.



Figure 6.3: Detailed view of the LED light strip and its integration.

7. MAINTENANCE

To ensure the longevity and appearance of your Bellemave LED TV Stand, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the surfaces with a dry, soft cloth. For stubborn marks, a slightly damp cloth followed by a dry cloth can be used. Avoid abrasive cleaners or harsh chemicals.
- **Dusting:** Regularly dust the stand to prevent buildup, especially around the LED lights and electronic components.
- **Hardware Check:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **LED Lights:** If the LED lights malfunction, first check the power connection and remote control battery.

8. TROUBLESHOOTING

If you encounter any issues with your Bellemave LED TV Stand, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
LED lights not turning on.	Power adapter unplugged; remote battery dead; LED strip disconnected.	Ensure power adapter is securely plugged in. Replace remote battery. Check LED strip connection to the controller.
Remote control not working.	Battery dead or incorrectly inserted; remote not pointed at receiver.	Replace battery (CR2025 or similar). Ensure battery is inserted with correct polarity. Point remote directly at the LED receiver.
Stand feels wobbly.	Screws loose; uneven floor.	Retighten all assembly screws. Move the stand to a level surface or use shims to stabilize.
Drawer not sliding smoothly.	Drawer slides misaligned or damaged.	Check alignment of drawer slides. Ensure no obstructions. If damaged, contact customer service for replacement parts.

9. SPECIFICATIONS

- **Brand:** Bellemave
- **Model:** LED TV Stand for 70 inch TV
- **Material:** MDF (Medium-Density Fiberboard) and Particle Board, Glass, Acrylic
- **Color:** Black
- **Product Dimensions (L x W x H):** 51.18 x 15.75 x 20.87 inches
- **Item Weight:** Approximately 57.8 pounds
- **Accommodates TV Size:** Up to 70 inches
- **LED Lighting:** 16-color system with wireless remote control
- **Storage:** 1 large sliding drawer, 2 side cabinets, 1 open shelf with glass partition

10. WARRANTY AND SUPPORT

Bellemave is committed to providing high-quality products and excellent customer service. Your Bellemave LED TV Stand comes with a limited warranty covering manufacturing defects. For specific warranty details, please refer to the warranty card included in your package or contact our customer service.

If you have any questions, concerns, or require assistance with assembly or parts, please do not hesitate to contact our customer support team. We are dedicated to promptly addressing any inquiries you may have.

Customer Service Contact:

Refer to your purchase documentation for specific contact information or visit the official Bellemave store on Amazon.

