



[Manuals.plus](#) /

› [Cyrank](#) /

› [Cyrank Z73 Smart Watch User Manual](#)

## Cyrank Z73

# Cyrank Z73 Smart Watch User Manual

Model: Z73

## 1. INTRODUCTION

---

Thank you for choosing the Cyrank Z73 Smart Watch. This manual provides essential information for setting up, operating, and maintaining your device. Please read it carefully to ensure proper use and to maximize your experience with the smart watch.



Image 1.1: Front view of the Cyrank Z73 Smart Watch, showcasing its elegant design with a floral pink watch face.

## 2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- Cyrank Z73 Smart Watch
- Data Cable (Charging Cable)
- Strap Adjuster
- User Manual (this document)



Image 2.1: The Cyrank Z73 Smart Watch displayed alongside its included data cable and strap adjuster tool.

## 3. SPECIFICATIONS

Detailed technical specifications for the Cyrank Z73 Smart Watch:

Feature	Specification
Main Control Platform	XC2806
Memory	16+128M
Touch Mode	G+F Single Touch
Screen Size	1.09 inches (2.77 cm)
Screen Resolution	240x240 pixels
Dial Diameter	Approx. 36mm (1.4in)

Dial Thickness	Approx. 11.5mm (0.5in)
Strap Length	Approx. 220x16mm (8.7x0.6in)
Built-in Battery	200mAh Lithium Battery
Normal Use Time	About 7 Days
Standby Time	About 15 Days
Connectivity	Bluetooth, USB, GPS (via smartphone)
Item Weight	Approx. 180g (6.3oz)
Product Dimensions	0.39 x 0.39 x 0.39 inches



Image 3.1: Diagram illustrating the dimensions of the Cyrank Z73 Smart Watch, including dial diameter and thickness.



Image 3.2: Visual representation of the Cyrank Z73 Smart Watch strap length, measuring approximately 220mm (8.7 inches).

## 4. SETUP

### 4.1. Charging the Smart Watch

Before first use, fully charge your smart watch. Connect the provided data cable to the charging port on the watch and plug the USB end into a compatible power adapter (not included) or a computer's USB port. The watch display will indicate charging status.

### 4.2. App Installation

To unlock the full functionality of your Cyrank Z73 Smart Watch, you need to install the companion application on your smartphone. Scan the QR code provided in the quick start guide (if available) or search for the recommended app name in your smartphone's app store (e.g., Google Play Store for Android, Apple App Store for iOS).

### 4.3. Pairing with Your Smartphone

The Cyrank Z73 Smart Watch utilizes Dual Bluetooth (BT) connectivity. One BT connection (Z73) is for data transmission, and the other (Z73 Audio) is for audio transmission (calls, music playback).

1. Ensure your smart watch is charged and powered on.
2. Enable Bluetooth on your smartphone.
3. Open the companion app on your smartphone and follow the on-screen instructions to add a new device.
4. The app will search for available devices. Select 'Z73' from the list to establish the data connection.
5. Once the data connection is established, go to your smartphone's Bluetooth settings and manually pair with 'Z73 Audio' for call and music functions.
6. Confirm any pairing requests on both your watch and smartphone.

## 5. OPERATING INSTRUCTIONS

---

### 5.1. Basic Navigation

- **Touch Screen:** Swipe left, right, up, or down to navigate through menus and functions. Tap to select an item.
- **Side Button:** Typically used to wake the screen, return to the home screen, or access the main menu.

### 5.2. Health Monitoring Functions

The smart watch offers various health tracking features:

- **Multiple Exercise Modes:** Track different sports activities.
- **Steps:** Counts daily steps taken.
- **Sleep Monitoring:** Analyzes sleep patterns.
- **Heart Rate:** Monitors heart rate throughout the day.
- **GPS Running:** Utilizes smartphone GPS for tracking outdoor runs.

### 5.3. Reminder Functions

Stay informed with timely reminders:

- **Alarm Clock:** Set alarms directly on the watch or via the app.
- **Sedentary Reminder:** Notifies you to move after periods of inactivity.
- **Drinking Reminder:** Prompts you to drink water.
- **Message Push:** Receives notifications for calls, SMS, WeChat, QQ, Messenger, and other apps.

### 5.4. Daily Functions

Convenient features for everyday use:

- **Calls:** Make and receive calls directly from the watch.
- **Contacts:** Access your phone's contacts.
- **Call Records:** View your call history.
- **Music Playback:** Control music playing on your smartphone.
- **Custom Dial:** Personalize your watch face.
- **Multi-language Support:** Select your preferred language.
- **Recording:** Use the watch as a voice recorder.
- **Voice Control:** Interact with the watch using voice commands.
- **Weather:** Get current weather updates.
- **Calculator:** Perform basic calculations.
- **Stopwatch & Countdown:** Timing functions.
- **Remote Camera:** Control your smartphone's camera remotely.
- **Find Mobile Phone:** Locate your paired smartphone.
- **Settings:** Adjust watch settings like brightness, screen time, and themes.
- **Raise Wrist to Brighten Screen:** Automatically illuminates the screen when you raise your wrist.
- **Do Not Disturb Mode:** Silence notifications.

**INCOMING CALL ANSWERING IS NO LONGER DELAYED  
QUICKLY ANSWER INCOMING CALLS FROM FRIENDS  
ANY IMPORTANT CALL**



Image 5.1: The Cyrank Z73 Smart Watch screen showing an incoming call notification, demonstrating its call answering capability.

## HUGE AMOUNTS OF DIAL

APP massive dials and mobile phone photos to make dials at any time



Image 5.2: A selection of diverse custom watch faces available for the Cyrank Z73 Smart Watch, allowing for personalization.

### 5.5. Special Purpose Functions

The Cyrank Z73 Smart Watch includes specific features for women's health:

- **Feminine Functions:** Prediction of menstrual period, ovulation period, ovulation day, and safe period.

## 6. MAINTENANCE

To ensure the longevity and optimal performance of your smart watch, follow these maintenance guidelines:

- **Cleaning:** Regularly wipe the watch screen and strap with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, but avoid excessive moisture.
- **Avoid Extreme Temperatures:** Do not expose the watch to extreme heat or cold, as this can damage the battery and internal components.
- **Water Resistance:** Refer to the product specifications for water resistance ratings. Avoid submerging the watch beyond its rated depth or exposing it to hot water, steam, or chemicals.
- **Charging:** Use only the provided data cable for charging. Avoid using damaged cables or chargers.
- **Storage:** When not in use for extended periods, store the watch in a cool, dry place.

## 7. TROUBLESHOOTING

---

If you encounter issues with your Cyrank Z73 Smart Watch, try the following steps:

- **Watch Not Turning On:** Ensure the watch is fully charged. Connect it to the charger for at least 30 minutes.
- **Cannot Pair with Phone:**
  - a. Ensure Bluetooth is enabled on your phone and the watch.
  - b. Make sure the watch is within range of your phone.
  - c. Restart both your phone and the watch.
  - d. Clear the Bluetooth cache on your phone (if applicable) and try pairing again.
  - e. Ensure the companion app is installed and running.
- **Notifications Not Received:**
  - a. Check if the watch is properly paired and connected to the app.
  - b. Verify notification permissions are granted to the app on your phone.
  - c. Ensure 'Do Not Disturb' mode is not active on the watch or phone.
- **Inaccurate Health Data:** Ensure the watch is worn snugly on your wrist, but not too tight. Clean the sensor on the back of the watch.
- **Short Battery Life:** Reduce screen brightness, disable unnecessary features, and ensure background app usage is optimized on your phone.
- **Restore Factory Settings:** If issues persist, you may try restoring the watch to factory settings via the watch's menu or the companion app. Note that this will erase all data on the watch.

## 8. WARRANTY AND SUPPORT

---

The Cyrank Z73 Smart Watch comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package or contact your retailer for specific warranty terms and conditions. For technical support or further assistance, please reach out to Cyrank customer service through the contact information provided with your purchase or on the official Cyrank website.