

Best Choice Products SKY7174

Best Choice Products 61-Key Electronic Keyboard Piano Set Instruction Manual

Model: SKY7174

Brand: Best Choice Products

INTRODUCTION

Welcome to your new Best Choice Products 61-Key Electronic Keyboard Piano Set. This comprehensive set is designed for beginners and aspiring musicians, offering a full range of features to facilitate learning and musical expression. With lighted keys, multiple teaching modes, and a complete accessory bundle, you'll be playing your favorite tunes in no time. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your instrument.



Image: The complete 61-key electronic keyboard piano set, including the keyboard, adjustable stand, padded bench, and a music rest with a tablet displaying sheet music.

WHAT'S INCLUDED

Your Best Choice Products 61-Key Electronic Keyboard Piano Set comes with the following components:

- 1 x 61-Key Electronic Keyboard
- 1 x H-Style Keyboard Stand
- 1 x Padded Stool (Bench)
- 1 x Music Stand (Holder)
- 1 x Headphones
- 1 x Note Stickers for keys
- Power Adapter

WHAT'S INCLUDED



x1 Keyboard




x1 Headphone



x1 Note Stickers



x1 Holder



x1 Stand



x1 Chair

Image: A visual representation of all components included in the package: the keyboard, headphones, note stickers, a blue music holder, the black keyboard stand, and the black padded stool.

SETUP

1. **Assemble the Keyboard Stand:** Unfold the H-style keyboard stand and adjust it to a comfortable height. Ensure all locking mechanisms are securely fastened to prevent wobbling.
2. **Assemble the Padded Stool:** Unfold the padded stool and ensure it is stable.
3. **Place the Keyboard:** Carefully place the 61-key electronic keyboard onto the assembled stand. Ensure it is centered and stable.
4. **Attach the Music Stand:** Insert the music stand into the designated slot on the top of the keyboard.
5. **Apply Note Stickers (Optional):** If desired, carefully apply the provided note stickers to the keys. These can assist beginners in identifying notes.
6. **Connect Power:** Plug the power adapter into the DC IN port on the back of the keyboard, then plug the adapter into a standard electrical outlet.
7. **Power On:** Press the **POWER** button on the keyboard to turn it on.

OPERATING INSTRUCTIONS

Basic Operation

- **Volume Control:** Use the volume knob or buttons to adjust the overall sound level.
- **LCD Screen:** The LCD screen displays current settings, selected timbre, rhythm, and teaching mode information.
- **Headphone Jack:** For private practice, plug the included headphones into the 3.5mm headphone jack. This mutes the built-in speakers.



Image: The included headphones, featuring padded speakers, designed for comfortable and private practice sessions.

Teaching Modes

The keyboard features three teaching modes to assist beginners:

- **One-Key Mode:** Allows you to play along with demo songs by pressing any key. The keyboard will play the correct note.
- **Follow Mode:** The keyboard waits for you to play the correct note before proceeding with the song.

- **Ensemble Mode:** You play the melody while the keyboard plays the accompaniment.

The light-up keys feature provides visual guidance, illuminating the correct keys to press during teaching modes or demo songs.

LEARN BY PLAYING

Follow along as keys light up in teaching mode and play your way to proficiency!



Image: A close-up of hands playing the keyboard, with several keys illuminated in red, demonstrating the "Learn by Playing" feature with lighted keys.

Sound Customization

Explore the various sound options to enhance your musical creations:

- **Timbres (255):** Select from a wide range of instrument sounds. Refer to the keyboard's panel for a list of available timbres.
- **Rhythms (255):** Choose from various rhythm patterns to accompany your playing.
- **Demo Songs (50):** Play along or listen to pre-recorded demo songs.
- **Keyboard Percussion (32 types):** Access different percussion sounds directly from the keys.
- **Rhythm Programmer:** Create and program your own rhythm sequences.

CUSTOMIZE YOUR SOUND

Create your own full masterpiece when you mix timbres and rhythms or explore the keyboard percussion sounds



255
Timbres



255
Rhythms



50
Demo
Songs



32
Percussions
Sounds



Image: A detailed view of the keyboard's control panel, highlighting the extensive options for sound customization, including 255 timbres, 255 rhythms, 50 demo songs, and 32 percussion sounds.

USB Port Functionality

The integrated USB port allows you to connect a USB drive and play along to songs stored on it. This feature enables you to practice with your favorite tracks or add your own melodies and rhythms to background music.

MAINTENANCE

- Cleaning:** Use a soft, dry cloth to wipe down the keyboard and accessories. Avoid using abrasive cleaners or solvents, as they may damage the finish.
- Storage:** When not in use, store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- Handling:** Handle the keyboard and its components with care to prevent physical damage. Avoid dropping or placing heavy objects on the keys.
- Power:** Always turn off the keyboard and unplug it from the power outlet when not in use for extended periods or during electrical storms.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound from speakers/headphones	Volume too low; Headphones not fully inserted; Power not connected.	Increase volume; Re-insert headphones firmly; Ensure power adapter is connected and keyboard is on.
Keys not lighting up	Light-up key feature is off; Not in a teaching mode that uses lighted keys.	Activate the key lighting feature (refer to keyboard controls); Select a teaching mode (One-Key, Follow, Ensemble).
Keyboard not turning on	Power adapter not connected; Power outlet issue.	Check power adapter connection; Try a different power outlet.
Distorted sound	Volume too high; Loose connections.	Lower volume; Check all cable connections.

If you encounter issues not listed here, please refer to the manufacturer's support information.

SPECIFICATIONS

Brand: Best Choice Products

Model Name: 61-Key Beginners Electronic Keyboard Piano Set w/ Lighted Keys, Headphones

Model Number: SKY7174

Number of Keys: 61

Timbres: 255

Rhythms: 255

Demo Songs: 50

Keyboard Percussion: 32 types

Product Dimensions: 36.4" (L) x 12" (W) x 3.7" (H)

Item Weight: 17.2 Pounds

Color: Blue

Material Type: Plastic

Connectivity Technology: USB

Headphones Jack: 3.5mm Jack

Skill Level: Beginner

Special Feature: Portable

UPC: 842957136353

PRODUCT DIMENSIONS





Image: A visual guide illustrating the key dimensions of the keyboard (36.4" L x 12" W x 9.5" H with music rest), the keyboard stand (32" W x 15" D x 22.5-27" H adjustable), and the padded stool (16" L x 12" W x 19" H).

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the documentation included with your product or visit the official Best Choice Products website. You can also contact their customer service for assistance with any product-related inquiries or issues.

Protection plans are available for purchase separately. Please refer to the product listing or contact Best Choice Products for more details on extended protection options.



[61-Key Electronic Teaching Keyboard Instruction Manual](#)

Comprehensive instruction manual for the 61-Key Electronic Teaching Keyboard by Best Choice Products. Learn about assembly, features, functions, and basic operation.

lang:en score:36 filesize: 438.93 K page_count: 16 document date: 2023-08-30