

Riobel ED08+

Riobel ED08+ Edge 1.2 GPM Widespread Bathroom Faucet User Manual

Model: ED08+

1. INTRODUCTION

This manual provides essential instructions for the installation, operation, and maintenance of your Riobel ED08+ Edge 1.2 GPM Widespread Bathroom Faucet. Please read this manual thoroughly before installation and retain it for future reference. The Edge faucet collection features a unique design with a subtle trumpet-shaped tip and base, offering a versatile aesthetic for various bathroom styles.

2. SAFETY INFORMATION

- Always turn off the main water supply before beginning any installation or maintenance work.
- Wear appropriate personal protective equipment, such as safety glasses and gloves.
- If you are unsure about any part of the installation process, it is recommended to consult a qualified professional plumber.
- Ensure all connections are secure to prevent leaks.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Faucet Spout Assembly
- Hot and Cold Handle Assemblies
- Drain Assembly
- Mounting Hardware and Gaskets
- Water Supply Lines (typically included or purchased separately)

4. SETUP AND INSTALLATION

The Riobel ED08+ faucet is designed for widespread, deck-mounted installation requiring three faucet holes.



Figure 1: Riobel ED08+ Edge Widespread Bathroom Faucet in Black. This image displays the complete faucet set, including the high-arc spout, two cross-handle controls, and a matching drain assembly, all in a matte black finish.

Pre-Installation Steps:

1. Turn off the hot and cold water supply valves under the sink or at the main water supply.
2. Clear the area under the sink for easy access.
3. Remove any existing faucet and clean the mounting surface.

Installation Procedure:

1. **Install Faucet Spout:** Insert the faucet spout through the center hole of the sink or countertop. Secure it from underneath with the provided washer and mounting nut. Ensure the spout is properly oriented.
2. **Install Handle Assemblies:** Insert the hot and cold handle assemblies through the outer holes. Secure them from underneath with their respective washers and mounting nuts.
3. **Connect Water Supply Lines:** Attach the hot and cold water supply lines to the corresponding inlets on the faucet body and to the water supply valves. Hand-tighten, then use a wrench for a quarter turn. Do not overtighten.
4. **Install Drain Assembly:** Follow the instructions provided with the drain assembly to install it into the sink drain.

hole. Ensure a watertight seal.

5. **Test for Leaks:** Once all connections are made, slowly turn on the main water supply. Check all connections for leaks. If leaks occur, tighten the connections slightly.

5. OPERATION

The Riobel ED08+ faucet features dual cross handles for controlling water flow and temperature.

- **Cold Water:** Turn the right handle counter-clockwise to open for cold water.
- **Hot Water:** Turn the left handle counter-clockwise to open for hot water.
- **Temperature Control:** Adjust the mix of hot and cold water by rotating both handles simultaneously to achieve the desired temperature.
- **Flow Control:** The further the handles are turned, the greater the water flow.

6. MAINTENANCE

Cleaning:

To maintain the finish of your faucet, clean it regularly with a soft, damp cloth. Avoid using abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the finish. For stubborn spots, a mild soap solution can be used, followed by rinsing with clean water and drying with a soft cloth.

Aerator Maintenance:

If water flow decreases, the aerator may be clogged. Unscrew the aerator from the tip of the spout, clean any debris or mineral deposits, and then reattach it securely.

Ceramic Disc Valves:

The faucet is equipped with durable ceramic disc valves, which typically require no maintenance. If a leak occurs from the handles, contact customer support.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator; partially closed water supply valves; debris in supply lines.	Clean aerator; ensure water supply valves are fully open; flush supply lines.
Leaks from Faucet Base	Loose mounting nuts; improper sealing.	Tighten mounting nuts; ensure gaskets are correctly seated.
Leaks from Handles	Worn O-rings or ceramic disc cartridge.	Contact Riobel customer support for replacement parts or service.
Water Temperature Issues	Incorrect hot/cold supply line connection; water heater issues.	Verify supply line connections; check water heater settings.

8. SPECIFICATIONS

Feature	Specification
Brand	Riobel
Model Number	ED08+
Mounting Type	Deck Mount, Widespread
Finish	Black
Material	Brass (Faucet Body), Brass/Ceramic (Handles)
Flow Rate	1.2 gallons-per-minute (GPM)
Faucet Centers	8" to 16"
Spout Height	4-5/8" (deck to spout outlet)
Spout Reach	3-3/4" (faucet base to spout outlet)
Overall Height	7-1/4" (deck to top of faucet)
Maximum Deck Thickness	1-3/4"
Faucet Hole Size	1-1/4"
Number of Faucet Holes	3 (minimum)
Item Weight	6.3 pounds
UPC	883186534190

9. WARRANTY AND SUPPORT

The Riobel ED08+ faucet is covered under Riobel's limited warranty. The faucet body is constructed of brass, which is highly resistant to corrosion and suitable for high temperatures. For specific warranty details, claims, or technical assistance, please contact Riobel customer support directly. Keep your proof of purchase for warranty purposes.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question