

[Manuals.plus](#) /

› [AGARO](#) /

› AGARO Royal Electric Spin Scrubber Replacement Brush Heads 10-in-1 Instruction Manual

AGARO Royal Electric Spin Scrubber

AGARO Royal Electric Spin Scrubber Replacement Brush Heads 10-in-1 Instruction Manual

1. PRODUCT OVERVIEW

This manual provides instructions for the AGARO Royal Electric Spin Scrubber Replacement Brush Heads 10-in-1 kit. This kit is designed to enhance the cleaning capabilities of your AGARO Royal Electric Spin Scrubber, offering versatile solutions for various cleaning tasks around your home.

The kit includes a variety of brush heads tailored for different surfaces and cleaning needs, ensuring efficient and thorough cleaning of bathrooms, bathtubs, stone tile floors, grout, and other areas.

What's in the Box:

- 1 pc Wool Brush
- 5 pcs Large Bristle Brushes
- 4 pcs Fibre Sponge Brushes

1 Pcs wool cloth brush



Image: The complete AGARO Royal Electric Spin Scrubber 10-in-1 Replacement Brush Head Kit, showcasing all included brush types.

Your browser does not support the video tag.

Video: An overview of the AGARO Royal Electric Spin Scrubber Kit, demonstrating the various brush heads and their applications for different cleaning tasks.

2. SAFETY INFORMATION

- Always ensure the electric spin scrubber is turned off before attaching or detaching brush heads.
- Do not immerse the entire handle of the electric spin scrubber in water. The brush head attachment area is designed for wet cleaning, but the main unit should be protected from excessive moisture.
- Keep the product and its accessories out of reach of children.
- Use appropriate cleaning agents for the surface being cleaned. Avoid harsh chemicals that may damage the brush heads or the surfaces.
- Inspect brush heads for wear or damage before each use. Replace worn-out brush heads to maintain optimal cleaning performance and prevent potential damage to surfaces.

- Do not use the scrubber on delicate surfaces that may be scratched or damaged by abrasive action. Test on an inconspicuous area first.

3. SETUP

Attaching and Detaching Brush Heads:

1. Ensure the AGARO Royal Electric Spin Scrubber is powered off.
2. Align the desired brush head with the attachment point on the scrubber.
3. Press firmly and twist clockwise until the brush head clicks securely into place.
4. To detach, twist counter-clockwise and pull the brush head off.

5 Pcs large bristle brush



Image: A large bristle brush head being attached to the AGARO Royal Electric Spin Scrubber.

4 Pcs fiber sponge brush



Image: A fiber sponge brush head being attached to the AGARO Royal Electric Spin Scrubber.

Assembling the Extension Rod:

The extension rod allows for cleaning hard-to-reach areas without bending or kneeling. To assemble, align the extension rod with the main handle and twist to secure. To adjust the length, rotate the handle and pull it out to the desired length, then twist to lock.

4. OPERATING INSTRUCTIONS

Powering On and Speed Settings:

- Press the power button to turn on the scrubber.
- The scrubber has two speed settings: Low speed (250 RPM) for gentle cleaning and High speed (350 RPM) for tougher stains.
- Press the power button again to cycle through the speed settings.
- Press and hold the power button to turn off the scrubber.

Cleaning Tips:

- **Wool Brush:** Ideal for polishing and gentle cleaning of delicate surfaces.
- **Large Bristle Brushes:** Suitable for general scrubbing of larger areas like bathtubs, shower walls, and floor tiles.
- **Fibre Sponge Brushes:** Excellent for tackling stubborn grime on kitchen countertops, sinks, and grout lines.
- Apply a small amount of appropriate cleaning solution directly to the surface or the brush head before scrubbing.
- For optimal results, allow the scrubber to do the work; avoid applying excessive pressure.

Multi purpose cleaning



Image: The AGARO Royal Electric Spin Scrubber in use for multi-purpose cleaning, demonstrating its versatility.

5. MAINTENANCE

Cleaning Brush Heads:

- After each use, detach the brush head from the scrubber.

- Rinse the brush head thoroughly under running water to remove any dirt, debris, or cleaning solution residue.
- For stubborn residue, a mild soap can be used.
- Allow brush heads to air dry completely before storing.

Charging the Scrubber:

The electric spin scrubber has a battery capacity of up to 2500 mAh and provides approximately 90 minutes of operation on a full charge. Refer to your main AGARO Royal Electric Spin Scrubber manual for specific charging instructions and indicators.

6. TROUBLESHOOTING

- **Brush head not spinning:** Ensure the brush head is securely attached and the main scrubber unit is charged and powered on.
- **Reduced cleaning performance:** Check if the brush head is worn out and needs replacement. Ensure sufficient cleaning solution is applied.
- **Scrubber not turning on:** Verify that the battery is charged. Connect to the charger and allow sufficient time for charging.

7. SPECIFICATIONS

Feature	Detail
Brand	AGARO
Colour	White (Scrubber unit, brush heads vary)
Handle Material	Plastic
Specific Uses For Product	Cleaning (Bathrooms, Bathtubs, Stone Tile Floors, Grout)
Product Dimensions	6L x 6W x 10H Centimeters (Approximate for brush heads)
Surface Recommendation	Grout, Tiles, Bathtubs, various hard surfaces
Number of Items	1 (Kit includes 10 brush heads)
Country of Origin	China
Item Type Name	Spin Scrubber (Replacement Heads)
Item Weight	70 Grams (Approximate for the kit)
Other Special Features	Reusable brush heads
Product Firmness	Medium (Varies by brush type)

8. WARRANTY AND SUPPORT

The AGARO Royal Electric Spin Scrubber (main unit) typically comes with a 1-year warranty. Please refer to the warranty card included with your original purchase for specific terms and conditions. For any product-related queries,

technical support, or warranty claims, please contact AGARO customer service through their official website or the retailer where the product was purchased.

Manufacturer: Universal Corporation Limited, Zhejiang, China

Importer Contact Information: Universal Corporation Limited, 4/1 Middleton Street, Sikkim Commerce House, Kolkata-71

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CNLP7T43>

More documents and user manuals: <https://manuals.plus/>