**KST-900**

# Serve Wireless Headphone KST-900 Black - User Manual

Model: KST-900 | Brand: Generic

## INTRODUCTION

Thank you for choosing the Serve Wireless Headphone KST-900 Black. This manual provides essential information for the safe and efficient operation of your new wireless headphones. Please read this manual thoroughly before use and retain it for future reference.
The Serve Wireless Headphone is designed for comfortable listening to music and making phone calls, featuring excellent tone quality and a humanized design for extended wear.

## SAFETY INFORMATION

- Do not expose the headphones to extreme temperatures, humidity, or corrosive substances.
- Avoid dropping or subjecting the headphones to strong impacts.
- Do not disassemble or modify the headphones. This may void the warranty and pose a safety risk.
- Clean the headphones with a soft, dry cloth. Do not use liquid cleaners.
- Listen at moderate volume levels to prevent hearing damage. Prolonged exposure to loud sounds can cause irreversible hearing loss.
- Keep out of reach of children.

## PACKAGE CONTENTS

Please check the package contents to ensure all items are present:

- 1 x Serve Wireless Headphone KST-900 Black
- 1 x Charging Cable (USB)
- 1 x Audio Cable (3.5mm Jack)

Image: The Serve Wireless Headphone KST-900 Black, along with its charging cable and 3.5mm audio cable, neatly arranged within its packaging tray.

## PRODUCT OVERVIEW

The Serve Wireless Headphone KST-900 features a comfortable over-ear design with soft earcups for extended listening. It includes integrated controls for easy operation and a built-in microphone for hands-free calls.

Image: A side view of the Serve Wireless Headphone KST-900 Black, showcasing its foldable design and over-ear earcups.

## Key Features:

- Soft & comfortable earcups for prolonged use.
- Superior Sound Quality for an immersive audio experience.
- Built-in microphone for hands-free call function.
- Long battery life: Up to 6 hours for music, 8 hours for calls.
- Excellent compatibility with Wireless 4.2 technology.
- Foldable design for easy portability.

## SETUP

### 1. Charging the Headphones

Before first use, fully charge the headphones. A full charge takes approximately 1.5 hours.

1. Connect the small end of the USB charging cable to the charging port on the headphone.
2. Connect the other end of the USB charging cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator light will illuminate during charging and turn off or change color once fully charged.

## 2. Bluetooth Pairing

Pair your headphones with your device (smartphone, tablet, laptop) to enable wireless audio.

1. Ensure the headphones are fully charged and turned off.
2. Press and hold the Power/Multi-function button on the headphones until the LED indicator light flashes rapidly (usually blue and red alternately), indicating pairing mode.
3. On your device, go to Bluetooth settings and ensure Bluetooth is enabled.
4. Search for available devices. You should see "KST-900" or "Serve Headphone" in the list.
5. Select "KST-900" to connect. Once connected, the LED indicator light will typically flash slowly or turn solid blue.
6. If prompted for a password, enter "0000".

*Note: The headphones will automatically attempt to reconnect to the last paired device when powered on.*

## OPERATING INSTRUCTIONS

## Power On/Off

- **Power On:** Press and hold the Power/Multi-function button for approximately 3 seconds until the LED indicator lights up.
- **Power Off:** Press and hold the Power/Multi-function button for approximately 3-5 seconds until the LED indicator turns off.

## Music Playback

- **Play/Pause:** Press the Power/Multi-function button once.
- **Next Track:** Press and hold the Volume Up (+) button.
- **Previous Track:** Press and hold the Volume Down (-) button.
- **Volume Up:** Short press the Volume Up (+) button.
- **Volume Down:** Short press the Volume Down (-) button.

## Call Function

- **Answer Call:** Press the Power/Multi-function button once when an incoming call rings.
- **End Call:** Press the Power/Multi-function button once during a call.
- **Reject Call:** Press and hold the Power/Multi-function button for approximately 2 seconds when an incoming call rings.
- **Redial Last Number:** Double-press the Power/Multi-function button.

## Wired Mode (3.5mm Audio Cable)

You can use the headphones with the included 3.5mm audio cable when the battery is low or for devices without Bluetooth connectivity.

- Plug one end of the 3.5mm audio cable into the audio input jack on the headphone.
- Plug the other end into the 3.5mm audio output jack of your device.
- In wired mode, the headphone's built-in controls may not function, and audio control will be managed by your connected device.

# MAINTENANCE

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the headphones. Do not use abrasive cleaners, alcohol, or chemical solvents.
- **Storage:** When not in use, store the headphones in a cool, dry place, away from direct sunlight and extreme temperatures. The foldable design allows for compact storage.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the headphones regularly, even if not in frequent use.

# TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---|---|---|
| Headphones do not power on. | Battery is low or depleted. | Charge the headphones fully. |
| Cannot pair with device. | Headphones not in pairing mode; Bluetooth off on device; device too far. | Ensure headphones are in pairing mode (flashing red/blue). Turn on Bluetooth on your device. Move headphones closer to the device (within 10m). Forget previous pairings on your device and try again. |
| No sound or low volume. | Volume too low on headphones or device; headphones not connected; incorrect audio output selected. | Increase volume on both headphones and device. Ensure headphones are properly paired/connected. Check audio output settings on your device. Try using the 3.5mm audio cable. |
| Poor sound quality. | Interference; device too far; low battery. | Move away from sources of interference (Wi-Fi routers, other Bluetooth devices). Move headphones closer to the device. Charge the headphones. |
| Microphone not working. | Incorrect microphone input selected on device; software issue. | Check microphone input settings on your device. Restart your device. |

# SPECIFICATIONS

| Feature | Detail |
|---|---|
| Model Name | Wireless headphone KST-900 |
| Connectivity Technology | Wireless (Bluetooth 4.2) |
| Wireless Protocol | A2DP, AVRCP, HFP, HSP |
| Communication Distance | Up to 10 meters (33 feet) |
| Battery Capacity | 150 mAh |
| Charging Time | Approx. 1.5 hours |
| Music Playback Time | Up to 6 hours |
| Call Time | Up to 8 hours |

| Feature | Detail |
| --- | --- |
| Material | Quality ABS Plastic |
| Microphone Format | Built-In |
| Form Factor | Over-Ear, Foldable |
| Headphones Jack | 3.5 mm Jack (for wired use) |
| Manufacturer | in one smart technology (H.K) LTD |

## WARRANTY AND SUPPORT

### Warranty Information

This Serve Wireless Headphone KST-900 Black comes with a **1 Year Warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal use.
The warranty does not cover:

- Damage caused by accident, abuse, misuse, liquid contact, fire, or other external causes.
- Damage caused by operating the product outside the guidelines published in this manual.
- Damage caused by service performed by anyone who is not an authorized representative of the manufacturer.
- Cosmetic damage, including but not limited to scratches, dents, and broken plastic on ports.

Please retain your proof of purchase for warranty claims.

### Customer Support

For technical support, warranty claims, or any inquiries regarding your Serve Wireless Headphone KST-900 Black, please contact your retailer or the manufacturer's customer service department. Refer to your purchase documentation for contact details.