

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Infinix](#) /

> [Infinix Smart 8 Smartphone User Manual \(Model X6525\)](#)

## Infinix Smart 8

# Infinix Smart 8 Smartphone User Manual

Model: X6525

## INTRODUCTION

---

This manual provides essential information for the safe and efficient use of your Infinix Smart 8 smartphone. Please read it thoroughly before operating your device.

## Package Contents

Upon unpacking, verify that the following items are included:

- Infinix Smart 8 Smartphone
- Power Adapter
- USB Type-C Cable
- Headset
- Phone Cover
- Screen Protector (pre-applied or in box)
- SIM Ejector Tool
- Quick Start Guide (this document)



Image: Front and back view of the Infinix Smart 8 smartphone, highlighting its design and camera module.

## SAFETY INFORMATION

---

- Do not use the device in extreme temperatures.
- Avoid exposing the device to water or excessive moisture.
- Use only approved chargers and accessories.
- Do not attempt to disassemble or repair the device yourself.
- Keep the device away from medical devices and pacemakers.
- Dispose of the device and its battery responsibly according to local regulations.

## SETUP

---

### 1. Inserting SIM and SD Cards

1. Locate the SIM card tray on the side of your device.
2. Insert the SIM ejector tool into the small hole next to the tray and press gently until the tray pops out.
3. Place your Nano SIM card(s) and/or microSD card into the designated slots on the tray, ensuring correct orientation.
4. Carefully push the tray back into the device until it clicks into place.



Image: Side view of the Infinix Smart 8, illustrating the location of the SIM card tray.

## 2. Powering On and Initial Setup

1. Press and hold the Power button (located on the side) until the Infinix logo appears.
2. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set up your Google account.
3. You will also be guided through setting up security features like fingerprint unlock and face unlock.

## OPERATING YOUR DEVICE

---

## Basic Navigation

Your Infinix Smart 8 features a 6.6-inch HD+ touchscreen with a 90Hz refresh rate for smooth interaction. Use standard Android gestures:

- **Tap:** Select an item or open an app.
- **Swipe:** Navigate between screens, scroll through lists.
- **Pinch:** Zoom in or out on photos and web pages.

## Making Calls and Sending Messages

- Open the **Phone** app to dial numbers or access contacts.
- Open the **Messages** app to send and receive SMS/MMS.

## Camera Usage

The device is equipped with a 13MP dual AI rear camera and an 8MP front camera. Open the **Camera** app to capture photos and videos.

- **Rear Camera:** Utilizes AI for enhanced image processing and includes a ring flash for improved lighting.
- **Front Camera:** Ideal for selfies and video calls.



Image: Rear view of the Infinix Smart 8, detailing the dual AI camera setup and ring flash.

## Security Features

- **Side Fingerprint Sensor:** Register your fingerprint(s) in Settings > Security to unlock your device quickly and securely.
- **Face Unlock:** Set up face recognition in Settings > Security for convenient unlocking.

## Connectivity

- **Wi-Fi:** Connect to wireless networks via Settings > Network & internet > Wi-Fi.
- **Bluetooth:** Pair with other Bluetooth devices (headphones, speakers) via Settings > Connected devices > Bluetooth.
- **Cellular Data:** Manage your mobile data usage and settings via Settings > Network & internet > Mobile network.

## MAINTENANCE

## Charging the Battery

Your device is powered by a 5000mAh battery. Use the provided USB Type-C cable and power adapter to charge your phone. Connect the Type-C end to the phone's charging port and the adapter to a power outlet.

## Software Updates

Regularly check for software updates to ensure your device has the latest features and security patches. Go to Settings > System > System update.

## Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of your phone. Avoid using harsh chemicals or abrasive materials.

## Storage Management

Your device comes with 64GB of internal storage. To manage storage, go to Settings > Storage. You can free up space by deleting unnecessary files, uninstalling apps, or moving media to a microSD card (if installed).

## TROUBLESHOOTING

- **Device not turning on:** Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again.
- **Device freezing or unresponsive:** Press and hold the Power button for about 10-15 seconds to force a restart.
- **Network issues (no signal, cannot connect to Wi-Fi):** Check if Airplane mode is off. Restart the device. For Wi-Fi, forget the network and reconnect. For cellular, ensure SIM card is properly inserted.
- **Apps crashing:** Clear the app's cache (Settings > Apps > [App Name] > Storage & cache > Clear cache). If the issue persists, try reinstalling the app.
- **Battery draining quickly:** Reduce screen brightness, close unused apps, disable unnecessary background processes, and limit location services.

## SPECIFICATIONS

| Feature            | Detail                  |
|--------------------|-------------------------|
| Model Name         | Smart 8                 |
| Model Number       | X6525                   |
| Operating System   | Android 13.0            |
| RAM                | 3GB (expandable to 6GB) |
| Internal Storage   | 64GB                    |
| Display Size       | 6.6 inches              |
| Display Resolution | 1280 x 720 (HD+)        |
| Refresh Rate       | 90 Hz                   |

| Feature            | Detail                                     |
|--------------------|--|
| Rear Camera        | 13MP Dual AI Camera                        |
| Front Camera       | 8MP  |
| Battery Capacity   | 5000 mAh                                   |
| Connectivity       | Bluetooth, Wi-Fi, Cellular (Dual Nano SIM) |
| Charging Port      | USB Type-C                                 |
| Audio Jack         | 3.5 mm                                     |
| Dimensions (LxWxH) | 16.36 x 7.56 x 0.85 cm                     |
| Weight             | 184 grams                                  |
| Special Features   | Side Fingerprint Sensor, Face Unlock, GPS  |

## WARRANTY AND SUPPORT

Your Infinix Smart 8 device is covered by a limited warranty. For detailed warranty terms and conditions, please refer to the warranty card included in your product packaging or visit the official Infinix website. For technical support, service, or further inquiries, please contact Infinix customer service through their official channels. You can find more information and support resources on the official Infinix website: [www.infinixmobility.com](http://www.infinixmobility.com)