

AKLT43S-DFS6T

Generic Remote Control for AKAI Smart LED Fire TV AKLT43S-DFS6T User Manual

INTRODUCTION

This manual provides essential instructions for the Generic replacement remote control, specifically designed for use with AKAI Smart LED Fire TV model AKLT43S-DFS6T. This remote offers a compact and lightweight design with an ergonomic grip for comfortable use. Please read this manual carefully to ensure proper setup and operation.

Important: Before proceeding, please compare the image of this remote control with your existing remote to ensure compatibility.



Figure 1: Message advising users to match the remote with their old one before use.

IMPORTANT INFORMATION AND COMPATIBILITY

Please observe the following critical information regarding the use and compatibility of this remote control:

- This remote control is designed to work exclusively with AKAI Fire TV models.
- This is a standard infrared remote control and does not support voice commands or Alexa functionality.
- This remote control is not compatible with Amazon Fire Stick devices or any other non-AKAI Fire TV devices.



HAVE A QUESTION ON YOUR MIND?



We are here to help



9982096292



Figure 2: Visual warning highlighting compatibility restrictions and lack of voice control.

SETUP

Battery Installation

This remote control requires two (2) AAA batteries for operation. Ensure you use new batteries for optimal performance.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Note: Always replace both batteries at the same time with new ones. Do not mix old and new batteries, or different types of batteries.

OPERATING INSTRUCTIONS

Once batteries are installed, the remote control is ready for use. Point the remote directly at your AKAI Smart LED Fire TV.



ATTENTION



- ***THIS REMOTE WORKS WITH AKAI FIRE TV ONLY*** 
- ***THIS IS A NON ALEXA REMOTE AND DOESN'T SUPPORT ALEXA*** 
- ***THIS REMOTE DOESN'T WORK WITH AMAZON FIRESTICK OR ANY OTHER DEVICE***

For any other queries, please
get in touch with our team at
+91-9982096292

Figure 3: Front view of the remote control with various buttons.

Key Functions

- **Power Button (Navigation Pad (Circle with directional arrows)):** Use the up, down, left, and right arrows to navigate menus and select items. The center button acts as 'OK' or 'Select'.
- **Back Button (Home Button (Menu Button (Three horizontal lines)):** Opens context-sensitive menus or options.
- **Rewind, Play/Pause, Fast Forward Buttons:** Control media playback.
- **Volume Up/Down (-):** Adjusts the TV volume.
- **Mute Button (Settings Button (Live TV/Guide Button (TV icon)):** Accesses live TV channels or program guide.
- **App Shortcut Buttons (Prime Video, Netflix, Amazon Music, Apps):** Direct access to specified applications.

MAINTENANCE

Cleaning the Remote Control

To maintain the remote control's appearance and functionality:

- Wipe the surface with a soft, dry cloth.
- For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Do not use harsh chemicals, solvents, or abrasive cleaning pads, as these can damage the remote's finish or internal components.

Battery Care

- Remove batteries if the remote control will not be used for an extended period to prevent leakage.
- Dispose of used batteries responsibly according to local regulations.

TROUBLESHOOTING

If you encounter issues with your remote control, try the following solutions:

- Remote Not Responding:
 - Ensure new AAA batteries are correctly installed with the correct polarity.
 - Check if there are any obstructions between the remote control and the TV's infrared receiver.
 - Point the remote directly at the TV.
 - Try replacing the batteries with a fresh set.
- Specific Buttons Not Working:
 - Clean the remote control, especially around the unresponsive buttons, to remove any dirt or debris.
 - Ensure the remote is within effective range and pointed correctly.
- Interference:
 - Bright lights or other electronic devices can sometimes interfere with infrared signals. Try moving such devices or adjusting lighting.

SPECIFICATIONS

Feature	Detail
Brand	Generic
Compatible Devices	AKAI Smart LED Fire TV AKLT43S-DFS6T
Connectivity Technology	Infrared (IR)
Special Feature	Ergonomic Design
Power Source	2 x AAA Batteries (Alkaline recommended)
Color	Black

Max Number of Supported
Devices

1 (Television)

SUPPORT

If you have any questions or require further assistance with your remote control, please do not hesitate to contact our support team.

Dear Buyer,

**Please match your old
remote with the image
before placing the order**

**For any help, contact us
at +91-9982096292**

Figure 4: Contact information for customer support.

Contact Number: [+91-9982096292](tel:+91-9982096292)

