

## syitren SN13

# syitren PARON II Record Player User Manual

Model: SN13

## 1. IMPORTANT SAFETY INSTRUCTIONS

Please read and understand all safety instructions before operating this product. Keep this manual for future reference.

- Do not expose the unit to rain, moisture, or extreme temperatures.
- Avoid placing the unit near heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this unit during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way.
- Ensure proper ventilation around the unit. Do not block any ventilation openings.
- Protect the power cord from being walked on or pinched.

## 2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1x syitren PARON II Record Player
- 1x User Manual
- 1x Dust Cover
- 1x 12V AC Power Adapter



Image: The sytren PARON II Record Player with its dust cover open, showcasing the turntable and tonearm. This image provides an overall view of the product as received in the package.

### 3. PRODUCT OVERVIEW

Familiarize yourself with the main components of your sytren PARON II Record Player.



Image: Front view of the record player, highlighting the integrated speakers behind the grille.





Image: Side view of the record player, showing the walnut wood finish.



Image: Close-up of the control panel, featuring volume knob, tone controls, and playback buttons.



Image: Detailed view of the AT3600L magnet-type cartridge and stylus, essential for accurate record playback.

## 4. SETUP

1. **Unpack the Unit:** Carefully remove the record player and all accessories from the packaging.
2. **Place the Dust Cover:** Position the dust cover onto the hinges at the back of the unit.
3. **Connect Power:** Plug the 12V AC power adapter into the DC IN port on the back of the record player, then plug the adapter into a wall outlet.
4. **Adjust Counterweight:** The tonearm features an adjustable counterweight. Carefully balance the tonearm so it floats horizontally. Then, rotate the counterweight to the recommended tracking force (refer to cartridge specifications, typically around 2.5g for the AT3600L). This ensures optimal sound quality and prevents record damage.
5. **Anti-Skating Adjustment:** The anti-skating system helps prevent the stylus from skipping. Adjust this setting according to the instructions provided with the cartridge or by testing with a blank record.





Image: A hand adjusting the counterweight on the tonearm, a crucial step for proper stylus tracking and sound reproduction.

## 5. OPERATING INSTRUCTIONS

### 5.1 Playing a Vinyl Record

1. **Power On:** Turn the power knob to switch on the unit.
2. **Select Speed:** Choose the appropriate speed (33 or 45 RPM) for your vinyl record using the speed selector switch.
3. **Place Record:** Carefully place your vinyl record on the platter. If playing a 45 RPM single, use the included adapter.
4. **Lift Tonearm:** Use the tonearm lift lever to raise the tonearm.
5. **Position Stylus:** Gently move the tonearm over the desired starting groove of the record.
6. **Lower Tonearm:** Slowly lower the tonearm using the lift lever. The stylus will make contact with the record and playback will begin.

7. **Adjust Volume:** Use the volume knob to set the desired listening level.

The record player features an auto-stop function that will stop the platter approximately three minutes after the record ends. The tonearm will not auto-return.



Image: A hand carefully positioning the tonearm and stylus onto a spinning vinyl record, initiating playback.

## 5.2 Bluetooth Connectivity

The sytiren PARON II Record Player can receive audio wirelessly from Bluetooth-enabled devices.

1. **Enable Bluetooth:** Switch the function selector to Bluetooth mode. The indicator light will flash, indicating it's in pairing mode.
2. **Pair Device:** On your smartphone, tablet, or other Bluetooth device, enable Bluetooth and search for available devices. Select "sytiren PARON II" (or similar name) from the list.
3. **Confirmation:** Once paired, the indicator light on the record player will stop flashing and remain solid. You can now stream audio from your device to the record player's built-in speakers.

## 5.3 External Audio Connections

The unit supports both Aux-in and RCA output for versatile audio connections.

- **Aux-in:** Connect an external audio source (e.g., MP3 player, CD player) to the AUX IN port using a 3.5mm audio cable. Select AUX mode on the record player to play audio from the connected



device.

- **RCA Output:** Connect the RCA output jacks on the back of the record player to an external amplifier or powered speakers using RCA cables. This allows you to use the record player as a source for a larger audio system.

## 6. MAINTENANCE

### 6.1 Cleaning the Stylus

A clean stylus ensures optimal sound quality and extends the life of your records. Use a soft brush designed for stylus cleaning, brushing gently from back to front.

### 6.2 Cleaning the Unit

Wipe the unit with a soft, dry cloth. For stubborn marks, a slightly damp cloth can be used, followed by a dry cloth. Avoid abrasive cleaners or solvents.

### 6.3 Dust Cover Care

The dust cover protects your turntable. Clean it with a soft, lint-free cloth. Avoid harsh chemicals that may scratch or cloud the plastic.

## 7. TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions:

Problem	Possible Solution
No power	Ensure the power adapter is securely connected to the unit and a working power outlet.
No sound from speakers	Check volume level. Ensure correct input mode (Phono, Aux, Bluetooth) is selected.
Skipping or distorted sound	Clean the record and stylus. Re-adjust the tonearm counterweight and anti-skating. Ensure the record player is on a stable, level surface.
Bluetooth not pairing	Ensure the record player is in Bluetooth pairing mode. Disable and re-enable Bluetooth on your device. Move closer to the record player.

If problems persist, please contact customer support for assistance.

## 8. SPECIFICATIONS

Feature	Detail
Model Name	PARON II
Item Model Number	SN13
Product Dimensions	17.4 x 14.96 x 7.48 inches (445 x 380 x 195 mm closed)
Item Weight	16 pounds (6 kg)
Material	MDF cabinet with PVC veneer finish (Wood, Metal, Plastic)
Turntable Speeds	33 1/3, 45 RPM
Cartridge Type	Audio-Technica AT3600L (Magnet-type)
Bluetooth Version	5.0
Wired Connections	AUX Audio Input, RCA Audio Output
Speaker Output	15W x 2 (Built-in 2.5" woofer and 2" tweeter)
Power Supply	DC 12V 1.5A
Special Features	Adjustable Counterweight, Built-In Speaker, Built-In Bluetooth Receiver, RCA Output, Suspension Shock Absorption System, S5 Motor System

Product Specifications

Net Weight:	6 kg	Bluetooth Version:	5.0
Material:	MDF cabinet with PVC veneer finish	Wired Connections:	AUX Audio Input, RCA Audio Output
Power Supply:	DC 12V 1.5A	Speaker Output:	15W x 2
Dimensions:	445 x 380 x 195 mm (closed), 445 x 430 x 460 mm (open)	Turntable Speeds:	33 / 45 RPM
		Cartridge Type:	Audio-Technica AT3600L

Product Dimensions





Image: A visual representation of the product's key specifications and detailed dimensions, including closed and open states.

9. WARRANTY AND SUPPORT






The sytren PARON II Record Player is designed for reliable performance. For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official sytren website.

Please retain your proof of purchase for any warranty claims.

Related Documents - SN13

	<p><a href="#">Sytren MANTY III High Fidelity Belt Drive Turntable: Operation Manual &amp; Safety Guide</a></p> <p>Comprehensive operation instructions, safety guidelines, and maintenance tips for the Sytren MANTY III High Fidelity Belt Drive Turntable. Learn how to play records and use Bluetooth connectivity.</p>
---	---



	<p><a href="#">Syitren R300 CD Player User Manual: Operation, Specifications, and Safety</a></p> <p>Comprehensive user manual for the Syitren R300 CD Player. This guide covers device specifications, setup, operation, playback modes, Bluetooth connectivity, power management, and important safety precautions for optimal use.</p>
	<p><a href="#">Syitren R300 CD Player Instruction Manual</a></p> <p>Instruction manual for the Syitren R300 CD Player, covering features, operation, product parameters, precautions, and FCC statement.</p>
	<p><a href="#">Syitren MANTY III High Fidelity Belt Drive Turntable: Operation Manual &amp; Safety Guide</a></p> <p>Comprehensive operation instructions, safety guidelines, and maintenance tips for the Syitren MANTY III High Fidelity Belt Drive Turntable. Learn how to play records and use Bluetooth connectivity.</p>
	<p><a href="#">Syitren R300 CD Player User Manual: Operation, Specifications, and Safety</a></p> <p>Comprehensive user manual for the Syitren R300 CD Player. This guide covers device specifications, setup, operation, playback modes, Bluetooth connectivity, power management, and important safety precautions for optimal use.</p>
	<p><a href="#">Syitren R300 CD Player Instruction Manual</a></p> <p>Instruction manual for the Syitren R300 CD Player, covering features, operation, product parameters, precautions, and FCC statement.</p>