

## AUXITO 9005+H11

# AUXITO H11 9005 LED Headlight Bulbs Combo Instruction Manual

Model: 9005+H11

## 1. PRODUCT OVERVIEW

The AUXITO H11 9005 LED Headlight Bulbs Combo provides enhanced illumination for your vehicle. These bulbs are designed for high and low beam applications, offering a bright, cool white light for improved visibility.



Image 1: AUXITO H11 9005 LED Headlight Bulbs Combo.

The bulbs feature a 1:1 design for easy replacement of original halogen bulbs and incorporate an efficient cooling system for extended lifespan.

## 2. WHAT'S IN THE BOX

Your AUXITO H11 9005 LED Headlight Bulbs Combo package includes:

- 2 x H11/H9/H8 LED Bulbs
- 2 x 9005/HB3 LED Bulbs
- 1 x User Manual
- 1 x Pair of Gloves

# WHAT'S IN THE BOX



Image 2: Package contents including H11 and 9005 bulbs, user manual, and gloves.

## 3. SPECIFICATIONS

Feature	Specification
Bulb Types	H11/H8/H9 and 9005/HB3
Light Source Type	LED (16 pcs 7035 chips per bulb)
Brightness	40000 Lumen (total for combo)
Color Temperature	6500 Kelvin (Cool White)
Wattage	120 Watts (total for combo)

Operating Voltage	DC 12-18V
Operating Life	50,000 hours
IP Rate	IP68 (Waterproof)
Operating Temperature	-40°F to +176°F
Housing Material	Aviation Aluminum

## 4. INSTALLATION GUIDE

Before installation, ensure your vehicle's engine is off and the lights are cool. It is recommended to wear the provided gloves to avoid touching the LED chips directly, as oils from your skin can affect performance and lifespan.

### 4.1. Compatibility Check

Before installing, verify that these bulbs are compatible with your vehicle. Consult your owner's manual or the original bulb's part number. The Amazon Confirmed Fit tool may not be 100% accurate.




Image 3: Guide to checking bulb fitment.




Image 4: Compare with your stock halogen bulb.

### 4.2. General Installation Steps

1. **Disconnect the Plug:** Locate the existing halogen bulb in your headlight assembly. Disconnect the electrical connector from the bulb.
2. **Remove the Halogen Bulb:** Carefully twist and remove the old halogen bulb from its housing.
3. **Insert the LED Bulb:** Align the locking tabs of the AUXITO LED bulb with the slots in the headlight housing. Insert the LED bulb into the right slot.
4. **Secure the LED Bulb:** Turn the LED bulb clockwise until it locks securely into place. Ensure the LED chips face the 3 and 9 o'clock positions for optimal beam pattern.
5. **Connect the Plug:** Connect the vehicle's electrical connector to the AUXITO LED bulb. These bulbs are non-polarized, allowing for plug-and-play installation.



Image 5: Visual guide for LED bulb installation.

### 4.3. Installation Videos

For a visual guide, please refer to the following installation videos:

#### How to install AUXITO H11/H8/H9 LED bulbs

Video 1: Step-by-step instructions for installing AUXITO H11/H8/H9 LED headlight bulbs.

#### How to install AUXITO 9005 LED headlight bulbs

Video 2: Step-by-step instructions for installing AUXITO 9005 LED headlight bulbs.

## 5. OPERATING INSTRUCTIONS

Once installed, the AUXITO LED headlight bulbs provide a crisp, focused beam of 6500K cool white light. This enhances visibility and allows for earlier reaction to road conditions.



# SEE FURTHER AND WIDER, REACT SOONER

Provide wider and further viewing area with clear, white light, making driving easier and safer.




Image 6: Enhanced visibility with AUXITO LED bulbs.

The double-sided chip design ensures a focused beam pattern with a clear cutoff line, illuminating the road effectively without blinding oncoming traffic.



Image 7: Clear cutoff line prevents glare to oncoming traffic.

## 5.1. All-Weather Performance

The IP68 waterproof rating ensures reliable operation in various weather conditions, including rain, snow, and fog.



Image 8: Reliable performance in diverse weather conditions.

## 6. MAINTENANCE

These LED bulbs are designed for a long operating life of over 50,000 hours, minimizing the need for frequent replacement.

### 6.1. Cooling System

The bulbs feature a quadruple cooling system to maintain optimal operating temperature and ensure longevity. This includes:

- Whole aviation aluminum body
- Built-in copper tube
- Copper baseboard
- Multilayer heat sink

The fanless design eliminates noise and contributes to the extended lifespan.



Image 9: Quadruple heat dissipation design for extended lifespan.



## 7. TROUBLESHOOTING

### 7.1. Flickering or Error Message

AUXITO LED headlights are built with an intelligent IC driver, making them compatible with 99% of vehicle systems. However, some sensitive models may still require a CANBUS decoder to prevent flickering or error messages on the dashboard. If you experience these issues, please contact AUXITO for assistance; a decoder can be provided directly.



Image 10: CANBUS-ready design for broad compatibility.

### 7.2. No Light

Ensure all connections are secure and the bulb is correctly inserted into the housing. Check your









vehicle's fuse box for any blown fuses. If the issue persists, contact customer support.

## 8. WARRANTY AND SUPPORT

AUXITO offers a 24-month warranty on its products. If you encounter any issues or have questions, please contact AUXITO customer service through the Amazon messaging service or their official website. Provide your order number and a clear description of the problem for prompt assistance.

© 2023 AUXITO. All rights reserved.

### Related Documents - 9005+H11

	<p><a href="#">Nakamichi GR870 LED Headlight User Manual and Installation Guide</a></p> <p>Comprehensive user manual for Nakamichi GR870 series LED headlights, covering installation instructions for various bulb types (H1, H4, H7, H11, 9005, 9006, 9012, D2, D4) and important safety information.</p>
	<p><a href="#">Auxbeam GX Series LED Headlight Bulbs Installation and Troubleshooting Guide</a></p> <p>Comprehensive guide for installing and troubleshooting Auxbeam GX Series LED headlight bulbs. Includes product specifications, safety precautions, installation steps for various models, and solutions for common issues.</p>
	<p><a href="#">Sealight S2S LED Headlight Bulb Installation and User Manual</a></p> <p>Comprehensive guide for installing and using Sealight S2S LED headlight bulbs, including product specifications, installation instructions, troubleshooting tips, and warranty information.</p>
	<p><a href="#">H7 LED Headlight Bulb Installation Guide</a></p> <p>Step-by-step instructions for installing premium H7 LED headlight bulbs, including removing old bulbs, attaching the adapter, connecting the driver and power, and sealing the housing.</p>
	<p><a href="#">Muxall LED Headlight Bulbs - H1, H3, H4, H7, H11, H13, 9004, 9005, 9006, 9012 - Installation &amp; Warranty</a></p> <p>High-quality Muxall LED headlight bulbs for various car models including H1, H3, H4, H7, H11, H13, 9004, 9005/HB3, 9006/HB4, and 9012. Includes installation precautions and warranty information.</p>
	<p><a href="#">SEALIGHT Scoparc S6 LED Headlight Bulb Installation Guide and User Manual</a></p> <p>Comprehensive guide for installing and using SEALIGHT Scoparc S6 LED headlight bulbs. Includes product specifications, installation instructions for various models, troubleshooting tips, and warranty information.</p>