Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WINNY POOL CLEANER HJ1102

WINNY POOL CLEANER HJ1102 Cordless Robotic Pool Vacuum Instruction Manual

1. Introduction

This manual provides essential instructions for the safe and efficient operation, maintenance, and troubleshooting of your WINNY POOL CLEANER HJ1102 Cordless Robotic Pool Vacuum. Please read this manual thoroughly before using the product and retain it for future reference.

2. Product Overview

The WINNY POOL CLEANER HJ1102 is a cordless robotic pool vacuum designed for efficient cleaning of flat-bottomed pools. It features a transparent design, a powerful 30W motor, and a high-quality filter system to capture fine debris. Its lightweight construction (approximately 6.6 lbs) ensures easy handling.

Key Features:

- **Cordless Operation:** Provides hassle-free cleaning without tangled cords.
- **Powerful Cleaning:** Equipped with a 30W motor for effective debris pickup.
- **High-Quality Filtration:** Traps super tiny particles for a cleaner pool.
- **Transparent Design:** Allows visibility of collected debris, indicating when the filter needs cleaning.
- **Lightweight:** Weighs approximately 6.6 lbs for easy retrieval and handling.
- **Smart Parking:** Automatically parks by the pool wall when the battery is low.
- **Versatile Use:** Suitable for various pool surfaces including tile, PVC liner, and gunite. Recommended for flat-bottomed pools.

Product Components:

The package includes the robotic pool vacuum, a charger, a retriever hook, a handle, and an instruction manual.



Figure 1: Transparent Design of the WINNY POOL CLEANER HJ1102. This design allows users to observe the dirt collection process.



Figure 2: The robotic cleaner demonstrating powerful cleaning capabilities, picking up dirt and debris.



Figure 3: Illustrates the cordless design, allowing for hassle-free operation.

3. Setup

Before first use, ensure all components are present and undamaged. Attach the handle to the top of the cleaner. The retriever hook is used for safely removing the cleaner from the pool.

4. Charging

The WINNY POOL CLEANER HJ1102 is powered by 3 Lithium Ion batteries (included). A full charge typically takes 3-4 hours and provides approximately 60 minutes of cleaning time. Use the provided charger to power the unit. Ensure the charging port is dry before connecting the charger.



Figure 4: The robotic cleaner charging, indicating a full charge takes 3-4 hours.




Figure 5: Illustrates the extended battery life, providing 60 minutes of cleaning for above-ground flat-bottom pools up to 30ft.

5. Operation

To operate the cleaner, ensure it is fully charged. Place the cleaner into the pool. It will begin its cleaning cycle automatically. The cleaner is designed to move across the bottom of the pool, collecting debris. When the battery is low, the cleaner will automatically move to the nearest pool wall for easy retrieval (Smart Parking feature).



Figure 6: The Smart Parking feature, where the cleaner automatically moves to the pool wall when its battery is low.

Your browser does not support the video tag.

Video 1: This video provides a detailed review of the WINNY Pool Cleaner Robotic Pool Vacuum, demonstrating its features and operation in a pool environment.

6. Maintenance

Regular maintenance ensures optimal performance and longevity of your pool cleaner. After each use, or when the transparent housing indicates it is full, the filter should be cleaned.

Cleaning the Filter:

1. Carefully remove the cleaner from the pool using the handle or retriever hook.
2. Open the top of the cleaner by releasing the tabs.
3. Remove the filter basket.
4. Empty any collected debris from the filter basket.

5. Rinse the filter basket thoroughly with clean water to remove fine particles.
6. Reassemble the filter basket and close the cleaner securely.

7. Troubleshooting

If you encounter issues with your WINNY POOL CLEANER HJ1102, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cleaner stops prematurely or has short run time.	Insufficient battery charge.	Ensure the unit is fully charged for 3-4 hours before use.
Cleaner gets stuck or does not move smoothly.	Obstruction or uneven pool surface (e.g., liner wrinkles).	Manually reposition the cleaner. Ensure the pool bottom is as flat as possible. This model is recommended for flat-bottomed pools.
Poor cleaning performance.	Full or dirty filter basket.	Clean the filter basket as described in the Maintenance section.

8. Specifications

Specification	Detail
Brand	WINNY POOL CLEANER
Model Name	HJ1102
Material	Aluminum, Fiberglass, Plastic, Stainless Steel
Color	Blue
Power Source	Battery Powered
Control Method	Touch
Efficiency	High cleaning efficiency
Lithium Battery Energy Content	8 Watt Hours
Number of Batteries	3 Lithium Ion batteries (included)
Battery Description	Lithium-Ion
Battery Weight	500 Grams
Required Assembly	No (minor handle attachment)
Installation Type	Robotic

9. Warranty and Support

This product comes with a Limited Warranty. For specific warranty terms and conditions, please refer to the

documentation included with your purchase or contact the manufacturer directly. For technical support or further assistance, please reach out to WINNY POOL CLEANER customer service.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why does my new Winny 200/HJ1102P robotic pool cleaner stop at the wall of my round pool and fail to continue its cleaning path despite changing the wheel settings?

Based on the manual for the WINNY POOL CLEANER HJ1102, here are the steps to troubleshoot why your cleaner is stopping at the wall and not navigating your round pool effectively: Check for Smart...

Read full answer

Where can I find a replacement directional flap for the WINNY POOL CLEANER HJ1102?

The instruction manual for the WINNY POOL CLEANER HJ1102 does not list individual part numbers for internal components like the directional flap. To obtain a replacement part, you should follow these steps: Contact Manufacturer...

Read full answer

Open the live page

https://manuals.plus/asin/B0CNRPGSHH

More documents and user manuals: **https://manuals.plus/**