



Manuals.plus /

› **Momcozy /**

› Momcozy Squeeze Station, Baby Food Maker & Pouch Filler for Homemade Baby Puree, BPA-Free, Dishwasher Safe, with Reusable Baby Food Pouches for Babies & Toddlers User Manual

Momcozy SE01

Momcozy Squeeze Station User Manual

Model: SE01

PRODUCT OVERVIEW

The Momcozy Squeeze Station is an innovative solution for preparing and storing homemade baby food purees. Designed for convenience and cleanliness, this station allows parents to easily fill reusable pouches with nutritious meals for their babies and toddlers. Its compact design and user-friendly features make healthy food preparation simple and mess-free.



Figure 1: Momcozy Squeeze Station and included accessories.

KEY FEATURES

- **Mess-Free Filling:** Anti-splash tubing design prevents puree from splattering, ensuring clean counters and fast, hassle-free pouch prep.
- **Easy to Clean:** Features a new drying method with no bottom water traps, allowing for faster drying and hygienic storage.
- **Ultra-Stable Design:** A wide base with a compact top prevents tipping or wobbling, providing stability during filling.
- **All-in-One System:** Combines filling, pressing, and dispensing in one device, eliminating the need for extra tools.
- **BPA-Free & Eco-Friendly:** Includes 5 reusable, BPA-free baby food pouches that are freezer safe, dishwasher safe, and portable, promoting sustainable feeding.

WHAT'S IN THE BOX

- 1 x Momcozy Squeeze Station

- 5 x Reusable Baby Food Pouches

SETUP AND OPERATING INSTRUCTIONS

Follow these steps to set up and operate your Momcozy Squeeze Station for preparing homemade baby food:

1. **Prepare the Station:** Ensure all components are clean and dry before use. Place the Squeeze Station on a stable, flat surface.
2. **Insert Pouches:** Slide a reusable pouch fully into the designated slot on the squeeze station. Ensure the pouch spout is aligned with the opening at the top.
3. **Attach Filling Tube:** Screw the filling tube securely onto the pouch spout.
4. **Pour Puree:** Carefully pour your prepared baby food puree into the filling tube. The clear tubes have visible measurement markings for precise filling.
5. **Press Puree:** Buckle the press (plunger) onto the filling tube. Slowly and steadily push down on the plunger to push the puree into the pouch. The anti-splash design helps prevent mess.
6. **Remove Filling Tube:** Once the pouch is filled to your desired level, unscrew the filling tube from the pouch spout.
7. **Remove Pouch:** Carefully remove the filled pouch from the station.
8. **Seal Pouch:** Screw the cap securely onto the pouch spout to seal it. The pouches are designed for easy sealing and portability.



Figure 2: Visual guide for filling baby food pouches with the Squeeze Station.



Double Seal Protection Say no to Food Splashing

Sealed Lid: Ensures that food won't spill out

Silicone Ring: No food residue left behind

Figure 3: The double seal protection feature ensures no food splashing during operation.

Comes With Reusable Baby Food Pouches



TIPS: We recommend replacing the food pouches every 2-3 uses

Figure 4: The triangular-like design provides enhanced stability during use.

MAINTENANCE AND CLEANING

Proper cleaning and maintenance will ensure the longevity and hygiene of your Momcozy Squeeze Station:

- **Dishwasher Safe:** All components of the Momcozy Squeeze Station are dishwasher safe for convenient cleaning. Place parts on the top rack for best results.
- **Hand Washing:** For hand washing, disassemble all parts and wash with warm, soapy water. Rinse thoroughly and allow to air dry completely.
- **Hygienic Drying:** The station is designed to allow components to hang for drying, preventing water pooling and ensuring hygiene.
- **Pouch Care:** The reusable pouches are also dishwasher safe. We recommend replacing the food pouches every 2-3 uses for optimal hygiene and performance.



Figure 5: All components are dishwasher safe for easy cleaning.



Figure 6: The innovative design allows for thorough drying and prevents water accumulation.

TROUBLESHOOTING

No specific troubleshooting steps are provided in this manual. If you encounter any issues with your Momcozy

Squeeze Station, please refer to the contact information in the Support section for assistance.

SPECIFICATIONS

Feature	Detail
Product Dimensions	8.6"L x 8.1"W x 5.6"H
Recommended Uses	Baby food
Special Feature	Dishwasher Safe
Container Shape	Rectangular
Closure Type	Clip-On or Latch
Material Type Free	BPA Free
Item Package Quantity	1
Item Volume	3 Cups
Unit Count	1.0 Count
Is Microwaveable	No
Manufacturer	Momcozy
Item model number	SE01
Material Type	Polypropylene, Silicone
Item Weight	1.8 pounds
Color	Squeeze Station
Capacity	3 Cups

WARRANTY AND SUPPORT

Specific warranty information is not provided in this manual. For product support, warranty claims, or any inquiries, please contact Momcozy customer service through their official website or the retailer where the product was purchased.